

Automatic blind riveting system GAV-electronic Model 8000 Model 8000 eco

fully automatic blind riveting system

Year of manufacture

Device no.

Operating Manual

including spare parts list and extras



Table of Contents

Table of Contents

| | Chapter | Page |
|-----|---|---------|
| 1. | Dimension sheet, specifications and working area..... | 4 |
| 2. | Intended use and safety instructions..... | 5 - 6 |
| 3. | Notes on environment, recycling, declaration of conformity..... | 7 |
| 4. | Transport and installation..... | 8 |
| 5. | Commissioning and handling | 9 - 10 |
| 6. | Operational characteristics | 11 |
| 7. | Description of functions | 12 - 16 |
| 8. | Operation | 17 |
| | 8.1 Operational controls | 18 |
| | 8.2 Graphic display | 19 |
| | 8.3 Structure of menu | 20 |
| | 8.4 Main menu | 21 - 22 |
| | 8.5 Error message | 23 - 25 |
| | 8.6 Access management | 26 |
| | 8.7 Manual operation | 27 |
| | 8.8 Setting parameters | 28 |
| | 8.9 Selecting data..... | 29 |
| | 8.10 Text input | 30 |
| 9. | Settings GAV | 31 |
| | 9.1 Oscillating conveyor | 32 |
| | 9.2 Pressure sensors | 33 - 35 |
| | 9.3 Large pressure transmitter | 36 - 39 |
| | 9.4 Small pressure transmitter | 40 - 41 |
| | 9.5 Singulator | 42 |
| | 9.6 Blast air | 43 - 44 |
| | 9.7 Mandrel extractor | 45 - 46 |
| | 9.8 Cycle..... | 47 |
| | 9.9 Additional functions | 48 |
| | 9.10 Drive PLC | 49 |
| | 9.11 Permanent test | 50 |
| | 9.12 I/O-test | 51 |
| | 9.13 PLC interface test | 52 |
| 10. | Maintenance | 53 |
| | 10.1 Notes on maintenance | 54 - 55 |
| | 10.2 Maintenance messages | 56 - 57 |

Table of Contents

Table of Contents

| | Chapter | Page |
|-----|---|------------------|
| 11. | Process control | 58 |
| | 11.1 Functional characteristics | 59 |
| | 11.2 Settings | 60 - 61 |
| | 11.3 Creating a profile | 62 - 66 |
| | 11.4 Loading a profile | 67 |
| | 11.5 Storing a profile | 68 - 69 |
| | 11.6 Creating a profile list | 70 - 73 |
| | 11.7 Loading a profile list | 74 |
| | 11.8 Profile lists PLC | 75 |
| | 11.9 Process Control Calibration | 76 |
| | 11.9.1 Force Calibration | 77 |
| | 11.9.2 Stroke Calibration | 78 |
| 12. | Process data | 79 |
| 13. | Process counter | 80 |
| 14. | Operating data collection | - |
| 15. | Access codes | 81 |
| 16. | Time and Language | 82 |
| 17. | System info | 83 |
| 18. | GRivCheck | 84 |
| 19. | Faults feeding unit | 85 |
| 20. | Faults blind rivetting gun | 86 - 89 |
| 21. | Repair instructions blind rivetting gun | 90 - 93 |
| 22. | Disassembly and assembly of pressure transmitter | 94 - 95 |
| 23. | Repair instructions pressure transmitter | 96 - 97 |
| 24. | Filling hydraulic systems | 98 - 99 |
| 25. | Replacing control components | 100 |
| 26. | Pneumatic connection diagram | 101 |
| 27. | Electric connection diagram | 102 - 103 |
| 28. | PLC interface | 104 |
| | 28.1 Technical description | 105 - 107 |
| | 28.2 PLC interface test | 108 |
| | 28.3 Drive PLC | 109 - 110 |
| | 28.4 Process counter | 111 |
| | 28.5 Selecting a profile list | 112 |
| | 28.6 Selecting a profile directly | 113 |
| | 28.7 Selecting a profile step by step | 114 |
| | 28.8 Evaluation process | 115 |
| | 28.9 Evaluation component | 116 |
| | 28.10 Other functions | 117 |

not included in GAV-8000 eco





Table of Contents

Table of Contents

Spare parts list

| | Overview subassemblies | Spare parts list page |
|--------------|---------------------------------|--------------------------|
| Assembly 1: | Pneumatic assembly | 2 - 3 |
| Assembly 2: | Blind riveting gun..... | 4 - 10 |
| Assembly 3: | Hydraulic amplifier unit | 11 - 12 |
| Assembly 4: | Singulator | 13 |
| Assembly 5: | Case unit | 14 |
| Assembly 6: | Oscillating conveyor unit | 15 |
| Assembly 7: | Feed bundle | 16 |
| Assembly 8: | Controls..... | 17 |
| Assembly 9: | Accessories | 18 - 19 |
| Assembly 10: | Front plate | 20 |
| Assembly 11: | Cable tree | 21 - 23 |

Dimension sheet, specifications and working area



Feed unit

Weight: 100 kg
Volume remaining mandrel collecting basin: approx. 1800 – 5500 pieces (3.5 l) depending on size

Electrics

- Rated voltage: 230 Volt ~ 50 Hz
- Rated current: < 2,5 A
- System of protection: IP 54

Pneumatic equipment

- Network pressure: < 10 bar
- Working pressure: 6 -7 bar
- Air consumption / blind riveting process: 15 NL
- Air consumption / vacuum extractor for remaining mandrels (VE): 340 NL/min.
- Connecting line: ½ " (12.5 mm) max. length 5m
- Outlet hose remaining mandrel: 3.75 m length / exterior-Ø8 mm / interior-Ø5 mm
- Pressure transmitter: pneumatic / hydraulic

Hydraulic

- Hydraulic oil ISO-VG 46 (e.g. Shell Hydrol HV 46 or comparable HVLP-D products): 1.2 l
- Viscosity, kinematic at 40°C (DIN 51562) without silicone parts: 47 mm² / s

Ambient temperature: 10 -40°C

Blind riveting gun


- Weight: approx. 2.5 kg
- Setting motion: 16 -20 mm
- Setting force: 11770 N
- Hose assembly length (standard): 3.75 m
- Working cycle (theoretical setting performance) intended use: 1.25 sec.

Working environment

- Blind rivet up to Ø 5,0 mm stainless steel
- Blind rivet up to Ø 6,0 mm steel
- Blind rivet up to Ø 6,4 mm aluminium
- Maximal setting head diameter: 11.4 mm
- Maximal blind rivet shaft length: 25.0 mm
(additional size on request)

According to the supply agreement the device is designed for a specific blind rivet model suitable for automatic systems.





Feed unit

Weight: 100 kg
Volume remaining mandrel collecting basin: approx. 1800 – 5500 pieces (3.5 l) depending on size

Electrics

- Rated voltage: 230 Volt ~ 50 Hz
- Rated current: < 2,5 A
- System of protection: IP 54

Pneumatic equipment

- Network pressure: < 10 bar
- Working pressure: 6 - 7 bar
- Air consumption / blind riveting process: 15 NL
- Air consumption / vacuum extractor for remaining mandrels (VE): 340 NL/min.
- Connecting line: ½ " (12.5 mm) max. length 5m
- Outlet hose remaining mandrel: 3.75 m length / exterior-Ø8 mm / interior-Ø5 mm
- Pressure transmitter: pneumatic / hydraulic

Hydraulic

- Hydraulic oil ISO-VG 46 (e.g. Shell Hydrol HV 46 or comparable HVLP-D products): 1.2 l
- Viscosity, kinematic at 40°C (DIN 51562) without silicone parts: 47 mm² / s
Ambient temperature: 10 - 40°C


Blind riveting gun

- Weight: approx. 2.5 kg
- Setting motion: 16 - 20 mm
- Setting force: 11770 N
- Hose assembly length (standard): 3.75 m
- Working cycle (theoretical setting performance) intended use: 1.25 sec.

Working environment

- Blind rivet up to Ø 5,0 mm stainless steel
- Blind rivet up to Ø 6,0 mm steel
- Blind rivet up to Ø 6,4 mm aluminium
- Maximal setting head diameter: 11.4 mm
- Maximal blind rivet shaft length: 25.0 mm
(additional size on request)

According to the supply agreement the device is designed for a specific blind rivet model suitable for automatic systems.



Feed unit

Weight:

100 kg

Volume remaining mandrel collecting basin: approx. 1800 – 5500 pieces (3.5 l) depending on size

Electrics

- Rated voltage:

230 Volt ~ 50 Hz

- Rated current:

< 2,5 A

- System of protection:

IP 54

Pneumatic equipment

- Network pressure

< 10 bar

- Working pressure:

6 -7 bar

- Air consumption / blind riveting process:

15 NL

- Air consumption / vacuum extractor for remaining mandrels (VE):

340 NL/min.

- Connecting line:

½ " (12.5 mm) max. length 5m

- Outlet hose remaining mandrel:

3.75 m length / exterior-Ø8 mm / interior-Ø5 mm

- Pressure transmitter:

pneumatic / hydraulic

Hydraulic

- Hydraulic oil ISO-VG 46 (e.g. Shell Hydrol HV 46 or comparable HVLP-D products):

1.2 l

- Viscosity, kinematic at 40°C (DIN 51562) without silicone parts:

47 mm² / s

Ambient temperature:

10 -40°C

Blind riveting gun

- Weight:

approx. 2.5 kg

- Setting motion:

16 -20 mm

- Setting force:

11770 N

- Hose assembly length (standard):

3.75 m

- Working cycle (theoretical setting performance) intended use:

1.25 sec.

Working environment

- Blind rivet up to Ø 5,0 mm stainless steel

- Blind rivet up to Ø 6,0 mm steel

- Blind rivet up to Ø 6,4 mm aluminium

- Maximal setting head diameter:

11.4 mm


- Maximal blind rivet shaft length:

25.0 mm

(additional size on request)

According to the supply agreement the device is designed for a specific blind rivet model suitable for automatic systems.

GESIPA®



Feed unit

Weight:

100 kg

Volume remaining mandrel collecting basin: approx. 1800 – 5500 pieces (3.5 l) depending on size

Electrics

- Rated voltage:

230 Volt ~ 50 Hz

- Rated current:

< 2,5 A

- System of protection:

IP 54

Pneumatic equipment

- Network pressure

< 10 bar

- Working pressure:

6 -7 bar

- Air consumption / blind riveting process:

15 NL

- Air consumption / vacuum extractor for remaining mandrels (VE):

340 NL/min.

- Connecting line:

½ " (12.5 mm) max. length 5m

- Outlet hose remaining mandrel:

3.75 m length / exterior-Ø8 mm / interior-Ø5 mm

- Pressure transmitter:

pneumatic / hydraulic

Hydraulic

- Hydraulic oil ISO-VG 46 (e.g. Shell Hydrol HV 46 or comparable HVLP-D products):

1.2 l

- Viscosity, kinematic at 40°C (DIN 51562) without silicone parts:

47 mm² / s

Ambient temperature:

10 -40°C

Blind riveting gun

- Weight:

approx. 2.5 kg

- Setting motion:

16 -20 mm

- Setting force:

11770 N

- Hose assembly length (standard):

3.75 m

- Working cycle (theoretical setting performance) intended use:

1.25 sec.

Working environment

- Blind rivet up to Ø 5,0 mm stainless steel

- Blind rivet up to Ø 6,0 mm steel

- Blind rivet up to Ø 6,4 mm aluminium

- Maximal setting head diameter:

11.4 mm

- Maximal blind rivet shaft length:
(additional size on request)

25.0 mm

According to the supply agreement the device is designed for a specific blind rivet model suitable for automatic systems.

Intended use and safety instructions

Intended use

- The blind riveting tool is intended exclusively for the processing of blind rivets suitable for use in automatic systems. Any other use or use beyond those limits will not be considered as intended.
- Operators must receive instruction and follow safety instructions.

Safety instructions

- The machine is designed in accordance with the latest state-of-the-art technology and accepted safety regulations.
- When put to the use intended, a safe work environment will be ensured.
- The device is intended exclusively for the processing of blind rivets.
- Read the operating instructions before commissioning.
- Any work on the electrical equipment of the device must be carried out by an electrical specialist in accordance with the rules of electro technology.
- Any work on the mechanical, hydraulic or pneumatic system must be carried out by instructed persons with a special knowledge of the device.

Attention!



- To protect against electrocution, injury and danger of fire during all setting, maintenance and repair work, or the elimination of device disturbances there is a duty to ensure that
 - protective goggles are worn
 - the electric mains plug has been pulled
 - the pneumatic air supply was separated from the device
 - no blind rivet is present on the chute or singulator
 - the gun is at no time aimed at persons or other creatures.
- The blind rivet is conveyed at high speed from the feed unit through the conveying hose to the blind riveting gun!
- It is absolutely essential that the measures described above are followed when the feed hose or the expanding mouth piece have to be removed during repair or maintenance work ; in addition to this attach a warning sign to the device.
- Non-compliance with intended use or inexpert handling may result in injury.

Intended use and safety instructions

Prevention of accidents

Working with the GAV-8000 is only permitted for persons who

- have read and understood the operating and safety instructions (training!)
- have checked the device and the working area for hazards to life and limb before starting to work
- comply with accident prevention regulations
- do not wear their hair loose or loose fitting clothes or jewellery including rings (hazard of injury!)
- wear personal safety gear, such as: protective clothing, protective goggles, ear protection, protective shoes and gloves.

Work place

- This blind riveting tool is only intended as a place of work for an instructed operator possessing the special knowledge required for this tool.
- Keep your work place tidy.
- Do not expose the blind riveting tool to rain, wetness or dampness.
- Do not use the blind riveting tool near flammable gasses or liquids. Risk of explosion!
- Ensure sufficient lighting at the work place.
- Ensure the provision of a safe floor for operators and the riveting tool as uneven floors pose a danger of injury.
- Comply with the regulations for hazardous materials when handling hydraulic oil.

Blind riveting tool

The expanding mouth piece and the rivet mandrel conveying appliance with outlet hose or a mandrel collecting basin must be mounted before the blind riveting tool is commissioned.

Attention!



- Do not rivet without joint material! The blind rivet may shoot off the device! Do not point the device towards yourself or other persons!
- Do not overload the blind riveting tool.
- Always check blind rivet system for perfect working order before use.
- If a conveying frame is mounted, lock the guide rolls first.
- Maintenance and repair is to be carried out by a suitable expert. If in doubt, send the device to the manufacturer.
- Spare parts and fittings must meet the requirements determined by the manufacturer. This is guaranteed when genuine parts are used.
- When putting the blind riveting gun onto a surface secure it against falling.
- Proper care of blind riveting tool (Keep handle dry and free of oil and grease)
- Check plugs and cables on a regular basis. When damaged, have them repaired by an electrical specialist.
- Check compressed air and hydraulic connections and hoses regularly. When damaged, have them replaced by an instructed person.

Notes on environment, recycling, Conformity declaration

Notes on environment

- Noise of blind riveting plant
Applied guidelines:
89/392/EWG Abl. EU Nr. L 183/9
3. GSGV machine noise information-VO DIN 45635 part 21
Permanent noise level: **L_{PA} 78/84 dB** with/without conveyor unit
- Vibration of the GAV gun.
Rules of check:
Check according to ENV 28662-1; 9. GSGV; 91/368/EWG ISO 2631; 9. GSGV;
91/368/EWG as well as the guidelines pointed out there
<2,55 m/s²

uncertainty K= 1 m/s²

Recycling

- Hydraulic used oil and remaining drifts must be recycled accordingly.
- Observe regulations about dangerous substances.


Conformity declaration

We hereby declare under our sole responsibility that these products meet following standards and directives:

- 2006/42/EG
- 2006/95/EG
- 2004/108/EG



Signature
of the manufacturer



Signature
Safety specialist

Transport and installation

Transport

- The blind riveting tool will be delivered and erected as agreed, or dispatched in a special wooden crate.
- Unpacked, the blind riveting tool can be moved on an even floor with the help of the trolley available under extras. The blind riveting tool must be transported upright by using the two transport eyes at the top of the feed unit and suitable lifting gear, or secured on a pallet, by using a lift-truck or high-lift truck.



Attention! The blind riveting tool is supplied ready for connection and the sealed hydraulic system contains approx. 1.2 litre of hydraulic oil. To ensure stability, transport the feed unit in an upright position at all times

Installation

- Working pressure: min. 6 bar
 - The compressed air supply has to be arranged in such a way that 750 NL/min. of dry dressed, oil-free compressed air is available which must not be allowed to drop below 6 bar whilst the GAV is in operation (do not use mist lubricator!)
 - Pipework diameter 3/4"



Attention! The compressed air hose must have an inner diameter of at least 12.5 mm (1/2") During blind riveting the pressure must not drop below 6 bar; control via pressure gauge showing operating pressure.

- Hydraulic oil: For viscosity see specifications.
- Electrical connection: 230 V ~ 50 Hz, alternatively 115 V ~ 60 Hz.

Commissioning and handling

Note!




Prior to commissioning read, and comply with, the GAV operating instructions and safety instructions. In addition, comply with occupational safety regulations.

Commissioning


- Connecting the device to the compressed air supply network
- Use the pressure reducing valve 1-8002, to set the operating pressure to 6 bar; control via pressure gauge 1-8046
- Establishing electrical connection
- Use main switch to turn on device
- Fill about half of the oscillating conveying bowl and turn on oscillating conveyor (F4 key, see chapter 8 "Operation")
- Set the singulator tongue 4-8007 with the help of the setting screw in such a way that only one blind rivet at a time is separated
- Actuate the "ON" key
- Trigger the blind riveting gun twice (Menu "MAN" function "cycle"). The first blind rivet is made ready in the expanding mouth piece.

According to the supply details the device is designed for a specific blind rivet size. Despite this, check that


- the inner diameter of the rivet feed hose 7-8020 is 2-3 mm greater than the setting head diameter of the blind rivet (setting head diameter max. 11.4 mm)
- the drill hole of the expanding mouth piece 2-80 is approx. 0.3 mm greater than the blind rivet mandrel diameter. Cylindrically elongated expanding mouth pieces providing up to 15 mm extension are available for awkward blind riveting points (pay attention to blind riveting mandrel length)
- If required, the clamping force of the expanding mouth piece 2-80 can be increased by mounting additional O-rings 2-50.



Singulator 4-8000




Expanded mouth piece 2-80




Commissioning and handling

- The appropriate chuck jaws for each blind riveting mandrel diameter are used. Chuck jaw scaling is as follows:

| Blind rivet mandrel diameter |
|------------------------------|
| 1.5 to 2.1 mm |
| 2.1 to 2.7 mm |
| 2.7 to 3.3 mm |
| 3.3 to 3.65 mm |



- The adjustable deflection sheet leading to the outlet drain of the oscillating conveyor bowl 608002 is set in such a way that only one blind rivet is able to pass this baffle.
- Depending on each blind riveting mandrel diameter the distance between the chute sheets 4-8138 is set at an approximate mandrel diameter of +0.5 mm.



Handling

- Insert the blind rivet that is provided in working position inside the blind riveting gun up to its setting head into the blind riveting hole.
- The blind riveting process is triggered by pressing the trigger button, the torn off blind rivet mandrel is carried off and the next blind rivet is brought automatically into working position.

To allow the next blind rivet to be conveyed from the expanding mouth piece without hindrance, the blind riveting gun has to be pulled away from the blind riveting point immediately after the blind rivet mandrel is torn off.

- The remaining mandrels are conveyed automatically to the collecting basin. Afterwards the vacuum extractor (VE) is turned off automatically.

Note!



The collecting basin holds approx. 1800 to 5500 remaining mandrels (depending on size). Ensure that the collecting basin is emptied in good time.

- The blind riveting gun can be hung up ready for use at the work place with the help of a balancer.
- The feed unit must be placed and used on even ground only. The operator has to ensure always its stability.

Sequence of operations


The fully automatic blind riveting tool GAV-electronic comprises a feed unit and a handy blind riveting gun which are connected by a flexi-hose assembly.

The feed unit comprises an electronic control with dialogue box, two hydraulic pressure transmitters, an electrical blind riveting conveyor unit and a remaining mandrel extractor with mandrel collecting basin.

When the blind riveting gun is triggered, the blind rivet waiting inside the nose piece is processed, the torn off blind riveting mandrel is conveyed to the collecting basin and the reloading process is triggered automatically.

The oscillating conveyor unit with cut-off automatic ensures continuous provision of blind rivets.


GAV blind riveting gun



Description of functions

7 Functional components of blind riveting gun

The schematic diagrams and descriptions below show a simplified version of the extensive control and functional sequences.



Expanding mouth piece - three-pieces - (1)

Loading the blind rivet positioned in the gun head to processing position.

Snap collet (2)

carries out the unlocking and locking function of the expanding mouth piece (1).

Chuck jaws (3)

for gripping of blind rivet mandrel (9) and setting of blind rivet (10).

Chuck jaw tube (4)

transmits the snapping pressure to the chuck jaws (3) to ensure safe gripping of blind rivet mandrel (9) and setting of blind rivet (10).

Stop piston (5)

Final stop for blind rivet mandrel (9) during loading process of blind rivet

Locking spring (6)

positions the blind rivet (10) supplied to the gun head.

Pulling piston (7)


supports the complete gripping mechanism used to set the blind rivet (10).

Pressure piston (8)

supports the snap collet (2) operating the locking and unlocking process of the expanding mouth piece (1).

Description of functions

7 Functional units of feed unit



Blind rivet singulator (II)

Part of blind riveting feed appliance. Here, the blind rivet (10) is separated and conveyed by compressed air through the conveying hose to the blind riveting gun.

Pneumatic-hydraulic pressure transmitter (III)

actuates the pressure piston (8); thereby triggering the unlocking stroke for the expanding mouth piece.

Pneumatic-hydraulic pressure transmitter (IV)

actuates the pulling piston (7) to carry out the blind rivet setting lift and the rear side of the pressure piston (8) to lock the expanding mouth piece (1) during the setting process.

Whilst the piston system is moving forward and back inside the pressure transmitter (IV) impulses are accepted via the cylinder switch for function operations.


Valve (V)

turns on the readjusting air, thus returning the complete piston unit (7/8) to initial position. The stop piston (5), chuck jaw hose (4) and snap collet (2) are kept by the relevant pistons in locking or final position until the completion of the blind riveting process by the pending readjusting air.

Description of functions


7 Functional components of blind riveting gun

Function image 1



The readjusting air interconnected by the valve (V) is waiting and keeps the complete piston unit (7/8) in back stop position. The snap collet (2) locks the segments of the expanding mouth piece (1) at their undercut. The chuck jaws (3) are kept locked by the chuck jaw hose (4) on the blind riveting mandrel (9).

Function image 2




When the GAV is actuated the pulling piston (7) will be actuated by the pressure transmitter (IV) and the blind rivet setting process will be carried out. The blind rivet is set. The readjusting air is still pending.

Description of functions


7 Function images and description

Function image 3



The pulling piston (7) is being actuated by the pressure transmitter (IV) and moves to back stop position. When the valve is switched (V) the readjusting air escapes. This relieves the stop pistons (5) as well as the chuck jaw hose (4) and the chuck jaws (3) release the blind riveting mandrel (9). The blind riveting conveying air is turned on by a switch impulse on the pressure transmitter (IV), the blind rivet (10) supplied by the singulator (II) is loaded and the torn off blind riveting mandrel (9) is ejected.

Function image 4




The supplied blind rivet (10) is positioned in the gun head (6) by the locking spring.

Description of functions


7 Function images and description

Function image 5



The readjusting air is interconnected by the valve (V) and the pulling piston (7), as well as the piston of the pressure transmitter (IV), is reset at initial position. Simultaneously, the pressure piston (8) is actuated by the pressure transmitter (III) and carries out the unlocking stroke for the expanding mouth piece (1). The blind rivet mandrel (9) is taken over by the gripping mechanism and centred inside the chuck jaws (3).


Function image 6



Whilst the pulling piston (7) continues to reverse, the blind riveting mandrel (9) hits the stop piston (5), so that the expanding mouth piece (1) is opened by the blind rivet (10) bringing it into processing position. The pressure transmitter (III) relieves the pressure piston (8) which carries out the locking stroke for the expanding mouth piece (1). Triggered by a switch impulse on the pressure transmitter (IV), the singulator was furnished with a further blind rivet (10).

Operation


8.0 Overview



- 8.1 Operating elements
- 8.2 Graphic display
- 8.3 Menu structure
- 8.4 Main menu
- 8.5 Error message
- 8.6 Access management
- 8.7 Manual Operation
- 8.8 Setting parameters
- 8.9 Selecting data
- 8.10 Text input

Operation

8.1 Operational controls




1. **POWER** switch (main switch)
 - Switches the supply voltage (230V/50Hz or 110V 60Hz).
 - glowing green.
2. **ON** button
 - activates various control functions (dependent on display menu).
 - moves GAV into initial position.
 - glowing green.
3. **OFF** button
 - deactivates various control functions (dependent on display menu).
 - cuts off power to valves.
 - glowing red.
4. Function keys **F1..F6**
 - carry out various functions (dependent on display menu).
 - keys glowing orange.
5. Control knob / **OK** button
 - carries out various functions (dependent on display menu).



Operation

8.2 Graphic display




The graphic display is part of the dialogue unit and allows interactive control of the GAV. The graphic display shows the status and parameters, issues messages and visualises internal processes. Uniform display components and a well-structured menu ensure user-friendly handling.

1. The **title bar** of the graphic displays provides information about the current menu.
2. The graphic display's **function bar** is sub-divided into 6 fields and shows the assigned functions of the function keys F1 to F6 for the current menu.
3. Within the menus, functions may be selected by using the control knob of the dialogue unit or by pushing the control knob. Each selection is indicated by highlighting the relevant part with an added frame.

Operation

8.3 Menu structure

The following list shows how to access the various menus. Selections are made by using the function keys or the control knob. It is possible to return from each menu to the previous menu by selecting **Back**.



not included in GAV-8000 eco

Operation

8.4 Main menu

After start-up and during normal operation the GAV will be in the main menu AUTO.

AUTO / Ready (Manual)

Cycle ☐

Lift position ☐

Blast air ☐

Mandrel extractor ☐

Lock open ☐

Singulator open ☐

Modul 01

Monitoring
device ready

-
(1/6)

Oscillating conveyor

?
Off
On
Stby
MAN

AUTO main menu
Status "Ready"
Start option "manual" (man-
ual release)

Navigation:
AUTO

| Title bar | Status |
|--|---|
| AUTO-OFF (press ON) | <u>GAV switched on (main switch "POWER")</u> - Power to valves cut off. |
| Generating AUTO initial position... | <u>ON key actuated:</u> - Initial position is generated. |
| AUTO initial position | <u>Initial setting:</u> - Initial position was generated. - Start-up conditions not met: MALFUNCTION or oscillating con- veyor OFF |
| AUTO ready (manual) | <u>GAV ready (start-up conditions met):</u> - GAV in initial position - Start-up conditions met no malfunction and oscillating conveyor ON - Start-up options: Manual = Manual trigger Foot = foot-actuated triggering PLC = Drive PLC ... |

| | |
|--|--|
| Oscillating conveyor OFF / ON | controls the oscillating conveyor unit. By selecting "oscillating conveyor" you can go directly to the "set oscillating conveyor" menu and set, for instance, the conveying performance. |
| Stby | puts the GAV into standby mode. For this, the display goes dark and the GAV is switched to "OFF". This function is undone by pressing any key. |
| MAN | changes to MAN menu, i.e. manual mode. |

The display in the main menu may differ from the image shown if additional functions such as "process counters" are active.

Operation

8.4 Main menu

When the start-up conditions of the AUTO mode have been met, one of the active start-up options (shown in title bar) can be used to trigger a cycle. The current tool status is shown on the title bar of the main menu. In addition, the most important tool functions are shown by 6 red lights.

| Step in cycle | Tool status |
|--|---|
| <u>GAV ready</u> - Start-up conditions met - The displayed start-up option can be used to trigger a cycle. | AUTO ready (manual) Cycle ● Lift position ● Blast air ● Mandrel extractor ● Lock open ● Singulator open ● |
| <u>Cycle up to lift position:</u> - Processing blind rivet. - Ejecting and extracting remaining mandrel. | AUTO cycle up to lift position Cycle ● Lift position ● Blast air ● Mandrel extractor ● Lock open ● Singulator open ● |
| <u>Cycle lift position reached:</u> - GAV gun has reached back stop position. - Extracting remaining mandrel. | AUTO cycle lift position reached Cycle ● Lift position ● Blast air ● Mandrel extractor ● Lock open ● Singulator open ● |
| <u>Cycle lift position ready:</u> - GAV gun has reached back stop position. - Remaining mandrel extracted. - When triggered by PLC the GAV stops in this position until the gun has moved away from the work piece and the signal "reverse cycle" was sent from the PLC to the interface. | AUTO cycle lift position ready Cycle ● Lift position ● Blast air ● Mandrel extractor ● Lock open ● Singulator open ● |
| <u>Reverse cycle:</u> - Loading new blind rivet. | AUTO reverse cycle Cycle ● Lift position ● Blast air ● Mandrel extractor ● Lock open ● Singulator open ● |
| <u>Cycle complete</u> - Initial position reached after cycle. | AUTO cycle complete Cycle ● Lift position ● Blast air ● Mandrel extractor ● Lock open ● Singulator open ● |

Operation

8.5 Error message

Tool malfunctions are shown in the AUTO main menu by displaying a white text in a red box, whilst warning lights are blinking. Details of the causes of malfunctions can be found in the relevant menu of "settings GAV".

AUTO main menu
Status "initial position"
3 Error message

Navigation:
AUTO

| Error message | Submenu | |
|--|---|--|
| | Remedy | Navigation |
| Oscillating conveyor Insufficient blind rivet sent. | Setting the oscillating conveyor | |
| | Insert blind rivet or check oscillating conveyor setting. | <ul style="list-style-type: none"> ▶ MAN ▶ Menu ▶ Settings GAV ▶ Oscillating conveyor |
| Network pressure Air supply not in permitted pressure range. | Setting the pressure sensor DS1/DS2 | |
| | Ensure sufficient compressed air supply. | <ul style="list-style-type: none"> ▶ MAN ▶ Menu ▶ Settings GAV ▶ Pressure sensors |
| Oil level Oil level of great pressure transmitter has dropped below minimum mark or exceeded maximum mark. | Setting the large pressure transmitter WS2 | |
| | Correct oil level of great pressure transmitter, mind oil level mark. | <ul style="list-style-type: none"> ▶ MAN ▶ Menu ▶ Settings GAV ▶ Large pressure transmitter ▶ WS2 |
| Oil level of small pressure transmitter has dropped below minimum mark. | Setting the small pressure transmitter WS3 | |
| | Use oil squirting can to position piston rod in upper stop position. | <ul style="list-style-type: none"> ▶ MAN ▶ Menu ▶ Settings GAV ▶ Small pressure transmitter |
| Rivetting gun GAV gun did not reach front stop position. | Setting the large pressure transmitter WS2 | |
| | See Chapter 20 "Malfunction blind riveting gun" | <ul style="list-style-type: none"> ▶ MAN ▶ Menu ▶ Settings GAV ▶ Large pressure transmitter ▶ WS2 |

Operation

8.5 Error message


| Error message | Submenu | |
|--|--|---|
| | Remedy | Navigation |
| Mouth piece | Setting the small pressure transmitter WS3 | |
| Expanding mouth piece of GAV gun did not close. | - Press OFF button. - Remove blind rivet. Press ON button. | ► MAN ► Menu ► Settings GAV ► Small pressure transmitter |
| Singulator | Setting the singulator | |
| Singulator did not close, blind rivet jammed. | Open singulator in MAN mode and remove blind rivet. | ► MAN ► Menu ► Settings GAV ► Singulator |
| Mandrel extractor | Setting the mandrel extractor | |
| Remaining mandrel was not ejected. | See Chapter 20 "Malfunction blind riveting gun" | ► MAN ► Menu ► Settings GAV ► Mandrel extractor |
| Mandrel basin full | Setting the mandrel extractor | |
| Remaining mandrel basin full. | Empty remaining mandrel basin. | ► MAN ► Menu ► Settings GAV ► Mandrel extractor |
| Rivet query mouth piece | Setting the drive of PLC | |
| Blind rivet not loaded. | See Chapter 20 "Malfunction blind riveting gun" | ► MAN ► Menu ► Settings GAV ► Drive PLC |
| Rivet query conveyor | Setting additional functions | |
| Blind rivet not conveyed. | See Chapter 20 "Malfunction blind riveting gun" | ► MAN ► Menu ► Settings GAV ► Additional functions |
| Cycle | Setting the cycle | |
| Malfunction in cycle, blind rivet was not processed. | See Chapter 20 "Malfunction blind riveting gun" | ► MAN ► Menu ► Settings GAV ► Cycle |

Operation

8.5 Error message

Direct menu selection:

In order to simplify the search for the relevant menu containing information about the cause of the malfunction, and to use a shortcut, you can change the option in the main menu to the displayed error message by using **?**. After selecting an error message and pressing the control knob you will go directly to the relevant menu. To return from there to the main menu, use **back**.



Example:


In the example **?** and "malfunction oil level" were selected in order to go directly to the "Setting the great pressure transmitter WS2" menu. Here, the setting parameter "malfunction oil level min." is highlighted red in order to indicate the cause for the malfunction, the current oil level in the oil tank of the pressure transmitter is indicated numerically and displayed graphically.

For the example shown, the malfunction may be removed by topping up hydraulic oil in the great pressure transmitter. The numeric and graphic display for the oil level on the display allows the observation of the topping up process.

Operation

8.6 Access management


Access management ensures that service and setting work for the GAV can be carried out by authorised persons only. Access authorisation is granted after entering a four digit access code. There are two levels of access authorisation:

| | |
|---|---|
| - Service code | For service and general setting work. |
| - GESIPA code | For the input of calibration data. In the operating instructions the relevant menus are marked accordingly. |
|  GESIPA-Code | |

For most menus, access authorisation is only demanded when parameters or settings are to be changed. Once access authorisation is granted, this will be valid for the entire manual area. A return to the AUTO main menu will delete all access authorisations.

Entering an access code:

To enter an access code, an additional window appears in the relevant menu and the navigation bar is changed accordingly. The **title bar** of the window shows which access code must be entered, that is, the service or the GESIPA code.

The access code is entered by using numbers **1** to **4**. Numbers are entered by starting in the left field and, for hidden input (standard) are indicated by one star  per number.


The default setting for the service code is 1111.

Cancel interrupts the code input.

New enables renewed input of a code.

Access will be granted after the correct code was entered.

Access authorisations are deleted in the main menu.



Example code input
Service code

Title bar

Navigation:
AUTO
► MAN

Example:

In the example, "cycle" function was selected in the "MAN" menu. This function requires the access authorisation "service code" before it can be carried out.

Operation

8.7 Manual mode

The MAN menu allows GAV functions to be carried out manually. Malfunctions of the tool are shown in the same way as in the AUTO main menu but there are no start-up conditions. **For reasons of safety all the active start options of the AUTO main menu are disabled for the entire manual area.**

Manual operation MAN

Navigation:
AUTO
► MAN

| Function | Description |
|---|---|
| Cycle | <ul style="list-style-type: none"> - Conditions: GAV in initial position - Running complete processing cycle. |
| Lift position | <ul style="list-style-type: none"> - Conditions: GAV in initial position - Gun moves to back stop position with “gun air off”, “blast air on” and “drift extractor on” functions not being carried out. - Actuating the ON button once more will return the GAV to initial position, For this the “blast air off”, “lock open” and “singulator open” functions are not carried out. |
| Blast air | <ul style="list-style-type: none"> - Conditions: “Lift position active” function - “blast air on” function is activated. - “drift extractor on” function is activated. - “gun air off” function is activated. |
| Drift extractor | <ul style="list-style-type: none"> - Conditions: none - “drift extractor on” function is activated. - To reset this function, again operate the ON button. |
| Lock open | <ul style="list-style-type: none"> - Conditions: GAV in initial position - “lock open” function is activated. - To reset this function, again operate the ON button. |
| Singulator open | <ul style="list-style-type: none"> - Conditions: GAV in initial position - “singulator open” function is activated. - To reset this function, again operate the ON button. |
| Oscillating conveyor OFF / ON | same function as AUTO main menu. |
| Stby | same function as AUTO main menu. |
| MAN | changes to MAN menu, i.e. manual mode. |
| Menu | goes to selection menu. |
| AUTO | back to AUTO main menu. |

Operation

8.8 Setting parameters

Variable parameters are displayed and set the same way for all menus.

Setting range and step sizes may be limited according to parameter and data type.

High precision parameters have multi-step settings. For this, the whole number and decimal digits can be set in two steps, great values first in hundreds and then in unit digits.

Example:

Setting the conveying performance oscillating conveyor in "Set oscillating conveyor" menu.

Setting oscillating conveyor

0 %

Conveying performance 0 % of 70 %

Shut off delay 5 s of 5 s

Rivet counter 3 of 3

Running period 0 s of 15 s

Back Strd Off On

| Step | Input | Result |
|---------------------|-------|--|
| 1. Select parameter | | Conveying performance 0 % of 70 % Shut off delay 5 s of 5 s Rivet counter 3 of 3 |
| 2. Activate setting | | Conveying performance 0 % of 70 % Shut off delay 5 s of 5 s Rivet counter 3 of 3 |
| 3. Set parameter | | Conveying performance 0 % of 62 % Shut off delay 5 s of 5 s Rivet counter 3 of 3 |
| 4. Import parameter | | Conveying performance 0 % of 62 % Shut off delay 5 s of 5 s Rivet counter 3 of 3 |

For multi-level settings step 3 will be repeated accordingly.

The F1 and F6 function keys are ignored during step 3 "set parameter".



Operation


8.9 Selecting data

Some menus require the selection of data. An additional window appears for data selection and the navigation bar is changed accordingly.

The **title bar** of the window shows which data are selected.

Details to the currently selected data record are shown on the **status bar**.

| Input | | Function |
|---------------|---|---|
| Knob |  | Select data record in field that is highlighted in white. |
| First | | Select the first data record in the table. |
| Last | | Select the last data record in the table. |
| OK |  | Import selected data record. |
| Cancel | | Cancel without selection. |



Example data selection

Title bar

Status bar

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Process monitoring
- ▶ Profil
- ▶ Loading

Example:

In the example shown the "setting profile" menu is used to load a profile from the profile database. The profile to be loaded can be selected in the window shown. The number of the selected profile and its alteration index is displayed on the status bar.

This example shows features belonging to the process control function and is not included in the GAV-8000 **eco**.

Operation





8. 10 Entering text


Some menus require the input of text. An additional window appears for entering text and the navigation bar is changed accordingly.

Which text input is expected is shown on the **title bar** of the window.

The entered text and the number of characters still available are shown in the **input line** of the window. The flashing cursor “_” shows the input position.

The characters available for text input are displayed in the **selection field** of the window.

| Input | Function | |
|---|--|---|
|  | Select characters in options display. | |
| ok →  | Import selected character into input line. | |
| Del | Delete character before cursor. Holding for 2 seconds will delete the whole line of text. | |
| Ins | Activate insert mode: |  Select insert position. |
| | | ok →  Enter text. |
| end | End insert mode, set cursor at the end of the line of text. | |
| Clr | Space character. | |
| OK | Import input. | |
| Cancel | Cancel input without change. | |



Example text input

Title bar

Input line

Navigation:
 AUTO
 ► MAN
 ► Menu
 ► Maintenance

Selection field

Example:

The example shows the text input for one of the freely definable maintenance texts.

Settings GAV

9.0 Overview

- 9.1 Oscillating conveyor
- 9.2 Pressure sensors
- 9.3 Large pressure transmitter
- 9.4 Small pressure transmitter
- 9.5 Singulator
- 9.6 Blast air
- 9.7 Mandrel extractor
- 9.8 Cycle
- 9.9 Additional functions
- 9.10 Drive PLC
- 9.11 Permanent test
- 9.12 I/O-test
- 9.13 PLC interface test

Settings GAV

9.1 Oscillating conveyor

Menu settings oscillating conveyor

Proximity switch NS1

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Oscillating conveyor

Setting the oscillating conveyor (6-8000)

(How to set the proximity switch NS1 4-8045 is described in chapter 9.5 "Settings GAV" – "singulator")

| | |
|-----------------------|---|
| Conveying performance | controls the conveying performance of the oscillating conveyor. |
| Shut-off Delay | The slowing down time starts when the proximity switch NS1 reaches singulator chute "ON" (singulator chute filled with blind rivets). This function provides the storage of blind rivets on the singulator chute. |
| Rivet counter | The rivet counter is set at the piece number of blind rivets that are still present on the singulator chute after passing proximity switch NS1 "OFF". This function prevents that the singulator is running empty. Malfunction oscillating conveyor when reaching set value. |
| Running period | Not adjustable. Short running period for standard operation, long running period if oscillating conveyor bowl is empty. This function prevents the wedging together of blind rivets in a blind rivet pile-up. Malfunction oscillating conveyor when reaching set value. |

| | |
|------------------------|---|
| Strd | restores standard settings. |
| OFF / ON | switches the oscillating conveyor unit on or off. |

Settings GAV

9.2 Pressure sensors

Menu settings
Pressure sensor DS1/DS2

Navigation:
 AUTO
 ► MAN
 ► Menu
 ► Settings GAV
 ► Pressure sensors

DS1 Network pressure (1-8040.1)

monitors the compressed air supply of the GAV.
(For settings see chapter 5 “Commissioning and handling”).

| | |
|-----------------------|---|
| Network max. | Malfunction network when exceeding the set value. |
| Network pressure min. | Malfunction network when dropping below the set value. |

DS2 Rivetting gun air (1-8040.2)

monitors the compressed air supply of the GAV gun.

| | |
|-------------------|--|
| Manual trigger | Cycle start, if below set value. |
| Ventilation cycle | Continue cycle from lift position if pressure dropped below set value. |
| Backfeed delay | Time-delayed backfeed of gun air locked in initial position after pressure dropped below DS1 network pressure minimum. |
| Backfeed period | Period of gun air backfeed. |

The setting range of single parameters may vary when dependent on other variable parameters.

| | |
|--------------|---|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 “manual mode” “cycle” function). |
| Lift | Moves gun to lift position (See chapter 8.7 “manual mode” “lift position” function). |
| Cal | “Calibration pressure sensors DS1/DS2” menu |
| DS3 | “Calibration pressure sensor DS3” menu |


Settings GAV

9.2 Pressure sensors


Calibration and basic setting pressure sensor DS1/DS2 (1-8040.1/2)

The calibrating data for "signal type" and "measuring range" in the "calibration pressure sensor DS1/DS2" menu are set during installation and must not be changed.

Basic setting for pressure sensors is not required.



DS1
6.2 bar



DS2
6.2 bar

Calibration DS1

Signal type 0-10 V

Measuring range 0 to 10 bar

Calibration DS2

Signal type 0-10 V


Measuring range 0 to 10 bar

Menu
Calibration
Pressure sensor
DS1/DS2

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Pressure sensors
- ▶ Cal

Back **Strd** **Cycle** **Lift**
 GESIPA-Code



| Calibration DS1 (1-8040.1) | |
|----------------------------|------------------------------------|
| Signal type | Signal type of pressure sensor |
| Measuring range | Measuring range of pressure sensor |
| Calibration DS2 (1-8040.2) | |
| Signal type | Signal type of pressure sensor |
| Measuring range | Measuring range of pressure sensor |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |

Settings GAV

9.2 Pressure sensors

Not included in GAV-8000 eco



Calibration and basic setting pressure sensor DS3 (3-8192)

The pressure sensor DS3 is adapted at the connection for the hydraulic line of the large pressure transmitter.

The calibrating data for "signal type", and "measuring range" in the "calibration pressure sensor DS3" menu are set during installation and must not be changed.

Basic setting for the pressure sensor is not required.

After an exchange of pressure sensor it is necessary to bleed the hydraulic system (See chapter 24 "filling hydraulic systems").



Menu calibration
Pressure sensor DS3

Navigation:
AUTO
▶ MAN
▶ Menu
▶ Settings GAV
▶ Pressure sensors
▶ DS3

GESIPA-Code

Calibration DS1 (3-8192)


| | |
|---|------------------------------------|
| Signal type (Standard 0-10V) | Signal type of pressure sensor |
| Measuring range (Standard 0-400 bar) | Measuring range of pressure sensor |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |

Settings GAV

9.3 Large pressure transmitter

Setting large pressure transmitter WS1



WS1
0.0
mm

| WS1 Switching points cycle | |
|----------------------------|-------|
| Rivetting gun air off | 78 mm |
| Blast air on | 78 mm |
| Mandrel extractor on | 78 mm |
| Lift position | 90 mm |
| | |
| Blast air off | 88 mm |
| Lock open | 88 mm |
| Singulator open | 88 mm |
| Initial setting | 5 mm |

Menu settings
Large pressure transmitter
Distance sensor WS1

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Large pressure transmitter

⏮
GESIPA-Code

Back
Strd
Cycle
Lift
Cal
WS2

WS1 shift points cycle (3-8197)

The shift points control the sequences within the processing cycle. The setting range for this is the entire measuring range starting at the sensor's zero point.

| | | |
|------------------|----------------------|--|
| Pulling sequence | Gun air off | Turns off the gun air at the end of the power-driven lift, the chuck jaws open and the remaining mandrel is released. |
| | Blast air on | Turns on the blast air after the end of the power-driven lift, the remaining mandrel is ejected and the blind rivet is conveyed. |
| | Mandrel extractor on | Turns on the mandrel extractor, the remaining mandrel is conveyed to the remaining mandrel basin. |
| | Lift position | Lift position reached. |
| Return | Blast air off | Turns off blast air. |
| | Lock open | Opens the lock to enable loading of blind rivet. |
| | Singulator open | Opens the singulator for a new blind rivet. |
| | Initial setting | Initial position reached, lock activated and singulator closed. |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |
| Cal | "Calibration WS1 large pressure transmitter" menu |
| WS2 | "Setting large pressure transmitter WS2" menu |

Settings GAV

9.3 Large pressure transmitter


Calibration and basic setting distance sensor DS3 (3-8197)

To exchange the distance sensor, the pressure transmitter has to be disassembled first (See chapter 22 "disassembly and assembly pressure transmitter").

The distance between the lower edge of the distance sensor's head and the upper edge of the assembling trestle is set to 80 mm which serves as assembly measurement.

The calibrating data for "signal type", and "measuring range" in the "calibration WS1 large pressure transmitter" menu is set during installation and must not be changed.

The initial position for the pressure transmitter is adjusted by the "zero point" parameter. "Zero point" in initial position is set in such a way that the "current position" is 0.0 mm. From this should follow a "zero point" parameter between 2 and 4 mm. Minor correction may be carried out by shifting the distance sensor inside the pressure transmitter.



Calibration WS1 large pressure transmitter

Calibration WS1

Signal type0-10 V

Measuring range 0 to100 mm

Zero point at3.0 mm

Current position0.0 mm

Back
Strd
Cycle
Lift

Menu calibration
Distance sensor WS1
Large pressure transmitter

Navigation:
 AUTO
 ► MAN
 ► Menu
 ► Settings GAV
 ► Large pressure transmitter
 ► Cal

GESIPA-Code

Calibration WS1 (3-8197)

| | |
|-----------------|------------------------------------|
| Signal type | Signal type of distance sensor |
| Measuring range | Measuring range of distance sensor |
| Zero point | Zero point of distance sensor |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |

Settings GAV

9.3 Large pressure transmitter

Menu settings
Large pressure transmitter
Distance sensor WS2

Navigation:
AUTO
▶ MAN
▶ Menu
▶ Settings GAV
▶ Large pressure transmitter
▶ WS2

WS2 oil level (3-8198)

monitors the oil level in the tank of the large pressure transmitter.

| | |
|----------------------------|--|
| Warning oil level max. | Malfunction oil level when reaching set value. |
| Warning oil level min. | Malfunction oil level when reaching set value. |
| Malfunction oil level min. | Malfunction oil level when reaching set value. |
| Malfunction gun | Malfunction gun when reaching set value. A gun with blocked return motion results in a fast drop of oil level; the malfunction is evaluated in initial position. |
| Delay malfunction | The evaluation for "malfunction gun" is delayed. |

The setting range of single parameters may vary when dependent on other variable parameters.

| | |
|--------------|---|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |
| Cal | "Calibration WS2 large pressure transmitter" menu |

Settings GAV


9.3 Large pressure transmitter

Calibration and basic setting distance sensor WS2 (3-8198)

During assembly of the distance sensor the sensor body is set flush to the bottom side of the lid.


The calibrating data for "signal type", and "measuring range" in the "calibration WS2 large pressure transmitter" menu is set during installation and must not be changed.

The initial position for the float is adjusted by the "zero point" parameter. To do this, the oil level must be filled up to the mark on the inspection glass. The "Zero point" parameter is set in such a way that the "current position" is 0.0 mm. The "zero point" is then supposed to be around 14 mm. Minor correction may be carried out by shifting the distance sensor inside the pressure transmitter.



Menu calibration
Distance sensor WS2
Large pressure transmitter

Calibration WS2 large pressure transmitter



Calibration WS2

Signal type 0-10 V

Measuring range 0 to 24 mm

Zero point at 14 mm

Current position
0.0 mm

Back
Strd
Cycle
Lift

- Navigation:
- AUTO
 - ▶ MAN
 - ▶ Menu
 - ▶ Settings GAV
 - ▶ Large pressure transmitter
 - ▶ WS2
 - ▶ Cal

GESIPA-Code


Calibration WS2 (3-8198)

| | |
|-----------------|------------------------------------|
| Signal type | Signal type of distance sensor |
| Measuring range | Measuring range of distance sensor |
| Zero point | Zero point of distance sensor |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |

Settings GAV

9.4 Small pressure transmitter



WS3
74.0
mm

| WS3 Oil level | |
|----------------------------|---------|
| Warning oil level min. | 50 mm |
| Malfunction oil level min. | 45 mm |
| Delay malfunction | 0.2 s |
| Locking lift | 12.0 mm |
| Malfunction mouth piece | 14.0 mm |

Back
Strd
Cycle
Open
Cal

Menu settings
Small pressure transmitter
Distance sensor WS3

Navigation:

AUTO

- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Small pressure transmitter

WS3 oil level (3-8199)

monitors the oil level inside the small pressure transmitter.

| | |
|----------------------------|---|
| Warning oil level min. | Malfunction oil level when reaching set value. |
| Malfunction oil level min. | Malfunction oil level when reaching set value. |
| Delay malfunction | The evaluation for "malfunction oil level" is delayed. |
| Locking lift | Not adjustable. indicates the locking lift. This parameter is used for setting the set value for "malfunction mouth piece". |
| Malfunction mouth piece | Malfunction mouth piece when reaching set value. Setting: <ul style="list-style-type: none"> - Detach expandable mouth piece on gun with a ¼ rotation. - Open and close lock by pressing the OPEN button. - Import value of "locking lift" parameter. - Tighten expandable mouth piece on gun. |

The setting range of single parameters may vary when dependent on other variable parameters.

| | |
|--------------|---|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Open | Opens the lock of the gun in initial position. (See chapter 8.7 "manual mode" "open lock" function). |
| Cal | "Calibration WS3 small pressure transmitter" menu |

Settings GAV

9.4 Small pressure transmitter


Calibration and basic setting distance sensor WS3 (3-8199)

To exchange the distance sensor, the pressure transmitter has to be disassembled first (See chapter 22 “disassembly and assembly pressure transmitter”).


The distance between the lower edge of the distance sensor’s sensor head and the upper edge of the connecting flange of the pressure transmitter is set to 30 mm to serve as assembly measurement.

The calibrating data for “signal type“, and “measuring range” in the “calibration WS3 small pressure transmitter” menu is set during installation and must not be changed.

The initial position for the pressure transmitter is adjusted by the “zero point” parameter. “Zero point” in initial position is set in such a way that the “current position” is 0.0 mm. From this should follow a “zero point” parameter between 2 and 4 mm. Minor correction may be carried out by shifting the distance sensor inside the pressure transmitter.



Calibration WS3 small pressure transmitter



Calibration WS3

Signal type 0-10 V

Measuring range 0 to 88 mm

Zero point at 3.0 mm

Current position 74.0 mm

Zero

Back
Strd
Cycle
Open

Menu calibration
Distance sensor WS3
Small pressure transmitter

Navigation:
 AUTO
 ▶ MAN
 ▶ Menu
 ▶ Settings GAV
 ▶ Small pressure transmitter
 ▶ Cal

GESIPA-Code

CalibrationWS3 (3-8199)

| | |
|-----------------|------------------------------------|
| Signal type | Signal type of distance sensor |
| Measuring range | Measuring range of distance sensor |
| Zero point | Zero point of distance sensor |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 “manual mode” “cycle” function). |
| Open | Opens the lock of the gun in initial position. (See chapter 8.7 “manual mode” “open lock” function). |

Settings GAV

9.5 Singulator

Basic setting proximity switch NS1 4-8045

(oscillating conveyor control)

- Remove plug and detach locknut.
- Set sensor flush with inner edge of chute sheet.
- Tighten locknut and connect plug.

Basic setting proximity switch NS2 4-8044



(Monitoring the singulator spoon)

- Singulator closed in initial position.
- Remove plug and detach locknuts.
- Turn sensor manually right up to stop.
- Detach sensor with a ¼ rotation.
- Tighten locknut and connect plug.

Basic setting control valve

(Stop buffer for singulator)

Open setting screw of the regulating valve from locked position approx. 2 turns.



Menu settings
Singulator

Navigation:
AUTO
► MAN
► Menu
► Settings GAV
► Singulator

NS1 oscillating conveyor control (4-8045)

see chapter 9.1 "settings of oscillating conveyor".

NS2 singulator (4-8044)

monitors the status of the singulator.

Malfunction **singulator** when relevant triggered stop position is not reached.

| | |
|-------------------|--|
| Delay malfunction | The evaluation for "malfunction singulator" is delayed. |
| Safe monitoring | Closing the singulator is precondition for starting the cycle. |

| | |
|--------------|--|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Open | Opens the singulator in initial position of GAV (See chapter 8.7 "manual mode" "open singulator" function). |

Settings GAV



9.6 Blast air

Basic setting blast air

Open setting screw of the blast air regulating valve from locked position approx. 2 turns.

Other settings:

- Less blast air due to damages by conveyance on the blind rivet.
- More blast air at deficient blind rivet conveyance or faulty mandrel ejection.



Menu settings
Blast air

Navigation:
AUTO
▶ MAN
▶ Menu
▶ Settings GAV
▶ Blast air

Blast air

Monitors the running time of the blast air.

| | |
|----------------|--|
| Running period | turns off the blast air when set value is reached. |
|----------------|--|

| | |
|--------------|---|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |
| ON | Activates the blast air in lifting position of the GAV (See chapter 8.7 "manual mode" "blast air" function). |


Settings GAV

9.6 Blast air

Initial setting central lubrication (1-8130)

- Setting screw upper stop position:
Oil discharge per piston stroke near 0
- Setting screw lower stop position:
maximum oil discharge per piston lift. At
this setting, the filling is empty after
approx. 22.000 cycles.

Basic setting: Open setting screw starting from
stop position with approx. 1 rotation.




Settings GAV

9.7 Mandrel extractor

Basic setting Operating pressure mandrel extractor

- Activate mandrel extractor in the menu "MAN" using the function "mandrel extractor".
- At active mandrel extractor, set the pressure reducing valve mandrel extractor to 4 bar (flow pressure), check of manometer mandrel extractor.




Initial setting RS1 mandrel extractor (1-8041)

- Turn setting screw of the ring sensor RS1 clockwise (more sensible), until the LED display lights up.
- Turn setting screw of the ring sensor RS1 anticlockwise (less sensible), until the LED display goes out.


The ring sensor's sensitivity RS1 must be varied according to material and dimension of the remaining mandrel.

The switch status of the ring sensor RS1 can also be verified in the menu "setting of mandrel extractor".




Initial setting NS3 Mandrel box (4-8043)

- Release locknuts of sensor NS3.
- Set sensor NS3 as far as possible towards the mandrel box.
- Tighten the locknuts of sensor NS3.
- Detach the fastening screws of the support.
- Move mandrel box right up to just before sensor NS3.
- Set sensor NS3 in the height a little bit over the edge of the mandrel recipient.
- Tighten fastening screws of support.



Settings GAV

9.7 Mandrel extractor



Menu settings
mandrel extractor

Navigation:
AUTO
▶ MAN
▶ Menü
▶ Settings GAV
▶ Mandrel extractor

RS1 mandrel extractor (1-8041)

registers torn off remaining mandrels.

Malfunction **mandrel extractor** when set value for "remaining mandrel" is exceeded and set value for "running time" is reached.

| | |
|-------------------|---|
| Remaining mandrel | If the set value is exceeded, the processing cycle will be stopped in lift position until a remaining mandrel is detected. Settings greater than 0 enable faster working because there is no interruption for each processing cycle until the arrival of a remaining mandrel in the mandrel box. |
| Running period | turns off the mandrel extractor when set value is reached. |

NS3 Mandrel box (4-8043)

monitors the filling level of the mandrel box.

Malfunction **mandrel box full** when mandrel box is full.

| | |
|--------------|--|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |
| ON | Activates the mandrel extractor (See chapter 8.7 "manual mode" "mandrel extractor" function). |

Settings GAV

9.8 Cycle

Setting cycle

Initial position ON

| | | | |
|----------------|-------|----|-------|
| Unlocking time | 2.0 s | of | 2.0 s |
|----------------|-------|----|-------|

Times in cycle

| | | | |
|-------------------------------|-------|----|-------|
| Monitoring time lift position | 0.6 s | of | 2.0 s |
| Waiting time lift position | 0 ms | of | 0 ms |
| Monitoring time reverse | 0.7 s | of | 2.0 s |

Back
Strd
Cycle
Lift

Menu settings cycle

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Cycle

Initial position ON

"ON" function button from operating status "OFF".

| | |
|----------------|--|
| Unlocking time | Initial position will be activated when the set value is reached |
|----------------|--|

Times in cycle

monitors and controls times in cycle.


| | |
|-------------------------------|--|
| Monitoring time lift position | Malfunction cycle when reaching set value. |
| Waiting time lift position | Cycle is stopped in lift position until set value is reached. This function is activated under special conditions (e.g. excessive feed bundle). |
| Monitoring time reverse | Malfunction cycle when reaching set value. |

| | |
|-------|---|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Lift | Moves gun to lift position (See chapter 8.7 "manual mode" "lift position" function). |

Settings GAV


9.9 Additional functions

Setting additional functions




Lock manual trigger

No




Foot actuated trigger

No



Pressure monitoring device

No



Rivet query conveying hose

No

Back
Strd
Cycle

Menu settings Additional functions

Navigation:

AUTO

- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Additional functions

Setting additional functions

| | |
|----------------------------|---|
| Lock manual trigger | Manual trigger is locked whilst function is active. Manual trigger may be deactivated when additional start-up options were activated (foot-actuated triggering or drive PLC). |
| Foot-actuated triggering | Condition: Foot-actuated triggering connected (extra). The cycle is started by foot-actuated triggering with the function active (start-up option "foot"). |
| Pressure monitoring device | Condition: GAV gun with pressure monitoring device connected (extra). With the function activated, the blind riveting gun is pressed onto the jointing stock by a defined force to enable the start of a cycle. |
| Rivet query conveying hose | Condition: Additional sensor RS2 mounted on conveying hose (extra) With the function active, the conveying process of the blind rivet is being monitored, triggering the malfunction rivet query sensor conveyor triggered. |

| | |
|--------------|---|
| Strd | restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |

GESIPA®

GESIPA Blindniettechnik GmbH, Nordendstr.13-39, D-64546 Mörfelden-Walldorf, Telefon 06105/962-0, Telefax 06105/962287

Settings GAV

9.10 Drive PLC

Menu settings Drive PLC

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Drive PLC

Setting the drive of PLC

| | |
|-------------------------|---|
| Drive PLC | Condition: PLC interface connected (extra). With the f function active, the cycle is started via the PLC interface by the PLC (start-up option "PLC"). The drive is described in detail in chapter 28 "PLC interface". |
| Lock manual trigger | Manual trigger is locked whilst function is active. Manual trigger may be deactivated when additional start-up options were activated (foot-actuated triggering or drive PLC). |
| Rivet query mouth piece | Condition: PLC interface connected (extra), additional sensor (e.g. light barrier) in mouth piece area of GAV gun mounted and connected to PLC interface. With the function active, the loading process of the blind rivet on the mouth piece of the GAV gun is monitored and the malfunction rivet query mouth piece is triggered. For installation of sensor see detailed description in chapter "PLC interface". |

| | |
|--------------|---|
| Strd | Restores standard settings. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |

Settings GAV

9.11 Permanent test

Permanent test can be used by the GAV to trigger processing cycles independently and at a set time or for a set piece number.

It is possible to change to different menus during permanent test in order to observe statuses, sequences, parameter or settings. It is possible to change parameters and settings during a permanent test.

You may cancel a permanent test at any time by pressing the “ON” or “OFF” button.

Menu Permanent test

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ Permanent test

Permanent test

| | |
|-------------------------|--|
| Start delay | Each cycle start is delayed by the set time. |
| Testing without rivet | With the function active, the oscillating conveyor is turned “OFF” and the malfunction “oscillating conveyor” pressed. |
| Test until piece number | The permanent test is stopped when reaching the set value. |
| Test until time | The permanent test is stopped when reaching the set value. |

| | |
|-----------------|--|
| Strd | Restores standard settings. |
| OFF / ON | Turns the permanent test OFF/ON. |
| C | Resets the “piece number” and “time” parameter to 0. |

Settings GAV

9.12 I/O test

The "I/O-test" menu shows all input and output statuses of the GAV. Output statuses may be changed independently from the current tool status.

The values of the analogue sensors for distance and pressure are shown as absolute values, with the settings for "zero point" not taken into account.



Attention!

Inexpert application of the functions may result in damage to the GAV.

| I/O test | | | |
|--|-----------------------|--|-----------------|
| V1ab Gun empty | <input type="radio"/> | WS1 Lift large pr. tr. = 3.0 mm | |
| V2a Gun air | <input type="radio"/> | WS2 Oil level large pr. tr. = 14.0 mm | |
| V2b Mand. extr. | <input type="radio"/> | WS3 Lift small pr. tr. = 77.0 mm | |
| V3a Small pr. tr. | <input type="radio"/> | DS1 Network pressure = 6.2 bar | |
| V3b Large pr. tr. | <input type="radio"/> | DS2 gun air = 6.2 bar | |
| V4 Singulator | <input type="radio"/> | DS3 Oil pressure large pr. tr. = 0.1 bar | |
| V5 Blast air | <input type="radio"/> | Reserve A1 (0.1 V) | |
| Osz. conveyor | <input type="radio"/> | Reserve A2 (0.0 V) | |
| 0 % | | NS1 Chute | RS2 Rivet query |
| | | NS2 Singulator | Button ON |
| | | NS3 Mandr. box | Button OFF |
| | | RS1 Mandr. query | Reserve D1 |
| <div> <div>Back</div> <div>Toggle</div> <div>Switch</div> </div> | | | |

Menu I/O test

Navigation:

- AUTO
- MAN
- Menu
- Settings GAV
- I/O test

Toggle

The selected output changes the switching status whilst the control button is being pressed, the original status will be re-established after releasing.

Switch

The selected output changes the switching status whilst the control button is being pressed and this status will be retained after releasing.

Settings GAV

9.13 PLC interface test

The input and output assignment of the PLC interface is displayed, and the connection of the GAV to the interface is tested in the PLC interface test menu. In addition it is possible to test individual communications with a connected PLC or control and evaluation unit or input and messaging devices for each input and output.

| PLC interface test | | | | | | | | | | | | | | | |
|---|----|--|--|--|--|--|--|--|--|--|--|--|--|----|------------------------------------|
| Start cycle | 1 | | | | | | | | | | | | | 1 | Cycle ready |
| Reverse cycle | 2 | | | | | | | | | | | | | 2 | Cycle lift position |
| Rivet query mouth p. | 3 | | | | | | | | | | | | | 3 | Malfunction GAV R1 |
| Cycle close start | 4 | | | | | | | | | | | | | 4 | Malfunction cycle |
| Counter start | 5 | | | | | | | | | | | | | 5 | Counter/Part ready R2 |
| | 6 | | | | | | | | | | | | | 6 | MAN |
| Profile 1 | 7 | | | | | | | | | | | | | 7 | |
| Next profile | 8 | | | | | | | | | | | | | 8 | Process/Part OK R3 |
| Select profile | 9 | | | | | | | | | | | | | 9 | Process/Part NOK R4 |
| Profile list/Profile Bit 0 | 10 | | | | | | | | | | | | | 10 | Error code Bit 0 |
| Profile list/Profile Bit 1 | 11 | | | | | | | | | | | | | 11 | Error code Bit 1 |
| Profile list/Profile Bit 2 | 12 | | | | | | | | | | | | | 12 | Error code Bit 2 |
| Profile list/Profile Bit 3 | 13 | | | | | | | | | | | | | 13 | Error code Bit 3 |
| Evaluation Part | 14 | | | | | | | | | | | | | 14 | |
| | 15 | | | | | | | | | | | | | 15 | Maintenance R5 |
| | 16 | | | | | | | | | | | | | 16 | R6 |
| <div>Back</div> <div>Off</div> <div>Toggle</div> <div>Switch</div> <div>C</div> | | | | | | | | | | | | | | | |

PLC interface test

Navigation:
 AUTO
 ► MAN
 ► Menu
 ► Settings GAV
 ► PLC interface test

| | |
|---------------|--|
| Off | No test function active |
| Toggle | Output test active, output 1..16 can be selected or turned on/off with the control button. |
| Switch | Output test active, output 1..16 can be selected or turned on/off with the control button. |
| C | When output test is active, outputs 1..16 will be reset. |

See also chapter 28 "PLC interface".

Settings GAV

9.14-UA Proximity switch with pressure monitoring device

Proximity switch 2-6001UA2 (pressure monitoring device)

Adjusting:

Proximity switch-2-6001UA2 at operated pressure monitoring device to threaded pin easily close and approx. 1/4 then solve turn. Proximity switch with jam nut detent. The adjusting of the thread pin only in the need change (locked with Loctite 222).

Control:

- The push on distance shall be approx. 1 mm.


Possible disturbances:

- No release despite push on possible.

Cause/reason: Push on distance to big.

- Release without push on possible.

Remedy: Push on distance to small.



Maintenance

10.0 Overview

10.1 Service instructions

10.2 Maintenance messages

Maintenance

10.1 Maintenance messages




Attention!

**Follow safety instructions!
Wear protective goggles!**

Daily:


- **Lubricate / replace chuck jaws.**

- Turn off main switch "POWER".
- Unscrew expanding mouth piece 2-80.
- Pull off the snap collet 2-8022 and unscrew the chuck cage 2-8005 or 2-8205.
- Remove chuck jaw set with washer and stop ring and opening springs.
- Replace chuck jaws, as required.
- Apply a small amount of grease to the gliding surface of the chuck cage (roller bearing grease).
- Place chuck cage over chuck jaw set, insert stop ring and washer.
- Assemble in reverse order.
- Turn on main switch "POWER", press "ON" key.




- **Check / replace leaf spring.**

- Press "ON" button.
- Select „MAN“ mode.
- Carry out "lift position" function.
- Disassemble mandrel guide piece 2-8301.
- Check leaf spring visible in mandrel ejecting slot for correct fit and pre-tension.
- Replace leaf spring, as required.
(See chapter 21 "repair instructions for blind rivet gun").



- **Top up central lubrication.**

- Remove locking screw.
- Fill oil level up to maximal 5 mm below upper edge of inspection glass.
- Screw locking screw.



Maintenance


10.1 Maintenance messages

Weekly:

- **Clean chute sheets.**
Clean gliding surfaces of chute sheets (do not use oil).

As required:

- **Oil rivet feed hose**
(Required after exchange of conveying hose or prolonged dry running)
 - Press "OFF" button.
 - Remove stopper and fill in approx. 0.5 ccr of oil.
 - Put stopper back on.
 - Press "ON" button.
 - To distribute the oil inside the rivet feed hose, carry out several working cycles.



Maintenance

10.2 Maintenance messages

You can set maintenance intervals in the “maintenance” menu. All required maintenance work is then reported in the AUTO main menu.

8 different maintenance messages are available:

- 5 have fixed assignation (See chapter 10.1 “maintenance” – “notes on maintenance”)
- 3 may be assigned as you wish.

Several maintenance messages are shown at the same time.

| Maintenance | | | |
|-----------------------------|---------|---------|--------|
| Message maintenance | Counter | Message | Stop |
| Grease chuck jaws | 1234 | 5000 | 6000 |
| Replace chuck jaws | 1234 | 100000 | 101000 |
| Check / replace leaf spring | 1234 | 30000 | 31000 |
| Top up central lubrication | 1234 | 15000 | 16000 |
| Clean chute sheets | 1234 | 15000 | 16000 |
| ... | 0 | 0 | 0 |
| ... | 0 | 0 | 0 |
| ... | 0 | 0 | 0 |
| Counter mechanism | | | 1234 |
| Back | Strd | | |

Menu maintenance

Navigation:
 AUTO
 ► MAN
 ► Menu
 ► Maintenance

| Column | Description |
|-------------|---|
| Counter | Not settable, but value can be reset to 0. Piece number of blind rivets processed since last maintenance. |
| Message | Setting range: 0 to 500,000 pieces Message maintenance appears when “counter“ has reached or exceeded set value; GAV does <u>not</u> stop. |
| Stop | Setting range: 0 to 500,000 pieces Message maintenance appears when “counter“ has reached or exceeded set value; GAV stops. |
| Strd | Restores standard settings. |

Maintenance

10.2 Maintenance messages

| Maintenance | | | |
|-----------------------------|---------|---------|--------|
| Message maintenance | | | |
| | Counter | Message | Stop |
| Grease chuck jaws | 5000 | 5000 | 6000 |
| Replace chuck jaws | 5000 | 100000 | 101000 |
| Check / replace leaf spring | | | |
| Top up central lubrication | | | |
| Clean chute sheets | | | |
| ... | | | |
| ... | | | |
| ... | | | |
| Back | Strd | | |

AUTO / Ready (Manual)

Modul 01
Cycle ☐
Lift position ☐
MAINTENANCE
Grease chuck jaws
Service completed?
Singulator open ☐
Oscillating conveyor

1/6
(1/6)

No Yes

Example:

In the example shown the maintenance message "grease chuck jaws" is active, "counter" has reached the set value "message". The relevant message is issued in the "AUTO" main menu; the GAV does not stop. Work can continue until the maintenance has been carried out or confirmed or until the "counter" reaches the set value "stop".

Process monitoring

11.0 Overview

Not included in GAV-8000 **eco**

- 11.1 Functional characteristics**
- 11.2 Adjustment**
- 11.3 Create profile**
- 11.4 Load profile**
- 11.5 Store profile**
- 11.6 Create profile list**
- 11.7 Load profile list**
- 11.8 Profile lists PLC**

Process monitoring


11.1 Functional characteristics

Not included in GAV-8000 eco

The setting process of the GAV is monitored by recording tensile distance and force during blind rivet processing, followed by an evaluation of the tear off point (tear off distance and tear off force). The position of the tear off point is mainly dependent on the blind rivet used, the jointing stock thickness and the diameter of the hole in the jointing stock.

To evaluate the tear off point, limits are determined for tear off distance and tear off force using window technology. These limits are visualised in an evaluation window.

Evaluations are shown by the graphic display immediately after each setting process and also by the interface of the PLC interface.



Profiles


The evaluation parameters determined for the individual blind rivet points are stored in profiles. It is possible to create 9999 different profiles. Profiles may be changed by creating a copy of the last profile with a new index; up to 9999 changes per profile are possible.

Collective evaluations relating to component parts require the use of profile lists.

Profile lists

Profile lists are necessary for applications with several blind rivet points that are to be evaluated differently. A profile list is able to evaluate each blind rivet point by applying the appropriate profile. Profiles in profile lists are automatically called one after the other or directly triggered by the PLC interface. It is possible to create a maximum of 9999 profile lists with 9999 profiles for each list.

| Example: Profile list "Test part" | | |
|--------------------------------------|--------------------------|---------|
| No. | Jointing stock thickness | Profile |
| 1 | 3 mm | A |
| 2 | 2 mm | B |
| 3 | 4 mm | C |
| 4 | 2 mm | B |
| 5 | 3 mm | A |




Process data

The position of the tear off point and the evaluation of setting processes are stored with time stamps in the process data file. The process data file records the last 1,000,000 processes. If more data exists, the older data will be overwritten. The evaluation of process data is described in the chapter 12 "process data".

Process monitoring

11.2 Setting

Not included in GAV-8000 eco



The following details for setting process monitoring are shown in the AUTO main menu:

Designation:

The denomination of the current profile list is displayed. If no profile list is active, the denomination of the current profile will be displayed.



Attention!

Collective evaluations relating to component parts require the use of profile lists.

Process graph:

Process graph, tear off point and evaluation window are displayed after each setting process.

Process evaluation

After each setting process the evaluation is issued as text.

Monitoring device ready after GAV was switched on or the process graph deleted.

| | | |
|---|---|---|
| H | A | B |
| G | 0 | C |
| F | E | D |

Shows position of tear off point:

Left: Process IO tear off point in sector 0
Right: Process NIO tear off point in sector F
(Tearing path too short, tearing force too low)

| | | |
|---|---|---|
| H | A | B |
| G | 0 | C |
| F | E | D |

No measuring values e.g. after running an empty cycle.

Current profile:

The position of the current profile is shown in the profile list. In the example this is the first profile of 5 from profile list "TEST part 02".


Next profile

shows the position of the profile in the profile list which is to be used to evaluate the next setting process. Manual selection or triggering by PLC allows the selection of any profile from a profile list. In the example this is the second profile of 5 from profile list "TEST part 02".

Process monitoring

11.2 Setting

Not included in GAV-8000 eco



In the "setting process monitoring" menu

- the current process graph is displayed in detail, including the scaling of tensile distance and force. The tear off point is highlighted in blue. Tear off distance and tear off force are issued above the process graph against a green or red background according to evaluation. In addition to this, when individual profiles are used, the tear off point for the last 20 processes is displayed in the form of grey dots.
- The evaluation parameters together with the corresponding evaluation window of the last blind rivet processed are displayed. It is possible to change evaluation parameters and the scaling for the tensile distance. However, any changes made to evaluation parameters are only valid temporarily and should be stored in a profile. Details to the current profile are shown in grey in the lower area of the process graph.

The "setting process monitoring" menu serves as a starting point for all settings for process monitoring and the creation and administration of profiles and profile lists.

| | |
|-----------------------------|---|
| \bar{x} | Mediates the evaluation window above the tear off points and, at the same time, adapts the evaluation parameters. |
| Cycle | Running processing cycle (See chapter 8.7 "manual mode" "cycle" function). |
| Erase | deletes the current process graph and all tear off points. |
| Cal | "Calibration process monitoring" menu |
| Profile | "Setting profile" menu |


Process monitoring

11.3 Creating a profile

Not included in GAV-8000 eco

Starting position AUTO main menu

After the start-up of the GAV the profile used last will be loaded automatically. If no profile was created so far, a profile called "start profile" will be generated.




Step 1: "Setting profile" menu

From AUTO main menu by pressing

- ▶ MAN
- ▶ Menu
- ▶ Process monitoring
- ▶ Profile

go to the "setting profile" menu. The evaluation parameters of the current profile are displayed.



Use **New** to create a new profile.

Process monitoring

11.3 Creating a profile

Not included in GAV-8000 eco

Step 2: Enter denomination and item number

First enter the denomination of the profile and then the item number for the blind rivet.

The denomination of the profile should give an unambiguous identification of the blind rivet point; the example gives the denomination for the blind rivet and the thickness of the joining stock (FG2.5).

Once applied, denominations cannot be transferred to new profiles.

Setting profile

Profile

Enter profile designation

PG6,4x10 FP K11 FG2,5_ 4

A B C D E F G H I J K L M N O P Q R S T

Setting profile

Profile

Enter rivet art.no.

6706339_ 3

A B C D E F G H I J K L M N O P Q R S T

U V W X Y Z a b c d e f g h i j k l m n

o p q r s t u v w x y z 0 1 2 3 4 5 6 7

8 9 _ [] () * + , . - / : ; < = > ?

Step rate (scaling path) 0.04 mm

Abort Del Ins End Clr OK

Step 3: Recording process graphs

The GAV is only ready for the recording of process graphs.

The evaluation parameters are imported from the profile used last.

Setting profile

Monitoring device ready

13.0 kN

10.4

7.8

5.2

2.6

0

0 5 10 15 mm

Tearing path

Nom. 10.00 mm

Min. 9.00 mm

Max. 11.00 mm

Tol. ±10.0 %

Tearing force

Nom. 10000 N

Min. 9000 N

Max. 11000 N

Tol. ±10.0 %

Abort \bar{x} Cycle Erase Cal OK

Process monitoring


11.3 Creating a profile

Not included in GAV-8000 eco

When **cycle** is selected, at least 3 blind rivets will be processed in the jointing stock.

The tear off point of the current process graph turns blue and those of the last maximal 20 processes are displayed in grey.

Erase is used to delete all recorded data and to generate new process graphs.




Step 4: Setting evaluation parameters

Now you can determine the evaluation parameters for the tear off distance and tear off force. These are determined by setting the absolute values min. or max. or the target value and the deviation in percentage.

The set limits are displayed in a window.

\bar{x} is used to mediate the window above the tear off points automatically. Afterwards, only the tolerated deviation in percent needs to be set.



Process monitoring

11.3 Creating a profile


Not included in GAV-8000 eco

Step 5: Setting scaling for tensile distance


The scaling for the tensile distance is to be set in such a way that the target value for the tear off point lies at approx. 75% of the total scaling.

When the scaling for the tensile distance is changed, the tear off points are updated immediately, the graph however not before the next cycle.

The scaling for the tensile force is adapted automatically after each measurement.



For verification purposes, several process graphs can be run after this.



Step 6: Save profile

Use **OK** to store the new profile.

Use **cancel** to interrupt the process and the old profile will be reloaded.

Process monitoring

11.3 Creating a profile

Not included in GAV-8000 eco

After the profile was stored, the new parameters will be imported automatically...

Setting profile

New profile saved

| | |
|-----------------------|---------------|
| Designation | Rivet art.no. |
| PG6,4x10 FP K11 FG2,5 | 6706339 |

Evaluation parameters

| | |
|----------------------------------|---------|
| Tearing path min. | 7.45 mm |
| Tearing path max. | 9.05 mm |
| Tearing force min. | 8687 N |
| Tearing force max. | 10573 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |

Back
Load
Save
...to
New
List

...and after returning to the main menu they will be activated as individual profile.

AUTO / Ready (Manual)

PG6,4x10 FP K11 FG2,5

Cycle ☐


Lift position ☐

Blast air ☐

Mandrel extractor ☐

Lock open ☐

Singulator open ☐



| | | |
|---|---|---|
| H | A | B |
| G | 0 | C |
| F | E | D |

No List

Oscillating conveyor

?
Off
On
Stby
MAN

Process monitoring

11.4 Loading a profile

Not included in GAV-8000 eco

From the AUTO main menu by pressing

- MAN
- Menu
- Process control
- Profile

go to the "setting profile" menu the evaluation parameters of the current profile are displayed.

Select **load** and the window for selecting profiles will open.

Select the desired profile and load it by selecting **OK**.

In the example a profile of the same blind rivet for a lesser jointing stock thickness was loaded.

After returning to the main menu the loaded profile will automatically be activated as a single profile.

Setting profile

Profile

| | |
|-----------------------|---------------|
| Designation | Rivet art.no. |
| PG6,4x10 FP K11 FG3,0 | 6706339 |

Evaluation parameters

| | |
|----------------------------------|---------|
| Tearing path min. | 7.02 mm |
| Tearing path max. | 8.52 mm |
| Tearing force min. | 8787 N |
| Tearing force max. | 10673 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |

Back
Load
Save
...to
New
List

Setting profile

Select profile

| Designation | Rivet art.no. |
|-----------------------|---------------|
| PG6,4x10 FP K11 FG2,5 | 6706339 |
| PG6,4x10 FP K11 FG2,0 | 6706339 |
| PG6,4x10 FP K11 FG3,0 | 6706339 |
| PG6,4x10 FP K11 FG4,0 | 6706339 |

Profile 2/4 - Index 1/1

Step rate (scaling path) 0.04 mm

Abort
First
Last
OK

Setting profile

Profile loaded

| | |
|-----------------------|---------------|
| Designation | Rivet art.no. |
| PG6,4x10 FP K11 FG2,0 | 6706339 |

Evaluation parameters

| | |
|----------------------------------|---------|
| Tearing path min. | 7.65 mm |
| Tearing path max. | 9.31 mm |
| Tearing force min. | 8741 N |
| Tearing force max. | 10639 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |

Back
Load
Save
...to
New
List

Process monitoring

11.5 Storing a profile

Not included in GAV-8000 eco

From the AUTO main menu by pressing

- ▶ **MAN**
- ▶ Menu
- ▶ Process monitoring
- ▶ Profile

go to the "setting profile" menu. The evaluation parameters of the current profile are displayed.

Use **save** to store changes to the current profile.

The storage of the profile with changed parameters must be confirmed with **yes**.

The example shows a profile stored with changed parameters.

Setting profile

| Profile | |
|--------------------------------------|--------------------------|
| Designation PG6,4x10 FP K11 FG3,0 | Rivet art.no. 6706339 |
| Evaluation parameters | |
| Tearing path min. | 7.02 mm |
| Tearing path max. | 8.52 mm |
| Tearing force min. | 8787 N |
| Tearing force max. | 10673 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |
| Back | Load |
| Save | ...to |
| New | List |

Setting profile

| Profile | |
|--|--------------------------|
| Designation PG6,4x10 FP K11 FG3,0 | Rivet art.no. 6706339 |
| <div style="border: 1px solid black; background-color: #d3d3d3; padding: 10px; margin: 0 auto; width: 80%;"> <div style="background-color: #000080; color: white; text-align: center; padding: 2px 5px;">Save profile</div> <div style="text-align: center; padding: 10px;"> ? <div>Save profile with changed evaluation ?</div> </div> </div> | |
| Tearing path min. | 7.02 mm |
| Tearing path max. | 8.52 mm |
| Tearing force min. | 8787 N |
| Tearing force max. | 10673 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |
| No | Yes |

Setting profile

| Profile saved | |
|--------------------------------------|--------------------------|
| Designation PG6,4x10 FP K11 FG3,0 | Rivet art.no. 6706339 |
| Evaluation parameters | |
| Tearing path min. | 7.03 mm |
| Tearing path max. | 8.51 mm |
| Tearing force min. | 8787 N |
| Tearing force max. | 10673 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |
| Back | Load |
| Save | ...to |
| New | List |

Process monitoring

11.5 Storing a profile

Not included in GAV-8000 eco

Use **..as** (save as) to store the current profile with a new denomination and item number.

To add a new denomination and item number you can either change the original data or , you can enter new data, after deleting the individual input line (hold **Del**) .

A new denomination is essential but the item number may be kept.

Setting profile

Profile

Enter profile designation

PG6,4x10 FP K11 FG3,1_ 4

A B C D E F G H I J K L M N O P Q R S T
 U V W X Y Z a b c d e f g h i j k l m n
 o p q r s t u v w x y z 0 1 2 3 4 5 6 7
 8 9 _ [] () * + , - . / : ; < = > ?

Setting profile

Profile

Enter rivet art.no.

6706339_ 3

A B C D E F G H I J K L M N O P Q R S T
 U V W X Y Z a b c d e f g h i j k l m n
 o p q r s t u v w x y z 0 1 2 3 4 5 6 7
 8 9 _ [] () * + , - . / : ; < = > ?

Step rate (scaling path) 0.04 mm

Abort
Del
Ins
End
Clr
OK

In the example a new profile was created by using the parameters of an existing profile.

Setting profile

New profile saved

| | |
|-----------------------|---------------|
| Designation | Rivet art.no. |
| PG6,4x10 FP K11 FG3,1 | 6706339 |

Evaluation parameters

| | |
|----------------------------------|---------|
| Tearing path min. | 7.02 mm |
| Tearing path max. | 8.52 mm |
| Tearing force min. | 8787 N |
| Tearing force max. | 10673 N |
| Begin recording at pulling force | 2000 N |
| Step rate (scaling path) | 0.04 mm |

Back
Load
Save
...to
New
List

Process monitoring

11.6 Creating a profile list

Not included in GAV-8000 eco

Starting position AUTO main menu

After start-up the GAV loads first the profile or profile list used most recently as well as the profile used most recently in it.

If no profile was created so far, a profile called "start profile" will be generated. In this case at least one profile has to be created first (see chapter 11.3 "process monitoring" - "create profile").

AUTO / Ready (Manual)

PG6,4x10 FP K11 FG2,5

Cycle ☐

Lift position ☐

Blast air ☐

Mandrel extractor ☐

Lock open ☐

Singulator open ☐

Oscillating conveyor

? Off On Stby MAN

| | | |
|---|---|---|
| H | A | B |
| G | O | C |
| F | E | D |

No List

Step 1: "Setting profile list" menu

From the AUTO main menu by pressing

- **MAN**
- Menu
- Process control
- Profile
- List

go to the "setting profile" menu. Profiles of the current profile list or the profile list used most recently are shown. The text fields will be empty if no profile list has been created.

Setting profile list

Profile list

Designation Part art.no.
Modul 01 000123456789-01

Profile for next process (from 6)

| No. | Designation | Rivet art.no. |
|------|-----------------------|---------------|
| 0001 | PG6,4x10 FP K11 FG2,5 | 6706339 |
| 0002 | PG6,4x10 FP K11 FG2,5 | 6706339 |
| 0003 | PG6,4x10 FP K11 FG2,5 | 6706339 |

Back Load New PLC

Use **New** to create a new profile list.

Process monitoring

11.6 Creating a profile list

Not included in GAV-8000 eco

Step 2: Enter denomination and item number

First enter the denomination of the profile list and then the item number for the component part or sub-assembly.

The denomination of the profile list should give an unambiguous identification of the type of application.

Once applied, denominations cannot be transferred to new profile lists.

Setting profile list

Profile list

Enter profile list designation

Modul 02_ 17

A B C D E F G H I J K L M N O P Q R S T
U V W X Y Z a b c d e f g h i j k l m n

Setting profile list

Profile list

Enter profile list part art.no.

000123456789-02_ 0

A B C D E F G H I J K L M N O P Q R S T
U V W X Y Z a b c d e f g h i j k l m n
o p q r s t u v w x y z 0 1 2 3 4 5 6 7
8 9 _ [] () * + , - . / : ; < = > ?

0003 PG6,4x10 FP K11 FG2,5 6706339

Abort Del Ins End Clr OK

Step 3: Create profile list

When creating profile lists, it is important that profiles assigned to each blind rivet point are stored in the same order in which the blind rivet is later on processed in the component part (See chapter 11.1 "process monitoring" - "functional characteristics" - "profile lists").

Setting profile list

Select profile 1 for profile list

| Designation | Rivet art.no. |
|-----------------------|---------------|
| PG6,4x10 FP K11 FG2,5 | 6706339 |
| PG6,4x10 FP K11 FG2,0 | 6706339 |
| PG6,4x10 FP K11 FG3,0 | 6706339 |
| PG6,4x10 FP K11 FG4,0 | 6706339 |

Profile 3/4 - Index 1/1

0003 PG6,4x10 FP K11 FG2,5 6706339

Abort First Last OK


Process monitoring

11.6 Creating a profile list

Not included in GAV-8000 eco


Now the profiles can be selected in the required order and then stored to the profile list by using **OK**.

A new profile list is created by storing the first profile and will be extended with each following profile.



This sequence is repeated up to the number of profiles required for the profile list.

Use **Ready** to complete the profile list.



Process monitoring

11.6 Creating a profile list

Not included in GAV-8000 eco

After completion the new profile list and the first profile are automatically loaded from it.

Setting profile list

New profile list saved

Designation
Modul 02

Part art.no.
000123456789-02

Profile for next process (from 5)

| No. | Designation | Rivet art.no. |
|------|-----------------------|---------------|
| | | |
| 0001 | PG6,4x10 FP K11 FG3,0 | 6706339 |
| 0002 | PG6,4x10 FP K11 FG2,0 | 6706339 |
| 0003 | PG6,4x10 FP K11 FG4,0 | 6706339 |

Back
Load
New

PLC

In the example shown, a profile list was created for component part "TEST component part 02" using item number "0123456789" .

| Profile no. = rivet point | Profile Designation | Blind rivet Item No. | Joining stock Thickness: |
|------------------------------|------------------------|-------------------------|--------------------------------|
| 1 | PG 6.4x10 FK11 FG 3.0 | 6705890 | 3 mm |
| 2 | PG 6.4x10 FK11 FG 2.0 | 6705890 | 2 mm |
| 3 | PG 6.4x10 FK11 FG 4.0 | 6705890 | 4 mm |
| 4 | PG 6.4x10 FK11 FG 2.0 | 6705890 | 2 mm |
| 5 | PG 6.4x10 FK11 FG 3.0 | 6705890 | 3 mm |

After returning to the main menu the new profile list will be activated from it automatically.

AUTO / Ready (Manual)

Cycle ☐

Lift position ☐

Blast air ☐

Mandrel extractor ☐

Lock open ☐

Singulator open ☐

Modul 02

☐

Monitoring
device ready

-
(1/5)

Oscillating conveyor

?
Off
On
Stby
MAN

Process monitoring

11.7 Loading a profile list

Not included in GAV-8000 eco

From the AUTO main menu by pressing

- **MAN**
- Menu
- Process control
- Profile
- List

go to the "setting profile" menu. Profiles of the current profile list or the profile list used most recently are shown. The text fields will be empty if no profile list has been created.

Select **load** and the window for selecting a profile list will open.

Select the desired profile list and load it by selecting **OK**.

The loaded profile list and the first profile from it will be activated automatically after returning to the main menu.

Setting profile list

Profile list

| | |
|-------------|-----------------|
| Designation | Part art.no. |
| Modul 02 | 000123456789-02 |

Profile for next process (from 5)

| No. | Designation | Rivet art.no. |
|------|-----------------------|---------------|
| 0001 | PG6,4x10 FP K11 FG3,0 | 6706339 |
| 0002 | PG6,4x10 FP K11 FG2,0 | 6706339 |
| 0003 | PG6,4x10 FP K11 FG4,0 | 6706339 |

Back
Load
New
PLC

Setting profile list

Select profile list

| Designation | Part art.no. |
|-------------|-----------------|
| Modul 01 | 000123456789-01 |
| Modul 02 | 000123456789-02 |
| Modul 03 | 000123456789-03 |

Profile list 1/6 - 6 Profiles in profile list

Abort
First
Last
OK

Setting profile list

Profile list loaded

| | |
|-------------|-----------------|
| Designation | Part art.no. |
| Modul 01 | 000123456789-01 |

Profile for next process (from 6)

| No. | Designation | Rivet art.no. |
|------|-----------------------|---------------|
| 0001 | PG6,4x10 FP K11 FG2,5 | 6706339 |
| 0002 | PG6,4x10 FP K11 FG2,5 | 6706339 |
| 0003 | PG6,4x10 FP K11 FG2,5 | 6706339 |

Back
Load
New
PLC

Process monitoring

11.8 Profile lists PLC

Not included in GAV-8000 eco

From the AUTO main menu by pressing

- **MAN**
- Menu
- Process control
- Profile
- List
- PLC

go to the "setting profile lists PLC" menu.

Here, 10 profile lists can be prepared for direct selection by the PLC interface.

After selecting the position to be assigned, a window containing the available profile lists will open. Select the desired profile list and assign it by selecting **OK**.

Profile lists selected by the PLC are highlighted.

The drive of PLC is described in chapter 28 "PLC interface" paragraph "selecting profile list". Select **Test** to go directly to the "PLC interface test" menu.

| Setting profile list PLC | | | |
|--|------|-------------|-----------------|
| Selection profile lists from PLC interface | | | |
| No. | 0123 | Designation | Part art.no. |
| 1 | 1000 | Modul 01 | 000123456789-01 |
| 2 | 0100 | Modul 02 | 000123456789-02 |
| 3 | 1100 | Modul 03 | 000123456789-03 |
| 4 | 0010 | Modul 04 | 000123456789-04 |
| 5 | 1010 | Modul 05 | 000123456789-05 |
| 6 | 0110 | | |
| 7 | 1110 | | |
| 8 | 0001 | | |
| 9 | 1001 | | |
| 10 | 0101 | | |

| | | | | |
|------|--|--|--|------|
| Back | | | | Test |
|------|--|--|--|------|

| Setting profile list PLC | | | |
|--|---|-----------------|----|
| Selection profile lists from PLC interface | | | |
| No. | Select profile list | | |
| 1 | Designation | Part art.no. | 01 |
| 2 | | | 02 |
| 3 | Modul 04 | 000123456789-04 | 03 |
| 4 | Modul 05 | 000123456789-05 | 04 |
| 5 | Modul 06 | 000123456789-06 | 05 |
| 6 | | | |
| 7 | Profile list 6/6 - 2 Profiles in profile list | | |
| 8 | | | |
| 9 | | | |
| 10 | 0101 | | |

| | | | |
|-------|-------|------|----|
| Abort | First | Last | OK |
|-------|-------|------|----|

| Setting profile list PLC | | | |
|--|------|-------------|-----------------|
| Profile list for PLC selection dedicated | | | |
| No. | 0123 | Designation | Part art.no. |
| 1 | 1000 | Modul 01 | 000123456789-01 |
| 2 | 0100 | Modul 02 | 000123456789-02 |
| 3 | 1100 | Modul 03 | 000123456789-03 |
| 4 | 0010 | Modul 04 | 000123456789-04 |
| 5 | 1010 | Modul 05 | 000123456789-05 |
| 6 | 0110 | Modul 06 | 000123456789-06 |
| 7 | 1110 | | |
| 8 | 0001 | | |
| 9 | 1001 | | |
| 10 | 0101 | | |

| | | | | |
|------|--|--|--|------|
| Back | | | | Test |
|------|--|--|--|------|

Process Control

11.9 Menu Calibration process monitoring Not included in GAV-8000 eco

Menu Calibration process monitoring

Last calibration

| Date | Time | Type | Factor | n | \bar{x} | s |
|------------|----------|-------|--------|----|-----------|------|
| 2008/09/01 | 08:40:38 | Path | 99 | 25 | 91.1 | 1.0 |
| 2008/09/01 | 09:24:28 | Force | 5.0 | 26 | 9170 | 53.1 |
| 2008/09/02 | 10:49:44 | Path | 99 | 25 | 93.0 | 0.0 |
| 2008/09/02 | 10:51:26 | Path | 99 | 25 | 92.9 | 0.0 |


Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Process control
- ▶ Cal

Back Force Path Cal Filter Status

Menu Calibration process monitoring


| | |
|--|--|
| Overview of the latest calibration operations: | |
| Date, Time | Time record of the terminated calibration operations |
| Type | Calibration of either force or path |
| Factor | Equipment specific factor for calibrations of force and path |
| n | Number of calibration operations |
| \bar{x} | Average value for measured paths and forces |
| s | Standard deviations for measured paths and forces |

| | | |
|---------------|--|--|
| Force | Menu " Calibration process monitoring" | |
| Path | Menu "Calibration force" | |
| Cal | Menu "Calibration path" | Amend System parameter  GESIPA-Code |
| Filter | Menu "Filter process monitoring" | |
| Status | Menu "Status process monitoring" | |

Process Control

11.9.1 Calibration force

Not included in GAV-8000 eco



Menu Calibration force

Navigation:
 AUTO
 ▶ MAN
 ▶ Menü
 ▶ Process Control
 ▶ Cal
 ▶ Force

Perform the calibration process:

- 1 Enter the breakload of the calibration mandrels (see. Label of calibration mandrels box)
- 2 Introduce the calibration mandrel into the spreading nosepiece until only the mandrel head is visible and cover the spreading nosepiece with the receptacle
- 3
- 4 Press the **Cycle** key

Repeat Steps 2 to 4 according to prescribed number of cycles


Close the calibration process by pressing the **End** key after the running the prescribed number of cycles.

| | |
|--------------|---|
| Cycle | Triggers a working cycle |
| Erase | Deletes the data recorded during the latest working cycle |
| End | Closes the calibration process after the prescribed number of cycles has been performed |

Process Control

11.9.2 Calibration path

Not included in GAV-8000 eco



Menu: Calibration path

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Process Control
- ▶ Cal
- ▶ Path

Performing the calibration:

- When **Improve WS1 Adjustment !** is displayed, then adjust the initial position of the stroke sensor WS1 according to the proposed value and direction (see also chapter 9.3 Major pressure transducer)
- Run the necessary number of empty cycles by pressing repeatedly the **Cycle** key
- Close the calibration process after running the prescribed number of cycles by pressing the **End** key.

| | |
|--------------|---|
| Cycle | Triggers a working cycle |
| Erase | Deletes the data recorded during the latest working cycle |
| End | Closes the calibration process after the prescribed number of cycles has been performed |

Process data


Not included in GAV-8000 eco

After each setting process the following parameters are stored in the process data file:

- Date and time (time stamp)
- Profile and profile list used for evaluation
- Tear off distance and tear off force (tear off point)
- Evaluation of process

The process data file records the last 1,000,000 processes. If more data exists, the older data will be overwritten.

To evaluate the recorded process data, go to the "process data" menu.




An overview over 20 days in the form of a bar chart is displayed under the menu option "process data 20 days". When selecting single days the option field displays date, total number of processes, process IO and processes NIO for each process. Select **day** to carry out a detailed evaluation.

The scaling of the piece number display relates automatically to the highest overall value. Sections bearing smaller piece numbers are thus always displayed in the same proportion. Sections bearing considerably lower piece number may be rescaled by selecting **Scale**.

| | |
|--------|--|
| < | This moves the display back by one day. |
| > | This moves the display forward by one day. |
| Update | Selects 20 days up to the current date. |
| Scale | Rescales the piece number. |
| Date | "Process data day" menu (detailed evaluation, one day) |

Process counter

The process counter can be applied to determine per component part the number of blind rivets to be processed and to display and monitor in the AUTO main menu their processing by counting. This function cannot be used simultaneously with another profile list. The installation of the required component parts is described in chapter 28.4 "PLC interface – process counter".



Process counter

To process:
23
of 23


| Process counter | |
|-----------------|-----|
| Nom. | 23 |
| Real | 23 |
| Active | Yes |

Back

Setting process counter

Navigation:
 AUTO
 ▶ MAN
 ▶ Menu
 ▶ Process counter

When a button is pressed (to be installed by the customer at the workplace) the counter display is set at the set value (target).



AUTO / Ready (Manual)

PG6,4x10 FP K11 FG2,5


To process:
23
of 23

| | | |
|---|---|---|
| H | A | B |
| G | 0 | C |
| F | E | D |

No List

Oscillating conveyor

? Off On Stby MAN



AUTO / Ready (Manual)

PG6,4x10 FP K11 FG2,5

To process:
0
of 23

| | | |
|---|---|---|
| H | A | B |
| G | 0 | C |
| F | E | D |

No List

Oscillating conveyor

? Off On Stby MAN

After the set number of blind rivets was processed (counter status 0), it is possible to activate a warning device (lamp, buzzer) and, additionally, to stop the GAV.

Access codes

Access management is described in chapter 8.6 "operation" paragraph "access management".


Changing access codes:

Service and GESIPA code may be changed in the "access codes" menu:

To change service or GESIPA code, the relevant access authorization has to be given. Afterwards the new code is entered twice. If both inputs are identical, the new code will be stored. Date and time of the last change of the access code are equally stored and displayed in the "access codes" menu.

It is standard that the input of access codes is hidden with shown in the input window instead of the entered numbers. In order to display the numbers, the "enter access codes hidden" function can be set to **no** in the "access codes" menu.

The default setting for the service code is 1111.



Access codes

Change service code (highlighted)

Change GESIPA code

Enter new service code

Enter access codes covertly

Yes


Abort 1 2

Example code input
Service code

Navigation:
AUTO
▶ MAN
▶ Menu
▶ Access codes

Example:

In the example shown, the service code was changed, access authorization granted and the new service code can now be entered. If the input was successful, date and time "last change" will be displayed.



Access codes

Change service code

Change GESIPA code

Last modification
2007/01/23
09:45:48

Last modification
2006/01/01
01:02:00

Enter access codes covertly

Yes

Back

Time and language

Time and language

System time (GMT)

Date

2007/01/23

Year

Month

Day

Language

English

German

Time

09:49:05

Hour

Minute

Second

Sync. 60s

09:49:00

09:49:01

Back

Settings time and language

Navigation:

AUTO

▶ MAN

▶ Menu

▶ System time

0

GESIPA-Code

System time is mainly required for the time stamp of the data record in the area of setting process monitoring and operating data collection.

To simplify file collating (e.g. process and operating data) from different time zones, it is advisable to set global time reference GMT (Greenwich Mean Time).

System information

| System info | | | |
|--------------------------------------|-----------|---------------------|--|
| System time (GMT) | | 2007/01/23 09:52:41 | |
| Counter mechanism | | 1237 | |
| <hr/> | | | |
| Version software control and display | | V01.71.20070116 | |
| Version operating system display | | TS4 V4.0.0 | |
| Cycle time display | | 20.0 ms | |
| Cycle time control | | 8.1 ms | |
| RAM memory | 10647 kB | RAM 99 % | |
| TMP memory | 1024 kB | TMP 0 % | |
| Flash memory | 8192 kB | Flash 32 % | |
| Card memory | 124778 kB | Card 56 % | |
| IP adress | | 192.168.82.247 | |
| Back | | Update | |

System information

Navigation:
AUTO
▶ MAN
▶ Menu
▶ System information


Apart from the current system time and the counter status of the electronic counter important internal system parameters are displayed in the "system info" menu.

- Version number of the installed software control and display.
- Cycle times of control and display.
- Total capacity and utilization of different memory areas on the display.

GRivCheck

Not included in GAV-8000 eco

The connection between the dialogue units of the GAV and the PC with the user software GRivCheck is prepared via the interface RS232 in the "GRivCheck" menu and communication is displayed according to connection structure. Connection can take place directly between PC and GAV or via the PLC interface. For detailed information please refer to the description of the user software GRivCheck.




Example (see images):

The readiness of the GAV for establishing a connection is indicated by the "PC mode ready" message.

After connection was established, the GAV will react merely to commands from GRivCheck; the current status is displayed immediately.

In the example, process data is transferred from GAV to GRivCheck, the command, a brief description and the status are displayed.



Malfunction supply unit

| <u>GAV not triggered</u> ("AUTO", main menu, no error message) | |
|---|--|
| Cause/reason | Remedy |
| Relevant trigger option not selected or disabled. | Select trigger option, see chapter 9.9 "settings GAV" – "additional functions". |
| Pressure sensor DS2 1-8040.2 set incorrectly. | Set pressure sensor DS2 1-8040.2, see chapter 9.2 "settings GAV" – "pressure sensors". |
| Large pressure transmitter 3-8060 not in initial position. | Move GAV to initial position by pressing the "ON" button, check basic setting of large pressure transmitter 3-8060, see chapter 9.3 "settings GAV" – "large pressure transmitter". |
| <u>GAV working independently</u> | |
| Cause/reason | Remedy |
| Leakage on valve island 1-8030, at cover of blind riveting gun 2-8002 or on air supply of blind riveting gun. | Eliminate leakage. |
| Incorrect settings for pressure sensors DS1 1-8040.1 and DS2 1-8040.2 | Set pressure sensor DS2 1-8040.1 and DS 1-8040.2, see chapter 9.2 "settings GAV" – "pressure sensors". |
| <u>Blind rivet not set or rivet mandrel not torn off</u> | |
| Cause/reason | Remedy |
| Worn chuck jaws. | Replace chuck jaws, see chapter 10.1 "maintenance" – "notes on maintenance". |
| Air inside hydraulic system. | Bleed hydraulic system for blind riveting process, see chapter 24 "filling hydraulic systems". |
| <u>Blind rivet is not separated.</u> | |
| Cause/reason | Remedy |
| Control valve stop buffer 4-8029 for singulator 4-8000 closed. | Basic setting singulator 4-8000, see chapter 9.5 "settings GAV" - "singulator". |
| Separating cylinder 4-8125 defective. | Replace separating cylinder 4-8125. |
| Separating spoon 4-8002 damaged. | Replace separating spoon 4-8002. |
| Sensor NS2 4-8044 screwed down too far. | Basic setting singulator 4-8000, see chapter 9.5 "settings GAV" - "singulator". |

Malfunction blind riveting gun

Follow safety and environmental instructions!



Wear protective goggles!




Attention!

Always cut off compressed air supply from the tool and turn off main switch before unscrewing the expanding mouth piece or the expanded mouth piece.

Blind rivet not conveyed from expanding mouth piece or mouth piece not closing.

- Press OFF button.
- Unscrew expanding mouth piece 2-80.
- Remove blind rivet
- Screw down expanding mouth piece 2-80 and lock it
- Press ON button.
- Carry out "cycle" function in "MAN" menu.




| Cause/reason | Remedy |
|---|---|
| Blind riveting gun was held too close to work-piece during loading process. | Take care to keep sufficient distance between the expanding mouth piece and the workpiece. |
| Insufficient projection of blind riveting mandrel. | Blind rivet must comply with specifications. |
| Air pressure too low or pressure drop too high during blind riveting process. | Ensure compressed air supply of 6 bar for of blind riveting tool. |
| Torn off blind rivet mandrel wedged in feed mechanism (chuck jaws wedged). | For maintenance of chuck jaws, see chapter 10.1 "notes on maintenance" - "lubricate chuck jaws" |
| Locking spring 2-8033 bent or broken. | Replace locking spring 2-8033, see chapter 21 "repair instructions blind riveting gun" - "replacing the locking spring". |
| Adhesive fit of snap collet 2-8022 on snap hose 2-8011 insufficient (expanding mouth piece not unlocked). | Replace snap collet 2-8022. (If adhesive fit is correct, you can lift the blind riveting gun together with the snap collet 2-8022). |
| Too great a locking pressure of O-rings 2-50 on expanding mouth piece 2-80. | Remove one of the O-rings 2-50 from the expanding mouth piece 2-80. |
| Snap ring 2-40 was deformed by blind riveting without snap collar 2-22 (unlocking lift for expanding mouth piece not completely carried out). | <ul style="list-style-type: none"> - Unscrew expanding mouth piece 2-80. - Detach snap collet 2-22. - Push back stop ring 2-6021. - Replace snap ring 2-40. - Assemble in reverse order. |

Malfunction blind riveting gun

Blind rivet conveyed too far out of the expanding mouth piece.


- Press OFF button.
- Remove blind rivet
- Press ON button.
- Carry out "cycle" function in "MAN" menu.



| Cause/reason | Remedy |
|--|---|
| Chuck jaws wedged and / or torn off blind rivet mandrel not ejected. | Maintenance of chuck jaws required, see chapter 10.1 "notes on maintenance" – "lubricate chuck jaws". Check setting for blast air, for basic setting see chapter 9.6 "settings GAV" – "blast air". |
| Locking spring 2-8033 broken. | Replace locking spring 2-8033, see chapter 21 "repair instructions blind riveting gun" - "replacing the locking spring". |
| Chuck jaw hose 2-6032 sluggish. | Replace chuck jaw hose 2-6032, see chapter 21 "repair instructions blind riveting gun" - "replacing the chuck jaw hose". |
| Insufficient locking pressure of O-rings 2-50 on expanding mouth piece 2-80. | Mount additional O-ring 2-50 on expanding mouth piece 2-80 (use genuine part). |
| Chuck cage 2-8005 or 8205 escaped from inlet cone. | Replace chuck cage 2-8005 or 8205, for sequence of operations see chapter 21 "repair instructions blind riveting gun" - "replacing chuck jaws". |

Blind rivet and torn off blind rivet mandrel in expanding mouth piece

- Press OFF button.
- Remove blind rivet and blind rivet mandrel
- Press ON button.
- Carry out "cycle" function in "MAN" menu.




| Cause/reason | Remedy |
|--|--|
| Torn off blind rivet mandrel wedged in chuck jaws. | Maintenance of chuck jaws required, see chapter 10.1 "notes on maintenance" – "lubricate chuck jaws". |
| Chuck jaw hose 2-6032 sluggish (bent). | Replace chuck jaw hose 2-6032, see chapter 21 "repair instructions blind riveting gun" - "replacing the chuck jaw hose". |
| Leaf spring 2-6093 bent or broken. | Replace leaf spring 2-6093, see chapter 21 "repair instructions blind riveting gun" - "replacing the leaf spring". |

Malfunction blind riveting gun

Blind rivet does not arrive in blind riveting gun

Carry out "cycle" function in "MAN" menu.



| Cause/reason | Remedy |
|---|---|
| Blind rivet wedged in rivet feed hose. | Loosen and remove wedged blind rivet by kinking the rivet feed hose. |
| Blind rivet wedged in singulator 4-8000. | To open singulator 4-8000, select "open singulator" function in "MAN" menu, pull back singulator tongue 4-8007 manually and remove rivet. |
| - Incorrect setting singulator tongue 4-8007. | Set singulator tongue 4-8007 in such a way that only one blind rivet at a time is separated. |
| - Control valve 4-8029 for stop buffer singulator closed. | For basic setting control valve 4-8029 see chapter 9.5 "setting GAV" - "singulator". |
| - Singulator spoon damaged. | Replace singulator spoon. |
| - Singulator cylinder defective. | Replace singulator cylinder. |

Blind rivet wedged in transfer mechanism of blind riveting gun.

- Carry out "lift position" function in "MAN" menu.
- Turn off main switch, unscrew expanding mouth piece and pull off snap collar.
- Swing out locking spring, point blind riveting gun down and shake out blind rivet.
- Assemble blind riveting gun in reverse order, connect it and turn it on.
- Carry out "cycle" function in "MAN" menu.




| Cause/reason | Remedy |
|---|--|
| Conveyor hose dry | Top up central lubricating system, see chapter 10.1 "notes on maintenance" - "topping up the central lubricating system" and - "oil rivet feed hose". Correct setting for central lubricating system, see chapter 9.6 "settings GAV" – "blast air". |
| Traversing radius of rivet feed hose too small. | Increase traversing radius for rivet feed hose. |
| Locking spring 2-33 broken or spring rubber has come loose. | Replace locking spring 2-8033, see chapter 21 "repair instructions blind riveting gun" - "replacing the locking spring". |
| Incorrect setting blast air. | Set blast air, for basic setting see chapter 9.6 "settings GAV" – "blast air". |
| Selected rivet feed hose is too large. | Comply with tool specifications. |

Malfunction blind riveting gun

Two blind rivets in expanding mouth piece.

- Press OFF button.
- Remove blind rivet
- Press ON button.
- Carry out "cycle" function in "MAN" menu.



| Cause/reason | Remedy |
|--|--|
| Incorrect setting singulator tongue 4-8007. | Set singulator tongue 4-8007 in such a way that only one blind rivet at a time is separated. |
| A second blind rivet ended up in the singulator when it was opened manually. | Press OFF button. Remove second blind rivet. Press ON button. |
| During the previous work cycle the blind rivet was not conveyed right up to the mouth piece. | |
| Traversing radius of rivet feed hose too small. | Increase traversing radius for rivet feed hose. |
| Rivet feed hose extremely worn. | Replace rivet feed hose. |
| Rivet feed hose too dry. | Top up central lubricating system, see chapter 10.1 "notes on maintenance" - "topping up the central lubricating system" and - "oil rivet feed hose". Correct setting for central lubricating system, see chapter 9.6 "settings GAV" – "blast air". |
| Locking spring 2-33 broken or spring rubber has come loose. | Replace locking spring 2-8033, see chapter 21 "repair instructions blind riveting gun" - "replacing the locking spring". |
| Incorrect setting blast air. | Set blast air, for basic setting see chapter 9.6 "settings GAV" – "blast air". |

Repair instructions blind riveting gun

Follow safety and environmental instructions!



Wear protective goggles!




Attention!

Turn off main switch and compressed air supply to tool!


Replacing the locking spring 2-33

- Unscrew expanding mouth piece 2-80.
- Detach snap collet 2-22.
- Pull out locking spring 2-33 from the catch.
- Assemble in reverse order.



Replacing chuck jaws

- Unscrew expanding mouth piece 2-80.
- Detach snap collet 2-22.
- Unscrew the feed mechanism.
- Remove complete chuck jaw assembly including washer, stop ring and opening spring.
- Before assembling the complete chuck jaw assembly, lubricate the gliding surface of the chuck cage with grease.
- Place the chuck cage onto the chuck jaw assembly.
- Insert stop ring and washer.
- Assemble in reverse order.



Replacing the leaf spring 2-6093

Assembly aid: Assembly drift E9-20 (extra)

- Disconnect compressed air supply from tool.
- Switch off main switch
- Unscrew expanding mouth piece 2-80.
- Detach snap collet 2-22.
- Unscrew cover 2-2 and thread plug 2-6003.
- Apply assembly drift, to push back tensile piece 2-6009 (pin pointing down) to stop surface.
- Remove feather key 2-6023 with pliers.
- Remove or replace leaf spring. After reassembling feather key 2-6023 by pressing it with thumb, push the tensile piece 2-6009 to the front so that the feather key slips into the groove guide.
- Assemble cover 2-2 and thread plug 2-6003.



Attention!

Do not connect compressed air supply before assembling thread plug 2-6003 and cover 2-2.

Repair instructions blind riveting gun


Replace chuck jaw hose 2-6032.

- Unscrew expanding mouth piece 2-80.
- Detach snap collet 2-22.
- Unscrew the feed mechanism.
- Pull out chuck jaw hose 2-6032 from catch.




Attention!


To prevent damage to the leaf spring, assemble the chuck jaw hose according to **pos. 1 – pos. 3**



Pos. 1



Pos. 2



Pos. 3

- **First insert the chuck jaw hose 2-6032 facing slotted side of leaf spring 2-6093 facing (pos. 1).**
- When touching the leaf spring 2-6093, turn the chuck jaw hose 2-6032 carefully by 180 ° (**pos. 2**) and move it 1-2 mm forward and back , then arrest in stop position (**pos. 3**).

Replacing the stop pistons 2-6020

Assembly aid: Assembly mandrel E9-20 (extra)


- Turn off main switch and ensure that tool is disconnected from the compressed air supply!
- Unscrew expanding mouth piece 2-80.
- Detach snap collet 2-22.
- Apply the assembly mandrel E9-20 and push tensile piece 2-6009 back (pin pointing up) to bearing surface of pin.
- Unscrew cover 2-2 and thread plug 2-6003.
- Remove safety ring 2-6043. Take care that the inner component parts subject to spring pressure do not jump out.
- Remove reset piston 2-6013, stop piston 2-6020, pressure spring 2-35 and cylinder collar 2-6012.
- Insert new stop piston 2-6020 with O-ring 2-55.
Before installing ensure that the O-ring 2-55
 - is greased on the stop piston 2-6020.
 - that the parts are assembled in the correct order.
 - that the cylinder collar 2-6012 with the control borings is assembled correctly.
 - that the thread plug 2-6003 is projecting approx. 2 mm beyond the case edge.



Repair instructions blind riveting gun

Replacing the blind riveting gun

- Turn off main switch and compressed air supply to tool.
- Disconnect rivet feed hose, air guide hose as well as hydraulic control hose from blind riveting gun.
- Unscrew ventilating screw 2-28a, lift blind riveting gun above level of pressure transmitter tank.
- Push back the spring suspended stop pin on the on coupling half 2-27.
- Detach blind riveting gun by rotating it around the connecting axis. When doing this ensure that you hold the end of the hydraulic hose level with or above the level of the supply unit.



Attention!

Make appropriate arrangements for catching the amount of hydraulic oil of approx. 0.02 l that escapes during unscrewing the gun and dispose of it in an environmentally friendly manner.

- Assembly new gun in reverse order.



Attention!

- Check the O-ring positioned in the coupling half of the gun for correct fit.
- Connect the air control hose to the blue screw joint.

Filling the blind riveting gun with hydraulic oil


• Hydraulic system for blind riveting process

- Unscrew the ventilating screw 2-28a.
- Lower the blind riveting gun below the level of the pressure transmitter tank; after a short while oil will start escaping from the ventilating borehole.
- Screw down ventilating screw 2-28a with conical nipple 2-57.

• Hydraulic system for mouth piece release

- Unscrew ventilating screw 2-28b.
- Use a squirt can, to top up hydraulic oil on the small pressure transmitter 3-8030 until oil starts escaping from ventilating borehole on the blind riveting gun.
- Screw down ventilating screw 2-28b with conical nipple 2-57.

Repair instructions blind riveting gun



Replacing the piston unit 2-6190

Mounting aids:

| | |
|---------------------|---------|
| Mounting cone E9-18 | (extra) |
| Mounting bolt E9-21 | (extra) |
| Punch E9-22 | (extra) |

Removal:

- Detach expanding mouth piece 2-80 and snap collet 2-22.
- Unscrew cover 2-2 and thread plug 2-6003.
- Turn back stop ring 2-6021 (pre-tensed) by approx. 2 mm and disassemble the appearing snap ring 2-40.
- Detach stop ring 2-6021.
- Detach coupling collet 2-6151 and shaft ring 2-6155, remove feather key 2-6153 with flat pliers.
- Remove piston unit 2-6190 from press fit by tapping it lightly with a synthetic hammer and by pushing it out with puncher E9-22; avoid damage to cylinder bearing surface.

Installation:

- Check cylinder bearing surface of gun case for damage.
- To prevent damage to the conical nipples, place mounting cone E9-18 on case end.
- Slightly grease lip seal 2-47, 2-6147 and O-ring 2-6082.
- Apply mounting bolt E9-21, to press piston unit 2-6190 in vertical position of gun case and tap it lightly with hammer until it has reached the stop (press fit approx. 4 mm length).
- Carry out the rest of the assembly in reverse order of disassembly described above.
- Check if the distance between the stopper ring and the thread collar of the gun casing is approx. 2.5 mm.

Disassembling and assembling The pressure transmitter

Follow safety and environmental instructions!



Wear protective goggles!




Attention!

It is of utmost importance that you disconnect the tool from the power and compressed air supply!

Large pressure transmitter 3-8060


- Remove right and left cover and the mandrel collector from the case.
- Remove screw plug (see right-hand side of image) from case and extract oil through opening.
- Remove the plug-connection of the two distance sensors and the pressure sensor; mind the marking or apply mark, as required.
- Release air supply line from the valve block to the pressure transmitter.
- Place GAV gun and hose assembly at a level that is lower than that of the supply unit.
- Place a cloth below the connection area before detaching the hydraulic hose from the pressure transmitter so that any oil still present in the hose is caught.
- Remove the fastening screws from the case unit.
- Lift the pressure transmitter and tilt it in a manner that it can be removed from the housing with the ground plate in forward position towards the right side.
- Assemble in reverse order. (basic setting see chapter 9.3 „Settings GAV“ - "big pressure transmitter").
- Afterwards the hydraulic system must be bled for the blind riveting process. (see chapter 24, "filling hydraulic systems").



Disassembling and assembling the pressure transmitter

Small pressure transmitter 3-8030

- Remove left-hand cover from housing.
- Place a cloth below the hydraulic control hose before disconnecting the plug-connection to the distance sensor and the hose connections so that any escaping oil is caught.
- Unscrew the fastening screws leading to the case unit from the base plate, lift the pressure transmitter and remove it from the case.
- Assemble in reverse order. Afterwards the hydraulic system must be bled for mouth piece release (see chapter 24 "filling hydraulic systems).



Repair instructions pressure transmitter

Follow safety instructions!



Wear safety goggles!

Replacing the pressure spring 3-8098 in large pressure transmitter 3-8060

- Disassemble the pressure transmitter 3-8060 (see chapter 22 "disassembling and assembling the pressure transmitter")
- Via boring in the cover lid 3-8073 suck off hydraulic oil in the legally admitted oil tank and remove it according to the environmental laws.
- Put away cover lid 3-8073 and inspection glass 3-8075 after screwing out the vertical bolts 3-8102
- Unscrew lock nozzle 3-8068 from valve plate 3-8067 and remove pressure spring 3-8099 together with disk 3-8077.
- Remove cylinder seal 3-8081.
- Take off flange 3-8063 after detaching the hexagon screws.
- Pull out the throttle cylinder 3-8079.
- Bring plunger 3-8070 in upper stop position by means of apportioning compressed air at 2 bar via air connection 3-8141 in base plate 3-8061.
- Unscrew valve plate 3-8067 with integrated O-ring from valve stem 3-8076.
- Loosen and unscrew collar screw 3-8069 with a pin spanner.



Note!



The collar screw 3-8069 is secured by "Loctite".

- Pull out cylinder hose 3-8064, transmitter piston 3-8065 and valve stem 3-8076.
- Turn off pending compressed air.
- Loosen con-rod 3-8078 with hexagon nuts (do not unscrew)



Attention!


The upper plate 3-8062 is under great pressure from the spring! Whilst unscrewing the con-rods 3-8078 compensate spring pressure by applying counter-pressure.

- Take off upper plate 3-8062.
- Replace pressure spring 3-8098.
- Assemble in reverse order.
- When assembling the lock nozzle, the valve stem 3-8076 with valve plate 3-8067 must be pulled through the opening boring of flange 3-8063 by means of a rod magnet. In this position set the valve plate 3-8067 in such a way that the lock nozzle 3-8068, driven by compressed air (2 bar) via air connection 3-8141 in the base plate 3-8061 up to the stop position carries out a lift of 1.5 to 1.9 mm.

Repair instructions pressure transmitter

23

23 Repair instructions pressure transmitter



Filling hydraulic systems

Follow safety and environmental instructions!



Wear safety goggles!

Hydraulic system for blind riveting process large pressure transmitter 3-8060

Assembly aid: Ventilating check valve E9-7 (extra)

- Close both throttle sound absorbers 3-8082 on the valve block leaving one rotation undone.
- Turn on main switch and select "MAN" menu.
- Use pressure reducing valve 1-8002, to reduce working pressure to 4 bar, control via pressure gauge 1-8046.
- To position piston unit 2-6190 in initial position, insert one blind rivet in expanding mouth piece 2-80.
- Actuate the ON key.
- Remove rear ventilating screw 2-28a on blind riveting gun and screw in ventilating check valve E9-7. (To drain and collect excessive hydraulic oil, connect a ventilating hose of 8 mm diameter to the valve).

Note!



To achieve faultless ventilation, place the riveting gun in such a way that the hose assembly is ascending from the supply unit to the riveting gun.

- Remove locking screw (on right-hand side of image) from the case and top up hydraulic oil into oil tank of pressure transmitter 3-8060, as required. Alternate actuating of the "lift position" function fills the hydraulic system. Ensure that the oil level does not drop below the minimum mark. As a rule it is necessary to top up 6 to 8 times.
- The topping up procedure is complete when hydraulic oil without bubbles starts escaping from the ventilating hose.
- Lower the riveting gun to the level of the oil tank on the pressure transmitter. Unscrew the ventilating check valve from the riveting gun.



Note!



Prior to screwing in the ventilating screw with conical nipple ensure that the oil level is visible on the ventilation boring. The oil level can be increased by lowering the riveting gun further.

- Screw in the ventilating screw with conical nipple.

Filling hydraulic systems

Hydraulic system for mouth piece release small pressure transmitter 3-8030

- Unscrew the front ventilating screw 2-28b on the gun.

Note!



To achieve faultless ventilation, place the blind riveting gun in such a way that the hose assembly is ascending from the supply unit to the blind riveting gun.

- Use the squirting can, top up hydraulic oil via the top up connection on the small pressure transmitter until oil starts flowing without bubbles from the ventilation boring to the oil bottle.
- The hydraulic oil caught in the oil bottle may be reused in both hydraulic systems.
- Screw ventilating screw back in.

Hydraulic pipes and screw joints

- Check all pipes, hoses and screw joints regularly for leaks and visually noticeable damage. Repair any damage immediately. Escaping oil may result in injury or fire!
- The user has to ensure that hose pipes are exchanged at appropriate intervals (max. 6 years incl. storage period of max. 2 years), even if no safety-related faults are visible.

Replacing control components

Follow safety instructions!



Attention!

It is of utmost importance that you disconnect the tool from the power and compressed air supply!


- Detach 8 screws on front plate and carefully take off front plate.
- Detach 2 cable connections from frontplate to tool.

• Control module

- The control module is plugged into two retainers on the base of the case's back wall and must be taken off carefully by lifting upwards.
- The 38-channel central plug of the control module is secured by a gripper and is released when removed.
- When assembling in reverse order ensure that the safety gripper of the central plug locks and the control module is plugged in centrally into both retainers.

• Control power pack and electronic module

- Apply a screw driver, to carefully loosen both plug-connections.
- The control power pack and the electronic module are plugged onto mounting rails (top hat rail) and can be loosened with a screw driver.
- Assembly is achieved by plugging in the modules and the plugs in reverse order.



Note!




When assembling plug-connections it has to be ensured that the plug-connectors lock in well.

Pneumatic connection diagram

26


26 Pneumatic connection diagram



Electric circuit diagram

27


27 Electric circuit diagram



Electric circuit diagram


27

27 Electric circuit diagram



PLC interface

28.0 Overview




- 28.1 Technical description**
- 28.2 PLC interface test**
- 28.3 Drive PLC**
- 28.4 Process counter**
- 28.5 Select profile list**
- 28.6 Selecting a profile (directly)**
- 28.7 Selecting a profile (step by step)**
- 28.8 Evaluation process**
- 28.9 Evaluation component part**
- 28.10 Other functions**

PLC interface


28.1 Specifications

The PLC interface serves as an interface to an external PLC, an external control and answer unit or to external input or message devices and enables the connection of a notebook / PC with suitable PC software. The PLC interface is designed for assembly in a control box with independent power supply 24 V DC.



PLC interface

28.1 Specifications




| Technical data | |
|-------------------------------------|--|
| Dimensions | approx. 205 mm x 128 mm x 50 mm |
| Weight | approx. 460 g |
| Fitting | on mounting rail NS 35 x 7.5 (top hat rail) |
| Operative voltage | 24V DC (permitted voltage range 20 - 30V DC) |
| Maximum current consumption | Interface: approx. 300mA Inputs approx. 40mA Outputs depends on loads to be switched |
| Temperature range | permitted ambient temperature -20°C to 70°C |
| Protection type | IP 20 |
| 16 PLC inputs | Control level 1: > 8V DC Control level 0: < 8V DC Fan-in current: typ. 2mA at 24V DC - Current limit - Overvoltage protection - Contact separation |
| 16 PLC outputs | Permitted voltage range: 20 - 30V DC Maximum switching current: 1A at 24V DC - Current limit - Overheating protection - Overvoltage protection - Contact separation |
| 6 relay outputs | DIN EN 61131-2 conform 1x make contact Maximum switching capacity: AC 750VA Maximum switching impulse current: 3A at 230V AC/DC |
| Interfaces | 1x RS232 (GAV) 1x USB (PC) 1 x SD memory card |
| Plug-connector and connecting cable | - Plug-connector for power supply, inputs and outputs (Included in delivery) - Interface cable GAV (Art.-Nr. 719 1133) |

PLC interface

28.1 Specifications

Pin assignment PLC interface



Assignment of functions GAV8000:

| | | | | | |
|----------------------------|----|--|----|---------------------|----|
| Start cycle | 1 | | 1 | Cycle ready | |
| Reverse cycle | 2 | | 2 | Cycle lift position | |
| Rivet query mouth p. | 3 | | 3 | Malfunction GAV | R1 |
| Cycle close start | 4 | | 4 | Malfunction cycle | |
| Counter start | 5 | | 5 | Counter/Part ready | R2 |
| | 6 | | 6 | MAN | |
| Profile 1 | 7 | | 7 | | |
| Next profile | 8 | | 8 | Process/Part OK | R3 |
| Select profile | 9 | | 9 | Process/Part NOK | R4 |
| Profile list/Profile Bit 0 | 10 | | 10 | Error code Bit 0 | |
| Profile list/Profile Bit 1 | 11 | | 11 | Error code Bit 1 | |
| Profile list/Profile Bit 2 | 12 | | 12 | Error code Bit 2 | |
| Profile list/Profile Bit 3 | 13 | | 13 | Error code Bit 3 | |
| Evaluation Part | 14 | | 14 | | |
| | 15 | | 15 | Maintenance | R5 |
| | 16 | | 16 | | R6 |

Input and output with double function:

- Output 5 "counter/part finished" reports when set value has been reached if "process counter" function is active, or the finished part, if profile list is active.
- Inputs 10 to 13 "profile list / profile bit 0" to "bit 3" can be used to select profile lists (see chapter 28.5 "selecting profile lists") or, when "selecting profile" (24V) input is active, to select profiles from the active profile list (see chapter 28.6 Selecting a profile directly").
- Outputs 8 to 13 "process/part IO" and "NIO" are able to issue an evaluation of the most recent process (see chapter 28.8 "evaluation process") and, when the "evaluation component part" input (24V) is active, an evaluation of a component part (see chapter 28.9 "evaluation component part").

PLC interface

28.2 PLC interface test

The input and output assignment of the PLC interface is displayed, and the connection of the GAV to the interface is tested in the PLC interface test menu. In addition it is possible to test individual communications with a connected PLC or control and evaluation unit or input and messaging devices for each input and output.

| Input | Function |
|---------------|---|
| Off | No test function active |
| Toggle | Output test active, output 1 to 16 can be selected via the control button as well as turned on/off. |
| Switch | Output test active, output 1 to 16 can be selected or turned on/off with the control button. |
| C | When output test is active, outputs 1 to 16 will be reset. |

PLC interface test

| | | | | | |
|----------------------------|----|---|----|---------------------|----|
| Start cycle | 1 | | 1 | Cycle ready | |
| Reverse cycle | 2 | | 2 | Cycle lift position | |
| Rivet query mouth p. | 3 | | 3 | Malfunction GAV | R1 |
| Cycle close start | 4 | | 4 | Malfunction cycle | |
| Counter start | 5 | | 5 | Counter/Part ready | R2 |
| | 6 | | 6 | MAN | |
| Profile 1 | 7 | | 7 | | |
| Next profile | 8 | I | 8 | Process/Part OK | R3 |
| Select profile | 9 | N | 9 | Process/Part NOK | R4 |
| Profile list/Profile Bit 0 | 10 | | 10 | Error code Bit 0 | |
| Profile list/Profile Bit 1 | 11 | | 11 | Error code Bit 1 | |
| Profile list/Profile Bit 2 | 12 | | 12 | Error code Bit 2 | |
| Profile list/Profile Bit 3 | 13 | | 13 | Error code Bit 3 | |
| Evaluation part | 14 | | 14 | | |
| | 15 | | 15 | Maintenance | R5 |
| | 16 | | 16 | | R6 |

Back **Off** **Toggle** **Switch** **C**

PLC interface test

Navigation:

- AUTO
- MAN
- Menu
- Settings GAV
- PLC interface test

Example:

- Input 1 "start cycle" is set to 1 (24V) by a connected PLC.
- Output test **switch** is active, output 3 "malfunction GAV" was set to 1 (24) and the related relay R1 was switched.

PLC interface

28.3 Drive PLC

| PLC interface test | | | | Drive PLC | |
|----------------------------|-----|---------------|----|---------------------|----|
| Start cycle | 1 | I N O U T | 1 | Cycle ready | |
| Reverse cycle | 2 | | 2 | Cycle lift position | |
| Rivet query mouth p. | 3 | | 3 | Malfunction GAV | R1 |
| Cycle close start | 4 | | 4 | Malfunction cycle | |
| Counter start | 5 | | 5 | Counter/Part ready | R2 |
| | 6 | | 6 | MAN | |
| Profile 1 | 7 | | 7 | Process/Part OK | R3 |
| Next profile | 8 | | 8 | Process/Part NOK | R4 |
| Select profile | 9 | | 9 | Error code Bit 0 | |
| Profile list/Profile Bit 0 | 10 | | 10 | Error code Bit 1 | |
| Profile list/Profile Bit 1 | 11 | | 11 | Error code Bit 2 | |
| Profile list/Profile Bit 2 | 12 | | 12 | Error code Bit 3 | |
| Profile list/Profile Bit 3 | 13 | | 13 | | |
| Evaluation part | 14 | | 14 | | |
| | 15 | | 15 | Maintenance | R5 |
| | 16 | | 16 | | R6 |
| Back | Off | Toggle Switch | | C | |

Navigation:
 AUTO
 ► MAN
 ► Menu
 ► Settings GAV
 ► PLC interface test

System requirements:

- PLC interface connected to GAV.
- PLC connected to PLC interface.
- Drive PLC active. **AUTO► MAN► menu► settings GAV► drive PLC.**

Inputs:

| | | |
|---------|---------------------------|--|
| Input 1 | "start cycle" | Cycle up to lift position (process blind rivet). |
| Input 2 | "reverse cycle" | Reverse cycle (load new blind rivet). |
| Input 3 | "rivet query mouth piece" | Sensor for monitoring loading process. |

Input 3 "rivet query mouth piece" is designed for the use of a GAV in a fully automatic blind riveting tool. A suitable sensor (make contact 24V DC e.g. light barrier) has to be installed in the blind riveting tool in such a way that a blind rivet loaded in the expanding mouth piece is detected in the initial position of the blind riveting tool. The signal of the sensor is evaluated by the GAV control during the loading process and, if required, will possibly be issued to output 3 as "malfunction GAV". This function is optional and must be activated during commissioning in **AUTO► MAN► menu► settings GAV► drive PLC.**

Outputs:

| | | |
|----------|-----------------------|---|
| Output 1 | "cycle ready" | GAV in initial position, no malfunction. |
| Output 2 | "cycle lift position" | Cycle reached lift position, remaining mandrel extracted. |
| Output 3 | "malfunction GAV" | Malfunction GAV |
| Output 4 | "malfunction cycle" | Cycle interrupted due to malfunction. |


Relay:

Relay R 1 is switched if output 3 is "malfunction GAV" 1 (24V).

PLC interface

28.3 Drive PLC

The flow chart shows a typical communication of a GAV8000 via PLC interface with the PLC of a device. In this example the GAV gun is mounted axially mobile on the conveying slide of a device, that has two stop positions, approx. 50 mm away from the work piece and inserts blind rivets into the work piece. To provide easy access to the mouth piece area and the mandrel ejector for maintenance and repair purposes, the conveying slide should have a further free motion available.



PLC interface

28.4 Process counter

| PLC interface test | | | | | |
|----------------------------|----|-----------------------|----|---------------------|----|
| Start cycle | 1 | I N O U T | 1 | Cycle ready | |
| Reverse cycle | 2 | | 2 | Cycle lift position | |
| Rivet query mouth p. | 3 | | 3 | Malfunction GAV | R1 |
| Cycle close start | 4 | | 4 | Malfunction cycle | |
| Counter start | 5 | | 5 | Counter/Part ready | R2 |
| Profile 1 | 6 | | 6 | MAN | |
| Next profile | 7 | | 7 | Process/Part OK | R3 |
| Select profile | 8 | | 8 | Process/Part NOK | R4 |
| Profile list/Profile Bit 0 | 9 | | 9 | Error code Bit 0 | |
| Profile list/Profile Bit 1 | 10 | | 10 | Error code Bit 1 | |
| Profile list/Profile Bit 2 | 11 | | 11 | Error code Bit 2 | |
| Profile list/Profile Bit 3 | 12 | | 12 | Error code Bit 3 | |
| Evaluation part | 13 | | 13 | Maintenance | R5 |
| | 14 | | 14 | | |
| | 15 | | 15 | | |
| | 16 | | 16 | | R6 |

Back
Off
Toggle
Switch
C

Prozess counter

Navigation:

AUTO

- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ PLC interface test

System requirements:

- PLC interface connected to GAV.
- Process counter active (see chapter 13 "process counter").
- No process list active (see chapter 11 "process monitoring").

Inputs:

With rising edge on output 5 "counter start" at 1 (24V), the counter is set to target value (number of blind rivets to be processed).

Outputs:

Output 5 "counter/part finished" becomes 1 (24V), after the set number of blind rivets was processed (counter at 0).

The GAV may be stopped after reaching the set number of riveting processes (see paragraph "additional functions") with the help of a bridge from output 5 "counter/part finished" to input 4 "lock cycle start".

Relay:

Relay R2 switches when output 5 "counter/part finished" is at 1 (24V).

Example (see image):

Output 5 "counter/part finished" signals that the set number of blind rivets has been processed. The next step is to reset the process counter via input 5 "counter start".

PLC interface

28.5 Select profile list

Not included in GAV-8000 eco

| PLC interface test | | | |
|----------------------------|----|--|---------------------------|
| Start cycle | 1 | | 1 Cycle ready |
| Reverse cycle | 2 | | 2 Cycle lift position |
| Rivet query mouth p. | 3 | | 3 Malfunction GAV [R1] |
| Cycle close start | 4 | | 4 Malfunction cycle |
| Counter start | 5 | | 5 Counter/Part ready [R2] |
| | 6 | | 6 MAN |
| Profile 1 | 7 | | 7 |
| Next profile | 8 | | 8 Process/Part OK [R3] |
| Select profile | 9 | | 9 Process/Part NOK [R4] |
| Profile list/Profile Bit 0 | 10 | | 10 Error code Bit 0 |
| Profile list/Profile Bit 1 | 11 | | 11 Error code Bit 1 |
| Profile list/Profile Bit 2 | 12 | | 12 Error code Bit 2 |
| Profile list/Profile Bit 3 | 13 | | 13 Error code Bit 3 |
| Evaluation part | 14 | | 14 |
| | 15 | | 15 Maintenance [R5] |
| | 16 | | 16 [R6] |

Back Off Toggle Switch C

Select profile list

Navigation:

AUTO

► MAN

► Menu

► Process monitoring

► Profile

► List

► PLC

► Test

System requirements:

- PLC interface connected to GAV.
- Process monitoring and profile list active (see chapter 11 "process monitoring").
- Process lists ready for selection (see chapter 11 "process monitoring").

Inputs:

Input 9 "Select profile" must be 0 (0V). Inputs 10 to 13 "profile list" allow a selection of maximal 10 available profile lists. When 0 (0000) is selected, the last profile list selected remains active.

| Setting profile list PLC | | | |
|--|---------------|-----------------|--|
| Selection profile lists from PLC interface | | | |
| No | Designation | Part art.no. | |
| 1 | 0000 Modul 01 | 000123456789-01 | |
| 2 | 0100 Modul 02 | 000123456789-02 | |
| 3 | 1100 Modul 03 | 000123456789-03 | |
| 4 | 0010 Modul 04 | 000123456789-04 | |
| 5 | 1010 Modul 05 | 000123456789-05 | |
| 6 | 0110 Modul 06 | 000123456789-06 | |
| 7 | 1110 | | |
| 8 | 0001 | | |
| 9 | 1001 | | |
| 10 | 0101 | | |

Back Test

For selection of available profile lists

Navigation:

AUTO

► MAN

► Menu

► Prozess monitoring

► Profile

► List

► PLC

Example (see images):

Selection 5 (1010) at inputs 10 to 13 "profile list" activates profile list "TEST list 05".

PLC interface

28.6 Selecting a profile directly

Not included in GAV-8000 eco

| PLC interface test | | | |
|----------------------------|----|---------------------------|----|
| Start cycle | 1 | I N O U T | 1 |
| Reverse cycle | 2 | | 2 |
| Rivet query mouth p. | 3 | | 3 |
| Cycle close start | 4 | | 4 |
| Counter start | 5 | | 5 |
| | 6 | | 6 |
| Profile 1 | 7 | | 7 |
| Next profile | 8 | | 8 |
| Select profile | 9 | | 9 |
| Profile list/Profile Bit 0 | 10 | | 10 |
| Profile list/Profile Bit 1 | 11 | | 11 |
| Profile list/Profile Bit 2 | 12 | | 12 |
| Profile list/Profile Bit 3 | 13 | | 13 |
| Evaluation part | 14 | | 14 |
| | 15 | | 15 |
| | 16 | | 16 |

Back
Off
Toggle Switch
C

Selecting profile directly

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ PLC interface test

System requirements:

- PLC interface connected to GAV.
- Process monitoring and profile list active (see chapter 11 "process monitoring").

Inputs:

Input 9 "Select profile" must be 1 (24V).

Use inputs 10 to 13 "profile", to activate profile 1 (1000) to profile 15 (1111) directly from the current profile list for the next process. When 0 (0000) is selected, the last selected profile of the current profile list will be active for the next process.

During this procedure the automatic indexing within a profile list is deactivated and only applied if the sequence of used profiles is to be controlled directly by an external PLC. Merely the different profiles of a profile list will be stored, with the number of profiles for this limited to 15.

Example (see image):

Profile 3 (1100) from the current profile list will be selected for the next process.

PLC interface

28.7 Selecting a profile step by step

Not included in GAV-8000 eco

| PLC interface test | | | | | |
|----------------------------|----|---|---|----|---|
| Start cycle | 1 | I | O | 1 | Cycle ready |
| Reverse cycle | 2 | | | 2 | Cycle lift position |
| Rivet query mouth p. | 3 | | | 3 | Malfunction GAV R1 |
| Cycle close start | 4 | | | 4 | Malfunction cycle |
| Counter start | 5 | | | 5 | Counter/Part ready R2 |
| | 6 | | | 6 | MAN |
| Profile 1 | 7 | N | T | 7 | Process/Part OK R3 |
| Next profile | 8 | | | 8 | Process/Part NOK R4 |
| Select profile | 9 | | | 9 | Error code Bit 0 |
| Profile list/Profile Bit 0 | 10 | | | 10 | Error code Bit 1 |
| Profile list/Profile Bit 1 | 11 | | | 11 | Error code Bit 2 |
| Profile list/Profile Bit 2 | 12 | | | 12 | Error code Bit 3 |
| Profile list/Profile Bit 3 | 13 | | | 13 | |
| Evaluation part | 14 | | | 14 | |
| | 15 | | | 15 | Maintenance R5 |
| | 16 | | | 16 | R6 |

Selecting profile step by step

Navigation:

AUTO

▶ MAN

▶ Menu

▶ Settings GAV

▶ PLC interface test

Back
Off
Toggle Switch
C

System requirements:

- PLC interface connected to GAV.
- Process monitoring and profile list active (see chapter 11 "process monitoring").

Inputs:

Input 9 "Select profile" must be 1 (24V).

With ascending edge on input 7 "profile 1" at 1 (24V) the first profile of the current profile list is activated for the next process. With ascending edge on input 8 "forward profile" at 1 (24V) each following profile of the current profile list is activated for the next process. When reaching the end of the profile list, restart with input 7 "profile 1".

During this procedure automatic indexing within a profile list is deactivated and only applied if the sequence of used profiles is to be controlled directly by an external PLC.

Example (see image):

With ascending edge on input 7 "profile 1" at 1 (24V) the first profile of the current profile list is activated for the next process.

PLC interface

28.8 Evaluation process

Not included in GAV-8000 eco

| PLC interface test | | | |
|----------------------------|----|---------------------------|---|
| Start cycle | 1 | I N O U T | 1 Cycle ready |
| Reverse cycle | 2 | | 2 Cycle lift position |
| Rivet query mouth p. | 3 | | 3 Malfunction GAV R1 |
| Cycle close start | 4 | | 4 Malfunction cycle |
| Counter start | 5 | | 5 Counter/Part ready R2 |
| | 6 | | 6 MAN |
| Profile 1 | 7 | | 7 |
| Next profile | 8 | | 8 Process/Part OK R3 |
| Select profile | 9 | | 9 Process/Part NOK R4 |
| Profile list/Profile Bit 0 | 10 | | 10 Error code Bit 0 |
| Profile list/Profile Bit 1 | 11 | | 11 Error code Bit 1 |
| Profile list/Profile Bit 2 | 12 | | 12 Error code Bit 2 |
| Profile list/Profile Bit 3 | 13 | | 13 Error code Bit 3 |
| Evaluation part | 14 | | 14 |
| | 15 | | 15 Maintenance R5 |
| | 16 | | 16 R6 |

Back
Off
Toggle Switch
C

Evaluation process

Navigation:

- AUTO
- ▶ MAN
- ▶ Menu
- ▶ Settings GAV
- ▶ PLC interface test

System requirements:

- PLC interface connected to GAV.
- Process monitoring and profile list active (see chapter 11 "process monitoring").

Inputs:

Input 9 "select profile" and input 14 "evaluation component part" must be at 0 (0V) .

Outputs:

- At the start of each process output 8 evaluation "process IO", output 9 evaluation "process NIO" and outputs 10 to 13 "error code" are set at 0 (0V).
- At the end of each process 1 (24V) is issued for the evaluation "process IO" at output 8 or "process NIO" at output 9. An error code will be issued at the outputs 10 to 13 if evaluation is "process NIO".

| Error code (outputs 10 to 13) | | | | | | |
|-------------------------------|-------------------------|--------------|-------|-------|-------|-------|
| Code | Tearing force | Tearing path | Bit 0 | Bit 1 | Bit 2 | Bit 3 |
| 0 | IO | IO | 0 | 0 | 0 | 0 |
| A | exceeded | IO | 1 | 0 | 0 | 0 |
| B | exceeded | exceeded | 0 | 1 | 0 | 0 |
| C | IO | exceeded | 1 | 1 | 0 | 0 |
| EN | not achieved | exceeded | 0 | 0 | 1 | 0 |
| E | not achieved | IO | 1 | 0 | 1 | 0 |
| F | not achieved | not achieved | 0 | 1 | 1 | 0 |
| G | IO | not achieved | 1 | 1 | 1 | 0 |
| H | exceeded | not achieved | 0 | 0 | 0 | 1 |
| 9 | No measuring values | | 1 | 0 | 0 | 1 |
| 10 | Monitoring device ready | | 0 | 1 | 0 | 1 |

| | | |
|---|---|----|
| H | A | B |
| G | 0 | C |
| F | E | EN |

Relay

Relay R3 switches when output 8 evaluation "part IO" is at 1 (24V).
 Relay R4 switches when output 9 evaluation "part NIO" is at 1 (24V).


Example (see image):

Evaluation "Process NIO", error code 6 "tear off force and tear off distance not achieved".

PLC interface

28.9 Evaluation component part

Not included in GAV-8000 eco



System requirements:

- PLC interface connected to GAV.
- Process monitoring and profile list active (see chapter 11 "process monitoring").
- Profile list active (see chapter 11 "process monitoring").

Inputs:

Input 9 "select profile" must be at 0 (0V) and input 14 "evaluation component part" must be at 1 (24V).

Outputs:

- At the start of the first process (first profile in profile list) output 8 evaluation "part IO" is set at 1 (24V), output 9 evaluation "part NIO" at 0 (0V) and output 5 "part finished" at 0 (0V).
- When an error occurs during the processing of the blind rivet, output 8 evaluation "part IO" will be set to 0 (0V) and output 9 evaluation "part NIO" to 1 (24V).
- After the last process was finished (last profile in profile list) and after reaching initial position output 5 "part finished" will be set to 1 (24V).

The outputs error code 10 to 13 is set to 0 (0V). The error code always relates to the evaluation of a process and is not issued when a component part is being evaluated.

Relay:

Relay R2 switches when output 5 "counter/part finished" is at 1 (24V).
 Relay R3 switches when output 8 evaluation "part IO" is at 1 (24V).
 Relay R4 switches when output 9 evaluation "part NIO" is at 1 (24V).

Example (see image):

Message "part finished", evaluation "part NIO", no error code.

PLC interface

28.10 Other functions

| PLC interface test | | | | | | | | | | | | | | | |
|--|----|--|--|--|--|--|--|--|--|--|--|--|--|----|------------------------------------|
| Start cycle | 1 | | | | | | | | | | | | | 1 | Cycle ready |
| Reverse cycle | 2 | | | | | | | | | | | | | 2 | Cycle lift position |
| Rivet query mouth p. | 3 | | | | | | | | | | | | | 3 | Malfunction GAV R1 |
| Cycle close start | 4 | | | | | | | | | | | | | 4 | Malfunction cycle |
| Counter start | 5 | | | | | | | | | | | | | 5 | Counter/Part ready R2 |
| | 6 | | | | | | | | | | | | | 6 | MAN |
| Profile 1 | 7 | | | | | | | | | | | | | 7 | |
| Next profile | 8 | | | | | | | | | | | | | 8 | Process/Part OK R3 |
| Select profile | 9 | | | | | | | | | | | | | 9 | Process/Part NOK R4 |
| Profile list/Profile Bit 0 | 10 | | | | | | | | | | | | | 10 | Error code Bit 0 |
| Profile list/Profile Bit 1 | 11 | | | | | | | | | | | | | 11 | Error code Bit 1 |
| Profile list/Profile Bit 2 | 12 | | | | | | | | | | | | | 12 | Error code Bit 2 |
| Profile list/Profile Bit 3 | 13 | | | | | | | | | | | | | 13 | Error code Bit 3 |
| Evaluation part | 14 | | | | | | | | | | | | | 14 | |
| | 15 | | | | | | | | | | | | | 15 | Maintenance R5 |
| | 16 | | | | | | | | | | | | | 16 | R6 |
| <div>Back</div> <div>Off</div> <div>Toggle Switch</div> <div>C</div> | | | | | | | | | | | | | | | |

Other functions

Navigation:
 AUTO
 ▶ MAN
 ▶ Menu
 ▶ Settings GAV
 ▶ PLC interface test

Inputs:

Input 4 "lock cycle start".

Input 4 "lock cycle start" at 1 (24V) can be used in "AUTO" MODE, to lock all trigger options (manual, foot, PLC etc).

Outputs:

Output 6 "MAN".

Output 6 "MAN" at 1 (24V) shows that the GAV8000 is in "MAN" mode (manual control, setting, error elimination, maintenance etc.).

Output 15 "maintenance".

Output 15 "maintenance" at 1 (24V) shows that GAV8000 needs servicing (see chapter 10 "maintenance").

Relay:

Relay R5 switches when output 15 "maintenance" is at 1 (24V).


Automatic blind riveting system GAV-electronic Model 8000 Model 8000 eco

Spare parts and extras



Spare parts


Assembly overview



| Assembly no. | Designation | Page |
|--------------|--|--------------|
| 1 | Pneumatics - control block | 3 - 4 |
| 2 | Blind riveting gun standard | 5 - 11 |
| 2-R | robotic | 5-R - 11-R |
| 2-U | type U | 5-U - 11-U |
| 2-UA | type U with pressure monitoring device | 5-UA - 11-UA |
| 3 | Hydraulics - amplifier unit | 12 - 13 |
| 4 | Singulator | 14 |
| 5 | Case unit | 15 |
| 6 | Oscillating conveyor unit | 16 |
| 7 | Feed bundle | 17 |
| 8 | Control electrical unit | 18 |
| 9 | Accessories | 19 - 20 |
| 10 | Front plate | 21 |
| 11 | Cable tree | 22 - 23 |

Spare parts

E 1 pneumatic assembly




Spare parts

E 1 pneumatic assembly

| Item | Part No. | Article No. | Designation |
|------|----------|-------------|-------------------------------------|
| 2 | 1-8002 | 719 1243 | Maintenance unit (without 8028) |
| 3 | 1-8003 | 719 1294 | Pressure tank (without 8045 / 8048) |
| 12 | 1-8012 | 719 1359 | Banjo bolt |
| 15 | 1-8015 | 719 1112 | Sealing plate |
| 16 | 1-8016 | 719 5559 | Twin vent valve |
| 16.0 | | 719 1189 | Sealing for 16 (2x) |
| 20 | 1-8020 | 719 1367 | Blast air throttle |
| 26 | 1-8026 | 719 2886 | Vacuum head (without 8012 / 8086) |
| 26.0 | | 719 0565 | Vacuum head – working part set |
| 28 | 1-8028 | 719 2916 | Pressure control valve |
| 30 | 1-8030 | 719 1113 | Valve block assembly |
| 32.1 | 1-8032 | 719 1114 | 5/2 Reversing valve AR Y4 |
| 32.2 | 1-8032 | 719 1114 | 5/2 Reversing valve AR Y5 |
| 33.1 | 1-8033 | 719 1115 | 3/2 Twin valve GR Y3 |
| 33.2 | 1-8033 | 719 1115 | 3/2 Twin valve GR Y1 |
| 34 | 1-8034 | 719 1116 | 3/2 Twin valve IR Y2 |
| 40.1 | 1-8040 | 719 2014 | Pressure sensor DS1 |
| 40.2 | 1-8040 | 719 2014 | Pressure sensor DS2 |
| 41 | 1-8041 | 719 2016 | Ring sensor |
| 45 | 1-8045 | 719 9244 | Quick vent valve |
| 46 | 1-8046 | 719 0700 | Pressure gauge (2x) |
| 52 | 1-8052 | 719 7667 | Elbow-type screwed joint |
| 57.1 | 1-8057 | 719 4064 | Elbow-type screwed joint assembly |
| 61 | 1-8061 | 719 5672 | Elbow-type screwed joint |
| 80 | 1-8080 | 719 1383 | Sound absorber |
| 82 | 1-8082 | 719 6962 | Throttle sound absorber |
| 130 | 1-8130 | 719 7772 | Piston-style proportioner |
| 135 | 1-8135 | 719 3874 | Piston rod assembly |
| 144 | 1-8144 | 719 0137 | Locking screw assembly |
| 175 | 1-8175 | 719 1119 | Check valve assembly |

Spare parts

E2 Blind riveting gun




Spare parts

E2-R

E2-R Blind riveting gun robotic

E2-R Blind riveting gun robotic




GESIPA®

E2-U

E2-U Blind riveting gun type U

Spare parts

E2-U Blind riveting gun type U




GESIPA®

Spare parts

E2-UA

E2-U Blind riveting gun type U with pressure monitoring device

E2-U Blind riveting gun type U
with pressure monitoring device



GESIPA®

80/..... kompl.


6150

28b

6190 V

28a

80/.....F kompl.



GESIPA®



This diagram illustrates the exploded view of a GESIPA E2 Blind rivet assembly. The components are numbered as follows:

- Main Body (9):** The central cylindrical part of the rivet.
- Mandrel (20):** The long rod used to pull the rivet together.
- Washers and Spacers:** Various colored rings (green, yellow, blue, grey, black) used for spacing and protection, including parts 12, 147, 18, 19, 42, 48, 49, 55, 70, 71, 72, 73, 74, 75, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93.
- End Components:** The nuts and washers at the ends of the assembly, including parts 13, 17, 18, 19, 23, 24, 29, 30, 31, 35, 36, 39, 41, 43, 44, 47, 50, 51, 56, 69, 70, 71, 72, 73, 74, 75, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93.

The diagram shows the assembly process where the mandrel is inserted through the main body and the various washers and spacers are placed around it. The end components are then used to secure the assembly.

Spare parts

E2-R Blind riveting gun robotic





Spare parts

E2-U

E2-U Blind rivetting gun type U

E2-U Blind rivetting gun type U





GESIPA®

Spare parts

E2-UA

E2-U Blind riveting gun type U with pressure monitoring device



E2-U Blind riveting gun type U
with pressure monitoring device



GESIPA®

Spare parts

E2-V Blind rivetting gun type V



Spare parts

E2 Blind riveting gun

| Item | Part No. | Article No. | Designation |
|--|----------|-------------|--|
| 0 | 2-6000 | 719 9465 | Blind riveting gun assembly |
| 1 | 2-6001 | 719 0921 | Case assembly |
| 2 | 2-0002 | 719 2029 | Cover |
| 3 | 2-6003 | 719 0913 | Thread plug |
| 205 | 2-6205 | 719 9201 | Chuck cage 36° (denomination: 1 ring) |
| 5 | 2-6005 | 719 1626 | Chuck cage 28° (denomination: 2 rings) |
| 9 • | 2-6009 | 719 1413 | Tensile piece assembly |
| 10 | 2-6010 | 719 4803 | Tensile piece fully assembled |
| 11 | 2-0011 | 719 2118 | Snap hose assembly |
| 11.1 | | 719 9252 | Snap hose assembly fully assembled |
| 12 • | 2-6012 | 719 0905 | Cylinder collar |
| 13 • * | 2-6013 | 719 0891 | Reset piston assembly with part no. 6083 and 6085 |
| 16 | 2-0016 | 719 2169 | Jacketed ring |
| 17 ° | 2-0017 | 719 2177 | Washer |
| 18 | 2-0018 | 719 2185 | Washer |
| 19 | 2-0019 | 719 2193 | Washer |
| 20 • * | 2-6020 | 719 1421 | Stop piston assembly with part no. 2-55 |
| 20.1 * | 2-6020.1 | 719 1944 | Stop piston assembly with part no. 2-55 4mm elongation |
| 21 | 2-6021 | 719 1235 | Stop ring |
| 22 | 2-0022 | 719 2223 | Snap collet |
| 6022 | 2-6022 | 719 1774 | Snap collet for expanding mouth piece 2-80/F |
| 23 • | 2-6023 | 719 1405 | Feather key |
| 24 • | 2-0024 | 719 2258 | Slide Valve |
| 25 * | 2-0025 | 719 5907 | Actuator assembly |
| 27.2 | 2-0027.2 | 719 2274 | Coupling piece |
| 27.3 | 2-0027.3 | 719 1863 | Bolt |
| 27.4 | 2-0027.4 | 719 2363 | Pressure spring |
| 27.5 ° | 2-0027.5 | 719 5699 | O-ring 8.5 x 2 |
| 28 | 2-0028 | 719 2282 | Vent screw (2x) |
| 529 • | 2-0529 | 719 2290 | Hub collar |
| 30 * • | 2-6030 | 719 0638 | Tappet bush assembly with part no. 2-56 |
| 31 • | 2-6031 | 719 0875 | Stop bush |
| 31.1 | 2-6031.1 | 719 9457 | Stop bush 2mm shorter |
| <ul style="list-style-type: none"> • Included for tensile piece assembly no. 10 * Only available as sub-assembly ° Included for sealing no. 191 | | | |

Spare parts

E2-R Blind riveting gun robotic

| <u>Articel-No.</u> | <u>Part No.</u> | <u>Discription</u> |
|--------------------|--------------------|---|
| 719 1642 | GAV 2 - 6000R | blind riveting tool, complete |
| 719 4765 | GAV 2 - 6000R/1 | sealing set |
| 719 4641 | GAV 2 - 6001R 1 | holding fixture |
| 719 4668 | GAV 2 - 6001R 2 | housing |
| 719 4676 | GAV 2 - 6001R 3 | tube bow |
| 719 4684 | GAV 2 - 6001R 4 | clamping ring |
| 719 4692 | GAV 2 - 6001R 5 | tube clamp |
| 719 4714 | GAV 2 - 6001R 7 | cap |
| 719 7675 | GAV 2 - 6001R 9 | straight screwing |
| 719 7721 | GAV 2 - 6001R 11 | reducing fitting |
| 719 5974 | GAV 2 - 6001R 13 | plastic hose |
| 719 4757 | GAV 2 - 6001R 17 ° | o-ring 40x2,5 (3x) |
| 719 2371 | GAV 2 - 6001R 19 | screw M5x12 |
| 719 4773 | GAV 2 - 6001R 20 | srewM6x12 |
| 719 9201 | GAV 2 - 6205 | jaw housing 36° (identification: 1 ring) |
| 719 1626 | GAV 2 - 6005 | jaw housing 28° (identification: 2 rings) |
| 719 1413 | GAV 2 - 6009 • | traction rod complete |
| 719 4803 | GAV 2 - 6010 | traction rod complete assembled |
| 719 2118 | GAV 2 - 11 | closing tube complete |
| 719 9252 | GAV 2 - 11.1 | closing tube complete assembled |
| 719 0905 | GAV 2 - 6012 • | mandrel control rod guide tube |
| 719 0891 | GAV 2 - 6013 * • | rest plunger with Part No. 6083 + 6085 |
| 719 2169 | GAV 2 - 16 | traction rod gasket |
| 719 2177 | GAV 2 - 17 ° | plate |
| 719 2185 | GAV 2 - 18 | plate |
| 719 2193 | GAV 2 - 19 | plate |
| 719 1421 | GAV 2 - 6020 * • | stopping rod complete with Part. No. 55 |
| 719 1944 | GAV 2 - 6020.1* | stopping rod complete SL4 with Part. No. 2-55 4mm lengthened |
| 719 1235 | GAV 2 - 6021 | stopping ring |
| 719 2223 | GAV 2 - 22 | spreader nosepiece locking tube 2-80 |
| 719 1774 | GAV 2 - 6022 | spreader nosepiece locking tube 2-80/F |
| 719 1405 | GAV 2 - 6023 • | feather key |
| 719 2258 | GAV 2 - 24 • | slider |
| 719 2274 | GAV 2 - 27/2 | coupler |
| 719 1863 | GAV 2 - 27/3 | pin |
| 719 2363 | GAV 2 - 27/4 | compression spring |
| 719 5699 | GAV 2 - 27/5 ° | o-ring 8,5 x 2 |
| 719 2282 | GAV 2 - 28 | air bleeding screw (2x) |
| 719 2290 | GAV 2 - 529 • | sleeve |

* contained in part complete No. 2-6010 traction rod

• only available as a set of parts

° contained in part No. 2-6000R/1 sealing set

Spare parts

E2-U Blind rivetting gun type U

| <u>Article-No.</u> | <u>Part-No.</u> | <u>Discription</u> |
|--------------------|------------------|--|
| 719 0182 | GAV 2 – 6000U | blind riveting tool, complete |
| 719 7535 | GAV 2 – 6001U | housing complete |
| 719 7667 | GAV 2 – 6001U7 | screw in connection |
| 719 2029 | GAV 2 - 2 | cover |
| 719 0913 | GAV 2 - 6003 | threaded plug |
| 719 9201 | GAV 2 - 6205 | jaw housing 36° (identification 1 ring) |
| 719 1626 | GAV 2 - 6005 | jaw housing 28° (identification 2 rings) |
| 719 1413 | GAV 2 - 6009 • | traction rod complete |
| 719 4803 | GAV 2 - 6010 | traction rod complete assembled |
| 719 2118 | GAV 2 - 11 | closing tube complete |
| 719 9252 | GAV 2 - 11.1 | closing tube complete assembled |
| 719 0905 | GAV 2 - 6012 • | mandrel control rod guide tube |
| 719 0891 | GAV 2 - 6013 * • | reset plunger with Part No. 6083 + 6085 |
| 719 2169 | GAV 2 - 16 | traction rod gasket |
| 719 2177 | GAV 2 - 17 ° | plate |
| 719 2185 | GAV 2 - 18 | plate |
| 719 2193 | GAV 2 - 19 | plate |
| 719 1421 | GAV 2 - 6020 * • | stopping rod complete with Part No. 2-55 |
| 719 1944 | GAV 2 - 6020.1 * | stopping rod complete SL4 with Part No. 2-55 4mm lengthened |
| 719 1235 | GAV 2 - 6021 | stopping ring |
| 719 2223 | GAV 2 - 22 | locking tube |
| 719 1774 | GAV 2 - 6022 | spreader nosepiece locking tube 2-80/F |
| 719 1405 | GAV 2 - 6023 • | feather key |
| 719 2258 | GAV 2 - 24 • | slider |
| 719 5907 | GAV 2 - 25 * | triggervalue assembly complete |
| 719 2274 | GAV 2 - 27/2 | coupler |
| 719 1863 | GAV 2 - 27/3 | pin |
| 719 2363 | GAV 2 - 27/4 | compression spring |
| 719 5699 | GAV 2 - 27/5 ° | o-ring 8,5 x 2 |
| 719 2282 | GAV 2 - 28 | air bleeding screw (2x) |
| 719 2290 | GAV 2 - 529 • | sleeve |
| 719 0638 | GAV 2 - 6030 * • | jaw closing tube bushing complete with Part No. 2-56 |
| 719 0875 | GAV 2 - 6031 • | stop sleeve |
| 719 9457 | GAV 2 - 6031.1 | stop sleeve shortened by 2 mm |

• contained in part complete No. 2-6010 traction rod

* only available as a set of parts

° contained in part No. 2-6191 sealing set

Spare parts

E2-U Blind riveting gun type U with pressure monitoring device

| <u>Article-No.</u> | <u>Part-No.</u> | <u>Discription</u> |
|--------------------|------------------|---|
| 719 1074 | GAV 2 – 6000UA | blind riveting tool, complete |
| 719 1012 | GAV 2 – 6001UA | housing complete |
| 719 1077 | GAV 2 – 6001UA1 | handle |
| 719 1068 | GAV 2 – 6001UA2 | proximity switch |
| 719 7667 | GAV 2 – 6001U7 | screw in connection |
| 719 2029 | GAV 2 - 2 | cover |
| 719 0913 | GAV 2 - 6003 | threaded plug |
| 719 9201 | GAV 2 - 6205 | jaw housing 36° (identification 1 ring) |
| 719 1626 | GAV 2 - 6005 | jaw housing 28° (identification 2 rings) |
| 719 1413 | GAV 2 - 6009 • | traction rod complete |
| 719 4803 | GAV 2 - 6010 | traction rod complete assembled |
| 719 2118 | GAV 2 - 11 | closing tube complete |
| 719 9252 | GAV 2 - 11.1 | closing tube complete assembled |
| 719 0905 | GAV 2 - 6012 • | mandrel control rod guide tube |
| 719 0891 | GAV 2 - 6013 * • | reset plunger with Part No. 6083 + 6085 |
| 719 2169 | GAV 2 - 16 | traction rod gasket |
| 719 2177 | GAV 2 - 17 ° | plate |
| 719 2185 | GAV 2 - 18 | plate |
| 719 2193 | GAV 2 - 19 | plate |
| 719 1421 | GAV 2 - 6020 * • | stopping rod complete with Part No. 2-55 |
| 719 1944 | GAV 2 - 6020.1 * | stopping rod compl. SL4 with Part No. 2-55, 4mm lengt |
| 719 1235 | GAV 2 - 6021 | stopping ring |
| 719 2223 | GAV 2 - 22 | locking tube |
| 719 1774 | GAV 2 - 6022 | spreader nosepiece locking tube 2-80/F |
| 719 1405 | GAV 2 - 6023 • | feather key |
| 719 2258 | GAV 2 - 24 • | slider |
| 719 5907 | GAV 2 - 25 * | triggervalue assembly complete |
| 719 2274 | GAV 2 - 27/2 | coupler |
| 719 1863 | GAV 2 - 27/3 | pin |
| 719 2363 | GAV 2 - 27/4 | compression spring |
| 719 5699 | GAV 2 - 27/5 ° | o-ring 8,5 x 2 |
| 719 2282 | GAV 2 - 28 | air bleeding screw (2x) |
| 719 2290 | GAV 2 - 529 • | sleeve |
| 719 0638 | GAV 2 - 6030 * • | jaw closing tube bushing complete withPart No. 2-56 |
| 719 0875 | GAV 2 - 6031 • | stop sleeve |
| 719 9457 | GAV 2 - 6031.1 | stop sleeve shortened by 2 mm |

• contained in part complete No. 2-6010 traction rod

* only availabe as a set of parts

° contained in part No. 2-6191 sealing set

Spare parts

E2-V Blind rivetting gun type V

| <u>Article-No.</u> | <u>Part-No.</u> | <u>Discription</u> |
|--------------------|------------------|--|
| 719 0174 | GAV 2 – 6000V | blind riveting tool, complete |
| 719 5923 | GAV 2 – 6001.1V | housing complete |
| 719 2029 | GAV 2 - 2 | cover |
| 719 0913 | GAV 2 - 6003 | threaded plug |
| 719 9201 | GAV 2 - 6205 | jaw housing 36° (identification 1 ring) |
| 719 1626 | GAV 2 - 6005 | jaw housing 28° (identification 2 rings) |
| 719 1413 | GAV 2 - 6009 • | traction rod complete |
| 719 4803 | GAV 2 - 6010 | traction rod complete assembled |
| 719 6334 | GAV 2 – 11V | closing tube complete |
| 719 0905 | GAV 2 - 6012 • | mandrel control rod guide tube |
| 719 0891 | GAV 2 - 6013 * • | reset plunger with Part No. 6083 + 6085 |
| 719 2169 | GAV 2 - 16 | traction rod gasket |
| 719 2177 | GAV 2 - 17 ° | plate |
| 719 2185 | GAV 2 - 18 | plate |
| 719 2193 | GAV 2 - 19 | plate |
| 719 1421 | GAV 2 - 6020 * • | stopping rod complete with Part No. 2-55 overall length 186mm |
| 719 1944 | GAV 2 - 6020.1 * | stopping rod complete with Part No. 2-55 overall length 190mm |
| 719 1235 | GAV 2 - 6021 | stopping ring |
| 719 2223 | GAV 2 - 22 | locking tube |
| 719 1774 | GAV 2 - 6022 | spreader nosepiece locking tube 2-80/F |
| 719 1405 | GAV 2 - 6023 • | feather key |
| 719 2258 | GAV 2 - 24 • | slider |
| 719 5907 | GAV 2 - 25 * | triggervalue assembly complete |
| 719 2274 | GAV 2 - 27/2 | coupler |
| 719 1863 | GAV 2 - 27/3 | pin |
| 719 2363 | GAV 2 - 27/4 | compression spring |
| 719 5699 | GAV 2 - 27/5 ° | o-ring 8,5 x 2 |
| 719 2282 | GAV 2 - 28 | air bleeding screw (2x) |
| 719 2290 | GAV 2 - 529 • | sleeve |
| 719 0638 | GAV 2 - 6030 * • | jaw closing tube bushing complete with Part No. 2-56 |
| 719 0875 | GAV 2 - 6031 • | stop sleeve overall length 38mm |
| 719 9457 | GAV 2 - 6031.1 | stop sleeve overall length 36mm |

• contained in part complete No. 2-6010 traction rod

* only available as a set of parts

° contained in part No. 2-6191 sealing set

Spare parts

E2 Blind riveting gun

| Item | Part No. | Article No. | Designation |
|--|----------|-------------|--|
| 32 | 2-6032 | 719 9449 | Chuck jaw hose |
| 33 | 2-33 | 719 2339 | Locking spring |
| 33 B | 2-33 B | 719 0506 | Locking spring (9mm shorter) |
| 33 C | 2-33 C | 719 0654 | Locking spring (90° notch) |
| 33 D | 2-33 D | 719 5567 | Locking spring (without spoon) |
| 35 • | 2-35 | 719 2355 | Pressure spring |
| 36 | 2-36 | 719 2363 | Pressure spring |
| 37 | 2-37 | 719 2371 | Cheese head screw M5 x 12 |
| 39 ° | 2-39 | 719 2398 | Snap ring SW 18 |
| 40 ° | 2-40 | 719 2401 | Snap ring SW 18 shortened |
| 41 • | 2-6041 | 719 0867 | Snap ring SW 20 |
| 42 | 2-42 | 719 2428 | Locking ring SB 24 |
| 43 • ° | 2-6043 | 719 1391 | Locking ring (22 x 1.5) |
| 44 • ° | 2-6044 | 719 0859 | Snap ring SW 27 |
| 47 | 2-47 | 719 2479 | Lip seal black |
| 48 ° | 2-48 | 719 2487 | Lip seal (blue), mounting tool E9-19 (extra) |
| 49 ° | 2-49 | 719 2495 | Scraper |
| 50 ° | 2-50 | 719 2509 | O-ring 18 x 2 (4x) |
| 51 ° | 2-51 | 719 2517 | O-ring 24 x 2 |
| 52 ° | 2-52 | 719 2525 | O-ring 32 x 2 |
| 54 ° | 2-54 | 727 9884 | O-ring 3.68 x 1.78 (for 2-25) 2x |
| 55 ° | 2-55 | 719 2622 | O-ring 4.3 x 2.4 |
| 56 ° | 2-56 | 719 2568 | O-ring 6 x 1 |
| 57 ° | 2-57 | 719 2576 | USIT-ring (2x) |
| 59 ° | 2-59 | 719 2592 | Nipple |
| 63 | 2-63 | 719 7845 | Screwed joint |
| 64 | 2-64 | 719 7853 | Screwed joint |
| <ul style="list-style-type: none"> • Included for tensile piece assembly no. 10 * Only available as sub-assembly ° Included for sealing no. 191 | | | |

Spare parts

E2-R Blind rivetting gun robotic

| <u>Article-No.</u> | <u>Part No.</u> | <u>Discription</u> |
|--------------------|------------------|---|
| 719 0638 | GAV 2 - 6030 * • | jaw closing tube bushing compl. with Part No.56 |
| 719 0875 | GAV 2 - 6031 • | stop sleeve |
| 719 9457 | GAV 2 - 6031.1 | stop sleeve shortened by 2 mm |
| 719 9449 | GAV 2 - 6032 | jaw closing tube |
| 719 2339 | GAV 2 - 33 | retaining spring |
| 719 0506 | GAV 2 - 33 B | retaining spring (9mm shortened) |
| 719 0654 | GAV 2 - 33 C | retaining spring (90° groove) |
| 719 5567 | GAV 2 - 33 D | retaining spring (90° groove) |
| 719 2355 | GAV 2 - 35 • | compression spring |
| 719 2363 | GAV 2 - 36 | compression spring |
| 719 2371 | GAV 2 - 37 | socket screw M5 x 12 (3x) |
| 719 2398 | GAV 2 - 39 ° | snap ring SW l8 |
| 719 2401 | GAV 2 - 40 ° | snap ring SW 18 shortened |
| 719 0867 | GAV 2 - 6041 • | snap ring SW 20 |
| 719 2428 | GAV 2 - 42 | snap ring SB |
| 719 1391 | GAV 2 - 6043 ° • | snap ring (22 x 1,5) |
| 719 0859 | GAV 2 - 6044 ° • | snap ring SW 27 |
| 719 2479 | GAV 2 - 47 ° | slot ring black |
| 719 2487 | GAV 2 - 48 ° | slot ring (blue) -> mounting tools 9-19 needed see optional accessories page 19 and 20 |
| 719 2495 | GAV 2 - 49 ° | |
| 719 2509 | GAV 2 - 50 ° | o-ring 18 x 2 (4x) |
| 719 2517 | GAV 2 - 51 ° | o-ring 24 x 2 |
| 719 2525 | GAV 2 - 52 ° | o-ring 32 x 2 |
| 719 2622 | GAV 2 - 55 ° | o-ring 4,3 x 2,4 |
| 719 2568 | GAV 2 - 56 ° | o-ring 6 x 1 |
| 719 2576 | GAV 2 - 57 ° | USIT-Ring (2x) |
| 719 7845 | GAV 2 - 63 | plug screwing |
| 719 7853 | GAV 2 - 64 | screw in connection |

- contained in part complete No. 2-6010 traction rod
- * only available as a set of parts
- ° contained in part No. 2-6000R/1 sealing set

Spare parts

E2-U Blind rivetting gun type U

| <u>Article-No.</u> | | <u>Part-No.</u> | <u>Discription</u> |
|--------------------|-----|-----------------|---|
| 719 9449 | GAV | 2 - 6032 | jaw closing tube |
| 719 2339 | GAV | 2 - 33 | retaining spring |
| 719 0506 | GAV | 2 - 33 B | retaining spring (9mm shortened) |
| 719 0654 | GAV | 2 - 33 C | retaining spring (90° groove) |
| 719 5567 | GAV | 2 - 33 D | retaining spring (without spoon) |
| 719 2355 | GAV | 2 - 35 • | compression spring |
| 719 2363 | GAV | 2 - 36 | compression spring |
| 719 2371 | GAV | 2 - 37 | socket screw M5 x 12 (3x) |
| 719 2398 | GAV | 2 - 39 ° | snap ring SW l8 |
| 719 2401 | GAV | 2 - 40 ° | snap ring SW 18 shortened |
| 719 0867 | GAV | 2 - 6041 • | snap ring SW 20 |
| 719 2428 | GAV | 2 - 42 | snap ring SB |
| 719 1391 | GAV | 2 - 6043 ° • | snap ring (22 x 1,5) |
| 719 0859 | GAV | 2 - 6044 ° • | snap ring SW 27 |
| 719 2479 | GAV | 2 - 47 | slot ring black |
| 719 2487 | GAV | 2 - 48 ° | slot ring blue -> mounting tools 9-19 needed see optional accessories page 19 and 20 |
| 719 2495 | GAV | 2 - 49 ° | wiper |
| 719 2509 | GAV | 2 - 50 ° | o-ring 18 x 2 (4x) |
| 719 2517 | GAV | 2 - 51 ° | o-ring 24 x 2 |
| 719 2525 | GAV | 2 - 52 ° | o-ring 32 x 2 |
| 727 9884 | GAV | 2 - 54 ° | o-ring 3,68 x 1,78 (für 2-25) 2x |
| 719 2622 | GAV | 2 - 55 ° | o-ring 4,3 x 2,4 |
| 719 2568 | GAV | 2 - 56 ° | o-ring 6 x 1 |
| 719 2576 | GAV | 2 - 57 ° | USIT-ring (2x) |
| 719 2592 | GAV | 2 - 59 ° | nipple |
| 719 7845 | GAV | 2 - 63 | plug screwing |
| 719 7853 | GAV | 2 - 64 | screw in connection |

- contained in part complete No. 2-6010 traction rod
- * only available as a set of parts
- ° contained in part No. 2-6191 sealing set

Spare parts

E2-U Blind rivetting gun type U with pressure monitoring device

| <u>Article-No.</u> | | <u>Part-No.</u> | <u>Discription</u> |
|--------------------|-----|-----------------|---|
| 719 9449 | GAV | 2 - 6032 | jaw closing tube |
| 719 2339 | GAV | 2 - 33 | retaining spring |
| 719 0506 | GAV | 2 - 33 B | retaining spring (9mm shortened) |
| 719 0654 | GAV | 2 - 33 C | retaining spring (90° groove) |
| 719 5567 | GAV | 2 - 33 D | retaining spring (without spoon) |
| 719 2355 | GAV | 2 - 35 • | compression spring |
| 719 2363 | GAV | 2 - 36 | compression spring |
| 719 2371 | GAV | 2 - 37 | socket screw M5 x 12 (3x) |
| 719 2398 | GAV | 2 - 39 ° | snap ring SW l8 |
| 719 2401 | GAV | 2 - 40 ° | snap ring SW 18 shortened |
| 719 0867 | GAV | 2 - 6041 • | snap ring SW 20 |
| 719 2428 | GAV | 2 - 42 | snap ring SB |
| 719 1391 | GAV | 2 - 6043 ° • | snap ring (22 x 1,5) |
| 719 0859 | GAV | 2 - 6044 ° • | snap ring SW 27 |
| 719 2479 | GAV | 2 - 47 | slot ring black |
| 719 2487 | GAV | 2 - 48 ° | slot ring blue -> mounting tools 9-19 needed see optional accessories page 19 and 20 |
| 719 2495 | GAV | 2 - 49 ° | wiper |
| 719 2509 | GAV | 2 - 50 ° | o-ring 18 x 2 (4x) |
| 719 2517 | GAV | 2 - 51 ° | o-ring 24 x 2 |
| 719 2525 | GAV | 2 - 52 ° | o-ring 32 x 2 |
| 727 9884 | GAV | 2 - 54 ° | o-ring 3,68 x 1,78 (für 2-25) 2x |
| 719 2622 | GAV | 2 - 55 ° | o-ring 4,3 x 2,4 |
| 719 2568 | GAV | 2 - 56 ° | o-ring 6 x 1 |
| 719 2576 | GAV | 2 - 57 ° | USIT-ring (2x) |
| 719 2592 | GAV | 2 - 59 ° | nipple |
| 719 7845 | GAV | 2 - 63 | plug screwing |
| 719 7853 | GAV | 2 - 64 | screw in connection |

- contained in part complete No. 2-6010 traction rod
- * only available as a set of parts
- ° contained in part No. 2-6191 sealing set

Spare parts

E2-V Blind rivetting gun type V

| <u>Article-No.</u> | | <u>Part-No.</u> | <u>Discription</u> |
|--------------------|-----|-----------------|---|
| 719 9449 | GAV | 2 - 6032 | jaw closing tube |
| 719 2339 | GAV | 2 - 33 | retaining spring |
| 719 0506 | GAV | 2 - 33 B | retaining spring (9mm shortened) |
| 719 0654 | GAV | 2 - 33 C | retaining spring (90° groove) |
| 719 5567 | GAV | 2 - 33 D | retaining spring (without spoon) |
| 719 2355 | GAV | 2 - 35 • | compression spring |
| 719 2363 | GAV | 2 - 36 | compression spring |
| 719 2371 | GAV | 2 - 37 | socket screw M5 x 12 (3x) |
| 719 2398 | GAV | 2 - 39 ° | snap ring SW l8 |
| 719 2401 | GAV | 2 - 40 ° | snap ring SW 18 shortened |
| 719 0867 | GAV | 2 - 6041 • | snap ring SW 20 |
| 719 2428 | GAV | 2 - 42 | snap ring SB |
| 719 1391 | GAV | 2 - 6043 ° • | snap ring (22 x 1,5) |
| 719 0859 | GAV | 2 - 6044 ° • | snap ring SW 27 |
| 719 6342 | GAV | 2 - 6047 | piston sealing set (2x) |
| 719 2487 | GAV | 2 - 48 ° | slot ring blue -> mounting tools 9-19 needed see optional accessories page 19 and 20 |
| 719 2495 | GAV | 2 - 49 ° | wiper |
| 719 2509 | GAV | 2 - 50 ° | o-ring 18 x 2 (4x) |
| 719 2517 | GAV | 2 - 51 ° | o-ring 24 x 2 |
| 719 2525 | GAV | 2 - 52 ° | o-ring 32 x 2 |
| 727 9884 | GAV | 2 - 54 ° | o-ring 3,68 x 1,78 (für 2-25) 2x |
| 719 9694 | GAV | 2 - 6086 | o-ring 6,75 x 1,78 (für 2-25) 1x |
| 719 2622 | GAV | 2 - 55 ° | o-ring 4,3 x 2,4 |
| 719 2568 | GAV | 2 - 56 ° | o-ring 6 x 1 |
| 719 2576 | GAV | 2 - 57 ° | USIT-ring (2x) |
| 719 2592 | GAV | 2 - 59 ° | nipple |
| 719 7845 | GAV | 2 - 63 | plug screwing |
| 719 7853 | GAV | 2 - 64 | screw in connection |

- contained in part complete No. 2-6010 traction rod
- * only available as a set of parts
- ° contained in part No. 2-6191 sealing set

Spare parts

E2 Blind riveting gun

| Item | Part No. | Article No. | Designation |
|--|----------|-------------|--|
| 69 • * | 2-6069 | 719 0840 | Valve piston assembly with part no. 6079 and +6094 |
| 70 • | 2-6070 | 719 0832 | Jumper ring |
| 71 • | 2-6071 | 719 0824 | Support ring |
| 72 * ° | 2-6072 | 719 0816 | Jacketed ring assembly with part no. 6084 |
| 73 • ° | 2-6073 | 719 0441 | Spacer ring |
| 74 • | 2-6074 | 719 0808 | Stop ring |
| 75 • | 2-6075 | 719 0794 | Spacer ring |
| 76 | 2-6076 | 719 1553 | Disk |
| 77 | 2-6077 | 719 1588 | Chuck jaw stop ring |
| 81 • ° | 2-6081 | 719 0980 | O-ring 28 x 1.5 (2x) |
| 82 • ° | 2-6082 | 719 0972 | O-ring 26 x 3 |
| 83 ° | 2-6083 | 719 0964 | O-ring 16 x 2 |
| 84 • ° | 2-6084 | 719 0956 | O-ring 10 x 2 |
| 85 ° | 2-6085 | 719 7768 | O-ring 6 x 2 |
| 86 ° | 2-6086 | 719 9694 | O-ring 6.75 x 1.78 |
| 90 • | 2-6090 | 719 0778 | Pressure spring |
| 92 | 2-6092 | 719 1537 | Chuck jaw springs (3x) |
| 93 • | 2-6093 | 719 1510 | Leaf spring |
| 147 • ° | 2-6147 | 719 1901 | Lip seal green (2x) |
| 150 | 2-6150 | 719 8272 | Mouth piece lock assembly |
| 151 | 2-6151 | 719 0468 | Coupling collet |
| 152 | 2-6152 | 719 0476 | Union nut |
| 153 | 2-6153 | 719 0484 | Feather key |
| 155 | 2-6155 | 719 0492 | Shaft ring |
| 190 | 2-6190 | 719 0948 | Piston unit |
| 191 | 2-6191 | 719 0999 | Sealing set |
| 300 | 2-6300 | 719 5761 | Mandrel conveying device |
| 301 | 2-6301 | 719 8159 | Mandrel guide piece assembly |
| 302 | 2-6302 | 719 6202 | Base plate |
| 303 | 2-6303 | 719 6210 | Base |
| 313 | 2-6313 | 719 5877 | Compensating adaptor |
| 314 | 2-6314 | 719 1033 | Synthetic hose |
| 315 | 2-6315 | 719 5109 | Plug-in connection |
| 321 | 2-6321 | 719 5117 | Mandrel guide piece assembly |
| <ul style="list-style-type: none"> • Included for tensile piece assembly no. 10 * Only available as sub-assembly ° Included for sealing no. 191 | | | |

Spare parts

E2-R Blind rivetting gun robotic

| <u>Article-No.</u> | <u>Part No.</u> | <u>Discription</u> |
|--------------------|------------------|---|
| 719 0840 | GAV 2 - 6069 • * | valve rod compl. with Part No. 6079 + 609 |
| 719 0832 | GAV 2 - 6070 • | connectionsring |
| 719 0824 | GAV 2 - 6071 • | bearing ring |
| 719 0816 | GAV 2 - 6072 ° * | traction rod gasket compl. with Part No. 6084 |
| 719 0441 | GAV 2 - 6073 ° • | spacer |
| 719 0808 | GAV 2 - 6074 • | stopping ring |
| 719 0794 | GAV 2 - 6075 • | spacer |
| 719 1553 | GAV 2 - 6076 | plate |
| 719 1588 | GAV 2 - 6077 | jaw stopping ring |
| 719 0980 | GAV 2 - 6081 ° • | o-ring 28 x 1,5 (2x) |
| 719 0972 | GAV 2 - 6082 ° • | o-ring 26 x 3 |
| 719 0964 | GAV 2 - 6083 ° | o-ring 16 x 2 |
| 719 0956 | GAV 2 - 6084 ° • | o-ring 10 x 2 |
| 719 7768 | GAV 2 - 6085 ° | o-ring 6 x 2 |
| 719 0778 | GAV 2 - 6090 • | compression spring |
| 719 1537 | GAV 2 - 6092 | jaw opening spring (3x) |
| 719 1510 | GAV 2 - 6093 • | leaf spring |
| 719 1901 | GAV 2 - 6147 ° • | slot ring green (2x) |
| 719 8272 | GAV 2 - 6150 | nosepiece locking complete |
| 719 0468 | GAV 2 - 6151 | coupling sleeve |
| 719 0476 | GAV 2 - 6152 | screwed cap |
| 719 0484 | GAV 2 - 6153 | feather key |
| 719 0492 | GAV 2 - 6155 | packing ring |
| 719 0948 | GAV 2 - 6190 | plunger unit |
| 719 0999 | GAV 2 - 6191 | sealing set |
| 719 8256 | GAV 2 - 6320 | mandrel transport unit |
| 719 8159 | GAV 2 - 6301 | mandrel transducer complete |
| 719 6202 | GAV 2 - 6302 | floor plate |
| 719 6210 | GAV 2 - 6303 | foundation |
| 719 5877 | GAV 2 - 6313 | compensation adapter |
| 719 1033 | GAV 2 - 6314 | plastic hose |
| 719 5109 | GAV 2 - 6315 | plug-type connection |
| 719 5117 | GAV 2 - 6321 | mandrel leader complete |

- contained in part complete No. 2-6010 traction rod
- * only available as a set of parts
- ° contained in part No. 2-6000R/1 sealing set

Spare parts

E2-U Blind rivetting gun type U

| <u>Article-No.</u> | <u>Part No.</u> | <u>Discription</u> |
|--------------------|------------------|---|
| 719 0840 | GAV 2 - 6069 • * | valve rod compl. with Part No. 6079 + 609 |
| 719 0832 | GAV 2 - 6070 • | connectionsring |
| 719 0824 | GAV 2 - 6071 • | bearing ring |
| 719 0816 | GAV 2 - 6072 ° * | traction rod gasket compl. with Part No. 6084 |
| 719 0441 | GAV 2 - 6073 ° • | spacer |
| 719 0808 | GAV 2 - 6074 • | stopping ring |
| 719 0794 | GAV 2 - 6075 • | spacer |
| 719 1553 | GAV 2 - 6076 | plate |
| 719 1588 | GAV 2 - 6077 | jaw stopping ring |
| 719 0980 | GAV 2 - 6081 ° • | o-ring 28 x 1,5 (2x) |
| 719 0972 | GAV 2 - 6082 ° • | o-ring 26 x 3 |
| 719 0964 | GAV 2 - 6083 ° | o-ring 16 x 2 |
| 719 0956 | GAV 2 - 6084 ° • | o-ring 10 x 2 |
| 719 7768 | GAV 2 - 6085 ° | o-ring 6 x 2 |
| 719 9694 | GAV 2 - 6086 ° | o-ring 6,75 x 1,78 |
| 719 0778 | GAV 2 - 6090 • | compression spring |
| 719 1537 | GAV 2 - 6092 | jaw opening spring (3x) |
| 719 1510 | GAV 2 - 6093 • | leaf spring |
| 719 1901 | GAV 2 - 6147 ° • | slot ring green (2x) |
| 719 8272 | GAV 2 - 6150 | nosepiece locking complete |
| 719 0468 | GAV 2 - 6151 | coupling sleeve |
| 719 0476 | GAV 2 - 6152 | screwed cap |
| 719 0484 | GAV 2 - 6153 | feather key |
| 719 0492 | GAV 2 - 6155 | packing ring |
| 719 0948 | GAV 2 - 6190 | plunger unit |
| 719 0999 | GAV 2 - 6191 | sealing set |
| 719 5761 | GAV 2 - 6300 | mandrel transport unit |
| 719 8159 | GAV 2 - 6301 | mandrel transducer complete |
| 719 6202 | GAV 2 - 6302 | floor plate |
| 719 6210 | GAV 2 - 6303 | foundation |
| 719 5877 | GAV 2 - 6313 | compensation adapter |
| 719 1033 | GAV 2 - 6314 | plastic hose |
| 719 5109 | GAV 2 - 6315 | plug-type connection |
| 719 5117 | GAV 2 - 6321 | mandrel leader complete |

• contained in part complete No. 2-6010 traction rod

* only availabe as a set of parts

° contained in part No. 2-6000R/1 sealing set

Spare parts

E2-U Blind rivetting gun type U with pressure monitoring device

| Article-No. | Part No. | Discription |
|-------------|------------------|---|
| 719 0840 | GAV 2 - 6069 • * | valve rod compl. with Part No. 6079 + 609 |
| 719 0832 | GAV 2 - 6070 • | connectionsring |
| 719 0824 | GAV 2 - 6071 • | bearing ring |
| 719 0816 | GAV 2 - 6072 ° * | traction rod gasket compl. with Part No. 6084 |
| 719 0441 | GAV 2 - 6073 ° • | spacer |
| 719 0808 | GAV 2 - 6074 • | stopping ring |
| 719 0794 | GAV 2 - 6075 • | spacer |
| 719 1553 | GAV 2 - 6076 | plate |
| 719 1588 | GAV 2 - 6077 | jaw stopping ring |
| 719 0980 | GAV 2 - 6081 ° • | o-ring 28 x 1,5 (2x) |
| 719 0972 | GAV 2 - 6082 ° • | o-ring 26 x 3 |
| 719 0964 | GAV 2 - 6083 ° | o-ring 16 x 2 |
| 719 0956 | GAV 2 - 6084 ° • | o-ring 10 x 2 |
| 719 7768 | GAV 2 - 6085 ° | o-ring 6 x 2 |
| 719 9694 | GAV 2 - 6086 ° | o-ring 6,75 x 1,78 |
| 719 0778 | GAV 2 - 6090 • | compression spring |
| 719 1537 | GAV 2 - 6092 | jaw opening spring (3x) |
| 719 1510 | GAV 2 - 6093 • | leaf spring |
| 719 1901 | GAV 2 - 6147 ° • | slot ring green (2x) |
| 719 8272 | GAV 2 - 6150 | nosepiece locking complete |
| 719 0468 | GAV 2 - 6151 | coupling sleeve |
| 719 0476 | GAV 2 - 6152 | screwed cap |
| 719 0484 | GAV 2 - 6153 | feather key |
| 719 0492 | GAV 2 - 6155 | packing ring |
| 719 0948 | GAV 2 - 6190 | plunger unit |
| 719 0999 | GAV 2 - 6191 | sealing set |
| 719 5761 | GAV 2 - 6300 | mandrel transport unit |
| 719 8159 | GAV 2 - 6301 | mandrel transducer complete |
| 719 6202 | GAV 2 - 6302 | floor plate |
| 719 6210 | GAV 2 - 6303 | foundation |
| 719 5877 | GAV 2 - 6313 | compensation adapter |
| 719 1033 | GAV 2 - 6314 | plastic hose |
| 719 5109 | GAV 2 - 6315 | plug-type connection |
| 719 5117 | GAV 2 - 6321 | mandrel leader complete |

• contained in part complete No. 2-6010 traction rod

* only available as a set of parts

° contained in part No. 2-6000R/1 sealing set

Spare parts

E2-V Blind rivetting gun type V

| <u>Article-No.</u> | <u>Part No.</u> | <u>Discription</u> |
|--------------------|------------------|---|
| 719 0840 | GAV 2 - 6069 • * | valve rod compl. with Part No. 6079 + 609 |
| 719 0832 | GAV 2 - 6070 • | connectionsring |
| 719 0824 | GAV 2 - 6071 • | bearing ring |
| 719 0816 | GAV 2 - 6072 ° * | traction rod gasket compl. with Part No. 6084 |
| 719 0441 | GAV 2 - 6073 ° • | spacer |
| 719 0808 | GAV 2 - 6074 • | stopping ring |
| 719 0794 | GAV 2 - 6075 • | spacer |
| 719 1553 | GAV 2 - 6076 | plate |
| 719 1588 | GAV 2 - 6077 | jaw stopping ring |
| 719 0980 | GAV 2 - 6081 ° • | o-ring 28 x 1,5 (2x) |
| 719 0972 | GAV 2 - 6082 ° • | o-ring 26 x 3 |
| 719 0964 | GAV 2 - 6083 ° | o-ring 16 x 2 |
| 719 0956 | GAV 2 - 6084 ° • | o-ring 10 x 2 |
| 719 7768 | GAV 2 - 6085 ° | o-ring 6 x 2 |
| 719 9694 | GAV 2 - 6086 ° | o-ring 6,75 x 1,78 |
| 719 0778 | GAV 2 - 6090 • | compression spring |
| 719 1537 | GAV 2 - 6092 | jaw opening spring (3x) |
| 719 1510 | GAV 2 - 6093 • | leaf spring |
| 719 1901 | GAV 2 - 6147 ° • | slot ring green (2x) |
| 719 8272 | GAV 2 - 6150 | nosepiece locking complete |
| 719 0468 | GAV 2 - 6151 | coupling sleeve |
| 719 0476 | GAV 2 - 6152 | screwed cap |
| 719 0484 | GAV 2 - 6153 | feather key |
| 719 0492 | GAV 2 - 6155 | packing ring |
| 719 5850 | GAV 2 – 6190 V | plunger unit |
| 719 0061 | GAV 2 – 6191 V | sealing set |
| 719 5761 | GAV 2 - 6300 | mandrel transport unit |
| 719 8159 | GAV 2 - 6301 | mandrel transducer complete |
| 719 6202 | GAV 2 - 6302 | floor plate |
| 719 6210 | GAV 2 - 6303 | foundation |
| 719 5877 | GAV 2 - 6313 | compensation adapter |
| 719 1033 | GAV 2 - 6314 | plastic hose |
| 719 5109 | GAV 2 - 6315 | plug-type connection |
| 719 5117 | GAV 2 - 6321 | mandrel leader complete |

- contained in part complete No. 2-6010 traction rod
- * only availabe as a set of parts
- ° contained in part No. 2-6000R/1 sealing set

Spare parts

E2 Blind riveting gun

| Item | Part No. | Article No. | Designation | Boring Ø mm |
|-------|---------------|-------------|--|----------------|
| 80/.. | 80/ 16 | 719 0395 | Expanding mouth piece assembly | 1,6 |
| | 80/ 18 | 719 2827 | | 1,8 |
| | 80/ 20 | 719 2800 | | 2,0 |
| | 80/ 23 | 719 2835 | | 2,3 |
| | 80/ 27 | 719 2878 | | 2,7 |
| | 80/ 29 | 719 2894 | | 2,9 |
| | 80/ 32 | 719 2924 | | 3,2 |
| | 80/ 34 | 719 0646 | | 3,4 |
| | 80/ 36 | 719 2967 | | 3,6 |
| | 80/ 38 | 719 1596 | | 3,8 |
| | 80/... SL ... | 719 | Expanding mouth piece assembly, extended | |

| Item | Part No. | Article No. | Designation | Boring Ø mm |
|--------|---------------|-------------|--|----------------|
| 80/..F | 80/ 16 F | 719 2819 | Expanding mouth piece assembly | 1,6 |
| | 80/ 18 F | 719 2843 | | 1,8 |
| | 80/ 20 F | 719 2797 | | 2,0 |
| | 80/ 23 F | 719 1677 | | 2,3 |
| | 80/ 27 F | 719 1723 | | 2,7 |
| | 80/ 29 F | 719 1685 | | 2,9 |
| | 80/ 32 F | 719 1715 | | 3,2 |
| | 80/ 34 F | 719 0670 | | 3,4 |
| | 80/ 36 F | 719 1650 | | 3,6 |
| | 80/ 38 F | 719 1006 | | 3,8 |
| | 80/...F SL... | 719 | Expanding mouth piece assembly, extended | |

| Item | Part No. | Article No. | Designation |
|------|----------|-------------|-------------|
| 152 | 2-6152 | 719 0476 | Union nut |

Spare parts

E2 Blind riveting gun

| Item | Part No. | Article No. | Designation | Partition mm | Rivet mandrel Ø mm |
|------|----------|-------------|---------------------------------|--------------|--------------------|
| 161 | 2-6161 | 719 0735 | Chuck jaws 3-piece / 28° | 1.25 | 1.5 - 2.0 |
| 162 | 2-6162 | 719 1448 | | 1.25 | 2.1 - 2.6 |
| 163 | 2-6163 | 719 1545 | | 1.25 | 2.7 - 3.2 |
| 164 | 2-6164 | 719 1618 | | 1.25 | 3.3 - 3.65 |
| 165 | 2-6165 | 719 9740 | Chuck jaws 3-piece / 36° | 1.25 | 1.5 - 2.0 |
| 166 | 2-6166 | 719 9759 | | 1.25 | 2.1 - 2.6 |
| 167 | 2-6167 | 719 9767 | | 1.25 | 2.7 - 3.2 |
| 168 | 2-6168 | 719 1529 | | 1.25 | 3.3 - 3.65 |
| 171 | 2-6171 | 719 1839 | Chuck jaws F / 3-piece / 36° | 0.8 | 1.5 - 2.0 |
| 172 | 2-6172 | 719 1847 | | 0.8 | 2.1 - 2.6 |
| 173 | 2-6173 | 719 1855 | | 0.8 | 2.7 - 3.2 |
| 174 | 2-6174 | 719 1898 | | 0.9 | 3.3 - 3.65 |
| 175 | 2-6175 | 719 4293 | | 0.8 | 3.5 - 3.65 |

| Item | Part No. | Article No. | Designation | Partition mm | Rivet mandrel Ø mm |
|------|----------|-------------|---|--------------|--------------------|
| 261 | 2-6261 | 719 0204 | Chuck mechanism assembly 3-piece / 28° | 1.25 | 1.5 - 2.0 |
| 262 | 2-6262 | 719 0212 | | 1.25 | 2.1 - 2.6 |
| 263 | 2-6263 | 719 0220 | | 1.25 | 2.7 - 3.2 |
| 264 | 2-6264 | 719 0239 | | 1.25 | 3.3 - 3.65 |
| 265 | 2-6265 | 719 0247 | Chuck mechanism assembly 3-piece / 36° | 1.25 | 1.5 - 2.0 |
| 266 | 2-6266 | 719 0255 | | 1.25 | 2.1 - 2.6 |
| 267 | 2-6267 | 719 0263 | | 1.25 | 2.7 - 3.2 |
| 268 | 2-6268 | 719 0271 | | 1.25 | 3.3 - 3.65 |
| 271 | 2-6271 | 719 0298 | Chuck mechanism assembly F / 3-piece / 36° | 0.8 | 1.5 - 2.0 |
| 272 | 2-6272 | 719 0301 | | 0.8 | 2.1 - 2.6 |
| 273 | 2-6273 | 719 0328 | | 0.8 | 2.7 - 3.2 |
| 274 | 2-6274 | 719 0336 | | 0.9 | 3.3 - 3.65 |
| 275 | 2-6275 | 719 4277 | | 0.8 | 3.5 - 3.65 |


Note: Chuck case denomination

36° chuck case GAV 2-6205 = 1 ring

28° chuck case GAV 2-6005 = 2 rings

Spare parts

E3 Hydraulics - amplifier unit




| Item | Part No. | Article No. | Designation |
|------|----------|-------------|-------------------------------------|
| 30 | 3-8030 | 719 1124 | Pressure transmitter assembly |
| 30.0 | | 719 3467 | Pressure transmitter - sealing |
| 60 | 3-8060 | 719 1125 | Pressure transmitter assembly |
| 144 | 3-8144 | 719 1947 | Ring connection screwed joint |
| 146 | 3-8146 | 719 3459 | Screw joint |
| 150 | 3-8150 | 719 3092 | Top up nipple |
| 160 | 3-8160 | 719 8299 | Conical nipple |
| 176 | 3-8176 | 719 3696 | Oil bottle assembly |
| 178 | 3-8178 | 719 3661 | Support |
| 186 | 3-8186 | 719 1126 | Sensor support 2 fully equipped Ø10 |
| 189 | 3-8189 | 719 1127 | Sensor support 3 fully equipped Ø12 |
| 192 | 3-8192 | 719 2014 | Pressure sensor |
| 197 | 3-8197 | 719 1128 | Distance sensor 1 fully equipped |
| 198 | 3-8198 | 719 2019 | Distance sensor 2 fully equipped |
| 199 | 3-8199 | 719 1129 | Distance sensor 3 fully equipped |
| | | 717 1757 | Hydraulic oil 250 cm ³ |

not included in GAV-8000 eco

Spare parts


E3 Hydraulics - amplifier unit



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|--|
| 60.1 | | 719 | Pressure transmitter (without accessories) |
| 60.0 | | 719 | Pressure transmitter - sealing |
| 63 | 3-8063 | 719 2058 | Flange |
| 64 | 3-8064 | 719 4536 | Cylinder hose |
| 65 | 3-8065 | 719 4609 | Transmitter piston |
| 67 | 3-8067 | 719 4579 | Valve plate assembly |
| 68 | 3-8068 | 719 3750 | Lock nozzle |
| 69 | 3-8069 | 719 4617 | Collar screw |
| 70 | 3-8070 | 719 3726 | Plunger assembly with air piston |
| 74 | 3-8074 | 719 3815 | Cylinder pipe |
| 75 | 3-8075 | 719 6504 | Inspection glass |
| 76 | 3-8076 | 719 4560 | Valve stem |
| 77 | 3-8077 | 719 5591 | Disk |
| 79 | 3-8079 | 719 4625 | Throttle cylinder |
| 80 | 3-8080 | 719 4633 | Valve ball (2x) |
| 98 | 3-8098 | 719 4447 | Pressure spring |
| 99 | 3-8099 | 717 4595 | Pressure spring |

Spare parts


E4 singulator



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|-------------------------------|
| 0 | 4-8000 | 719 6512 | Singulator assembly |
| 2 | 4-8002 | 719 4021 | Spoon assembly |
| 7 | 4-8007 | 719 4072 | Singulator tongue |
| 8 | 4-8008 | 719 4080 | Collar screw |
| 11 | 4-8011 | 719 4110 | Spacer ring |
| 13 | 4-8013 | 719 4137 | Pressure spring |
| 125 | 4-8125 | 719 4250 | Pneumatic cylinder assembly |
| 29 | 4-8029 | 719 3122 | Throttle check valve assembly |
| 138 | 4-8138 | 719 6520 | Chute assembly |
| 43 | 4-8043 | 719 3823 | Proximity switch NS5 |
| 44 | 4-8044 | 719 3858 | Proximity switch NS4 |
| 45 | 4-8045 | 719 8604 | Proximity switch NS1 |
| 67 | 4-8067 | 719 6970 | Y-connection assembly |

Spare parts


E5 Case unit



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|--------------------|
| 0 | 5-8000 | 719 0100 | Case unit assembly |
| 2 | 5-8002 | 719 6539 | Container |
| 8 | 5-8008 | 719 3904 | Cover assembly |
| 26 | 5-8026 | 719 5370 | Lock |

Spare parts


E6 oscillating conveyor unit



| Item | Part No. | Article No. | Designation | |
|------|----------|-------------|------------------------------------|-------------|
| 0 | 6-8000 | 719 6555 | Oscillating conveyor unit assembly | 230V / 50Hz |
| | | 719 6563 | | 115V / 60Hz |
| 1 | 6-8001 | 719 6571 | Oscillating conveyor drive | 230V / 50Hz |
| | | 719 6598 | | 115V / 60Hz |
| 1.1 | 6-8002 | 719 6601 | Oscillating conveyor magnet | 230V / 50Hz |
| | | 719 6628 | | 115V / 60Hz |
| 1.2 | 6-8001.2 | 719 6636 | Vibration spring - set | |
| 2 | 6-8002 | 719 6644 | Oscillating conveyor bowl | |
| 8 | 6-8008 | 719 6652 | Bowl fixing assembly | |
| 24 | 6-8024 | 719 6679 | Counter assembly | |
| 25 | 6-8025 | 719 6660 | Basin magnet | |
| 1.3 | 6-8001.3 | 719 6989 | Rubber bearing | |
| 26 | 6-8026 | 719 8051 | Plug | |

Spare parts


E7 feed bundle



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|---|
| 0.1 | 7-8001.1 | 719 1162 | Feed bundle without rivet feed hose |
| 0.2 | 7-8002.2 | 719 1170 | Feed bundle without rivet feed hose SL. . . m |
| 20 | 7-8020 | 719 6830 | Rivet feed hose assembly Ø6 / 3.8 m |
| | | | |
| 21 | 7-8021 | 719 6849 | Rivet feed hose assembly Ø8 / 3.8 m |
| 22 | 7-8022 | 719 6881 | Rivet feed hose assembly Ø9 / 3.8 m |
| 23 | 7-8023 | 719 6857 | Rivet feed hose assembly Ø10 / 3.8 m |
| 24 | 7-8024 | 719 6865 | Rivet feed hose assembly Ø11 / 3.8 m |
| 25 | 7-8025 | 719 6873 | Rivet feed hose assembly Ø12 / 3.8 m |
| 26 | 7-8026 | 719 5524 | Rivet feed hose assembly Ø13 / 3.8 m |
| 27 | 7-8027 | 719 6903 | Rivet feed hose assembly Ø14 / 3.8 m |
| 28 | 7-8028 | 719 7071 | Rivet feed hose assembly SL. . . m |
| | | | |
| 1 | 7-8001 | 719 6725 | Hydraulic hose assembly / 3.75 m |
| 4 | 7-8004 | 719 1034 | Air control hose / 4.6 m |
| 5 | 7-8005 | 719 1010 | Hydraulic hose / 5 m |
| 6 | 7-8006 | 719 1010 | Rivet disposal hose / 5 m |
| 7 | 7-8007 | 719 1035 | Neoprene safety hose / 3.7 m |
| | | | |
| 10 | 7-8010 | 719 7403 | Retaining strap |
| 50 | 7-8050 | 719 7543 | Adapter ring |

Spare parts


E8 control



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|--|
| 1 | 8-8001 | 719 2008 | Control module with 24 E/A |
| 2 | 8-8002 | 719 2012 | Control power pack 24VDC 2.5 A |
| 4 | 8-8004 | 719 2017 | Electronic module 1x |
| 5 | 8-8005 | 719 2018 | Electronic module 2x |
| 7 | 8-8007 | 719 2007 | Electronic module oscillating conveyor control |

Spare parts

E8.1-UA Proximity switch



| Pos. | Part No. | Article-No. | Discription |
|------|----------|-------------|------------------------|
| 104 | 8-8104 | 719 1069 | Sensorcable, komplette |


Spare parts

E9 accessories


| Item | Article No. | Designation |
|------|-------------|--|
| 1 | 719 9015 | Balancer for riveting gun |
| 3 | 719 9031 | GAV carriage with extension arm |
| 7 | 719 9074 | Ventilation check valve |
| 8 | 719 9082 | Rivet guns - support unit |
| 18 | 719 9198 | Mounting cone for piston unit |
| 19 | 719 5583 | Assembly tool for lip seal |
| 20 | 719 6687 | Assembly mandrel - tensile piece |
| 21 | 719 6695 | Assembly bolt - piston unit |
| 22 | 719 6709 | Punch |
| 27 | 719 9406 | Bale grip for standard gun |
| 30 | 719 9430 | Control grip for robotic gun |
| 32 | 719 9554 | Bale grip for robotic gun |
| 46 | 719 9538 | Gun suspension - vertical |
| 49 | 719 7896 | Gun suspension horizontal |
| 50 | 719 7985 | Gun suspension for horizontal and vertical riveting |
| 52 | 719 3912 | Roller support |
| 53 | 719 7640 | Disassembly tool hose no. Ø8 |
| 54 | 719 7772 | Central lubricating device (to increase working part life) |
| 55 | 719 7780 | Collecting basin (to carry out rivet reloading processes) |
| 56 | 719 7799 | Hose assembly suspension |
| 57 | 719 7918 | Cable pull protection for balancer |
| 59 | 719 7756 | Maintenance unit lockable |
| 60 | 719 2022 | PLC interface |
| 61 | 719 1133 | Interface cable GAV |
| 62 | 719 1123 | Foot Pedal |

Spare parts


E9 assembly tools




18




19



20




21



22

Spare parts front plate


E10 front plate



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|---|
| 0 | 10-8000 | 719 0065 | Front plate assembly |
| 5 | 10-8005 | 719 2009 | Process and dialogue display assembly with fixing set |
| 40 | 10-8040 | 719 0630 | Set of screws |
| 47 | 10-8047 | 719 1120 | Push button assembly POWER green |
| 48 | 10-8048 | 719 1121 | Push button assembly ON green |
| 49 | 10-8049 | 719 1122 | Push button assembly OFF red |
| | | | Cable tree front plate assembly |

Spare parts front plate


E10 front plate eco



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|---|
| 1 | 10-8100 | 719 0105 | Front plate assembly |
| 5 | 10-8105 | 719 1996 | Process and dialogue display assembly with fixing set |
| 40 | 10-8040 | 719 0630 | Set of screws |
| 47 | 10-8047 | 719 1120 | Push button assembly POWER green |
| 48 | 10-8048 | 719 1121 | Push button assembly ON green |
| 49 | 10-8049 | 719 1122 | Push button assembly OFF red |
| | | | Cable tree front plate assembly |

Spare parts cable tree


E11 cable tree



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|---------------------|
| 1 | | | Cable tree assembly |

Spare parts cable tree


E11 cable tree



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|---------------------|
| 1 | | | Cable tree assembly |

Spare parts cable tree

E11 interface cable



| Item | Part No. | Article No. | Designation |
|------|----------|-------------|--------------------------|
| 1 | | | Interface cable assembly |