
Plug in to top to cascade 450L-APC-IO-8 = NPS # 281275
Plug in to cascade Transmitter 450L-APT-PW-8 = NPS # 279932
Plug in to Cascade Receiver 450L-APR-MU-8 = NPS # 279933
Cascade up to 3 additional pairs; 4 pairs max including host pair
450L-APU-UN-8 or 450L-APR-ED-8 or 450L-APR-MU-8
450L-APT-PW-8
450L-APR-MU-8
889D-F8NBDM-10 (max length = 30m [98.4 ft])
889D-F8NBDM-10 (max length = 30m [98.4 ft])
Connection cable to Receiver & Transmitter 889D-F8NBDM-2 = NPS # 279930 or 889D-F8NBDM-
Plug in to top to cascade 450L-APC-IO-8 = NPS # 281275
450L-APC-IO-8
450L-APC-IO-8
Plug in to top to cascade 450L-APC-IO-8 = NPS # 281275
Blanking
450L-APT-PW-5
450L-APR-EN-8
Plug in to 1st stick Receiver 450L-APR-EN-8 = NPS # 279920
Plug in to 1st stick Transmitter 450L-APT-PW-5 = NPS # 279919